 <p><b>MOTION IMAGERY STANDARDS BOARD</b></p> <p><b>STANDARD</b></p> <p><b>UAS Datalink Local Set</b></p>	<p><b>MISB ST 0601.10</b></p> <p><b>27 October 2016</b></p>
--	---

## 1 Scope

MISB ST 0601 details the Unmanned Air System (UAS) Datalink Local Set (LS) for UAS platforms. The UAS Datalink LS is an extensible Key-Length-Value (KLV) metadata set designed for transmission through a wireless communication link (Datalink).

This standard provides direction and requirements for the creation of a SMPTE ST 336 compliant Local Set for a reliable, bandwidth-efficient exchange of metadata among digital Motion Imagery systems. This standard also provides a mapping to Predator Exploitation Support Data (ESD) for continued support of existing metadata systems.

The UAS Datalink LS is intended to be produced locally within a UAS airborne platform, and encapsulated along with compressed Motion Imagery from sensors, such as Electro-Optical / Infrared (EO/IR) in an MPEG-2 Transport Stream (or equivalent). This Motion Imagery stream is transmitted over a medium bandwidth (e.g. 1 to 5Mb/s) wireless Datalink for dissemination.

This document provides an extensible, bandwidth-efficient local set for enhancing sensor-captured Motion Imagery with relevant metadata. This standard also provides a mapping between UAS Datalink LS items, Exploitation Support Data (ESD) items, and Universal Set (US) items defined in the SMPTE KLV dictionary (RP 210) and the MISB-managed ST 0807 keyspace.

## 2 References

- [1] SMPTE ST 336:2007 Data Encoding Protocol Using Key-Length-Value.
- [2] MISB EG 0104.5 Predator UAV Basic Universal Metadata Set, Dec 2006.
- [3] SMPTE RP 210v13:2012 Metadata Element Dictionary.
- [4] MISB ST 0107.2 Bit and Byte Order for Metadata in Motion Imagery Files and Streams, Feb 2014.
- [5] MISB ST 0807.18 MISB KLV Metadata Registry, Oct 2016.
- [6] MISB ST 0603.4 MISP Time System and Timestamps, Feb 2016.
- [7] MISB ST 0806.4 Remote Video Terminal Metadata Set, Feb 2014.
- [8] MISB MISP-2017.1: Motion Imagery Handbook, Oct 2016.
- [9] MISB ST 1607 Constructs to Amend/Segment KLV Metadata, 2016.
- [10] MISB ST 0604.5 Timestamps for Class 1/Class 2 Motion Imagery, Oct 2016.

- [11] MISB ST 1402.2 MPEG-2 Transport Stream for Class 1/Class 2 Motion Imagery, Audio and Metadata, Oct 2016.
- [12] MISB ST 0605.6 Encoding and Inserting Time Stamps and KLV Metadata in Class 0 Motion Imagery, Jun 2015.
- [13] MISB ST 0902.5 Motion Imagery Sensor Minimum Metadata Set, Oct 2015.
- [14] MISB ST 1010.3 Generalized Standard Deviation and Correlation Coefficient Metadata, Oct 2016.
- [15] MISB ST 1201.2 Floating Point to Integer Mapping, Oct 2015.
- [16] MIL-STD-2500C National Imagery Transmission Format Version 2.1 for the National Imagery for the National Imagery Transmission Format, May 2006.
- [17] ASI-00209 Rev D Exploitation Support Data (ESD) External Interface Control Document, 04 Dec 2002.
- [18] MISB ST 0801.5 Photogrammetry Metadata Set for Digital Motion Imagery, Feb 2014.
- [19] MISB ST 0903.4 Video Moving Target Indicator and Track Metadata, Oct 2014.
- [20] MISB ST 1204.1 Motion Imagery Identification System (MIIS) Core Identifier, Oct 2013.
- [21] MISB ST 1206 SAR Motion Imagery Metadata, Feb 2014.
- [22] MISB ST 1002.2 Range Motion Imagery, Jun 2016.
- [23] MISB ST 1601 Geo-Registration Local Set, Oct 2016.

### 3 Acronyms

<b>BER</b>	Basic Encoding Rules
<b>ESD</b>	Exploitation Support Data
<b>KLV</b>	Key Length Value
<b>LS</b>	Local Set
<b>OID</b>	Object Identifier
<b>SMPTE</b>	Society of Motion Picture Television Engineers
<b>US</b>	Universal Set

### 4 Revision History

Revision	Date	Summary of Changes
ST 0601.10	10/27/2016	<ul style="list-style-type: none"> <li>• Added Tag 97 Range Image LS, Tag 98 Geo-Registration LS</li> <li>• Added Tag 100 Segment LS and Tag 101 Amend LS; Added Section 6.5.4 on Segment LS/Amend LS</li> <li>• Added Tag 102 SDCC-FLP; Added new column in Table 1 for SDCC-FLP allowed Tag's indicator</li> <li>• Added REQ -22</li> <li>• Updated References</li> </ul>

## 5 Introduction

A SMPTE ST 336 [1] Universal Set (US) provides access to a range of KLV-formatted metadata items. MISB EG 0104.5 [2] shows a translation between basic Exploitation Support Data (ESD) and Universal Set metadata items that exist in the most current version of the SMPTE RP 210 KLV dictionary [3]. The overhead in transmitting 16-byte US keys, however, is costly in bandwidth-constrained environments. The US metadata items in EG 0104.5 are more appropriate for higher bandwidth interfaces (e.g. > 10Mb/s), whereas this document targets low-to-medium bandwidth interfaces (e.g. 1 to 5Mb/s). Note EG 0104.5 was deprecated September 2008.

UAS airborne platforms typically operate over a wireless communications channel (i.e. UAS Datalink), which has limited bandwidth. Because of the high overhead in using a Universal Set, the more bit-efficient Local Set construct is more appropriate for transmitting metadata. As discussed in SMPTE ST 336, a local set can use a 1, 2 or 4-byte tag along with a 1, 2, or 4-byte BER (Basic Encoding Rules) encoded length. The UAS Datalink Local Set uses BER-OID encoded tags and BER-encoded lengths to minimize bandwidth, while still allowing the local set ample room for growth.

This standard defines a UAS Datalink Local Set according to SMPTE KLV encoding rules. This standard is intended to be extensible to include future relevant metadata with mappings between new Local Sets (LS), US, and ESD metadata items (where appropriate). When a new metadata LS item is required, the item will be added to the proper metadata registry (public or private), if the metadata item does not already exist.

This standard also provides a mapping between LS items and currently implemented US items defined in the SMPTE RP 210 KLV registry.

### 5.1 UAS Datalink Local Set Changes and Updates

This document defines the UAS Datalink Local Set and is under configuration management.

Requirement(s)	
ST 0601.8-01	Any changes to MISB ST 0601 shall be accompanied by a document revision and date change and coordinated with the managing organization.
ST 0601.8-02	Applications that implement MISB ST 0601 shall allow for metadata items in the UAS Datalink Local Set that are unknown so that they are forward compatible with future versions of the interface.

## 6 UAS Datalink Local Set - Requirements

These requirements for the UAS Datalink Local Set are outlined here and used as references from within this text.

### 6.1 KLV Rules

Requirement(s)	
ST 0601.8-03	All UAS Datalink metadata shall be expressed in accordance with MISB ST 0107 [4].
ST 0601.8-04	All UAS Datalink metadata shall be formatted in compliance with SMPTE ST 336 [1].

## ST 0601.10 UAS Datalink Local Set

ST 0601.8-05	Implementations of MISB ST 0601 shall parse unknown, but properly formatted metadata UAS Datalink Local Set packets, so as to not impact the reading of known Tags within the same instance.
ST 0601.8-06	All instances of item Tags within a UAS Datalink LS packet shall be BER-OID encoded using the fewest possible bytes in accordance with SMPTE ST 336.
ST 0601.8-07	All instances of item length fields within a UAS Datalink LS packet shall be BER Short form or BER Long form encoded using the fewest possible bytes in accordance with SMPTE ST 336 [1].
ST 0601.8-08	All instances of a UAS Datalink LS where the computed checksum is not identical to the included checksum shall be discarded.

### 6.2 Mandatory UAS Datalink LS items

Requirement(s)	
ST 0601.8-09	All instances of a UAS Datalink LS shall contain as their first element Tag 2, Precision Time Stamp – Microseconds.
ST 0601.8-10	The value assigned to the Precision Time Stamp - Microseconds item (Tag 2) shall represent the time of birth of the metadata of all the elements contained in that instance of the UAS Datalink LS.
ST 0601.8-11	All instances of the UAS Datalink LS shall contain as the final element Tag 1, (Checksum).
ST 0601.8-12	All instances of the UAS Datalink LS shall contain Tag 65, UAS Datalink LS Version Number.

### 6.3 Metadata Usage

Requirement(s)	
ST 0601.8-13	Excepting the requirements for Tag 2 at the start and Tag 1 at the end of a UAS Datalink LS any instance of the UAS Datalink LS, an instance of an UAS Datalink LS containing any number of properly formatted, unique Tags in any order shall be valid.
ST 0601.8-14	The usage of all Tags within the UAS Datalink LS shall be consistent with the descriptions and clarifications contained within MISB ST 0601.
ST 0601.8-15	UAS Datalink LS elements that have incomplete descriptions (i.e.: “TBD”) shall be informative rather than normative.
ST 0601.8-16	UAS Datalink LS decoding systems that understand the full-range representation of certain metadata items shall use the full-range representation and ignore the range-restricted representation when both exist in the same UAS Datalink LS packet.
ST 0601.8-17	UAS Datalink LS decoding systems that understand the Height Above Ellipsoid (HAE) representation of certain metadata items shall use the HAE representation and ignore the Mean Sea Level (MSL) representation when both exist in the same UAS Datalink LS packet.
ST 0601.9-20	When UAS Datalink LS decoding systems understand the distance- <u>extended</u> representation of certain metadata items the decoder shall use the distance-extended representation.

ST 0601.9-21	When UAS Datalink LS decoding systems understand the distance- <u>extended</u> representation of certain metadata items the decoder shall ignore the distance- <u>restricted</u> representation when both exist in the same UAS Datalink LS packet.
--------------	---

## 6.4 UAS LS Universal Keys

Requirement	
ST 0601.8-18	The UAS Datalink Local Set 16-byte Universal Key shall be 06 0E 2B 34 - 02 0B 01 01 - 0E 01 03 01 - 01 00 00 00 (CRC 56773)

### *UAS Datalink LS Universal Key history*

**Date Released:** May 2006

**Description:** Defined in MISB ST 0807 [5]

A key history is provided below as a way to track the keys used in engineering and development. Note that the keys listed below are informative only.

<b>DO NOT use the below historical universal keys in any future development.</b>	
<b>Key:</b> 06 0E 2B 34 - 01 01 01 01 - 0F 00 00 00 - 00 00 00 00	
<b>Date Released:</b> November 2005	
<b>Description:</b> Experimental node key used in software development efforts at General Atomics prior to the assignment of a defined key.	
<b>Key:</b> 06 0E 2B 34 - 02 03 01 01 - 01 79 01 01 - 01 xx xx xx	
<b>Date Released:</b> October 25, 2005	
<b>Description:</b> This key was released as a placeholder within early versions this document. Much development has been based around draft versions of this document which has used this key in some software implementations.	

Requirement	
ST 0601.8-19	Historical 16-byte Universal Keys shall be forbidden in future developments.


### 6.4.1 SMPTE Universal Key Version Number

Depreciated in MISB ST 0601.6.

## 6.5 UAS LS Packet Structure

Figure 6-1 shows the general configuration of the UAS Datalink LS. A packet is a combination of a Key, the Length of the Value, and the Value. It is required that each UAS Datalink LS packet contain a Precision Time Stamp (defined in MISB ST 0603 [6]), which represents the time of birth of the metadata within the LS packet to conform with the requirements in Section 6.2. Timestamping is further discussed in Section 6.7. A checksum metadata item is also

required to be included in each LS packet, and needs to conform with the requirements in Section 6.2. Checksums are discussed in Section 6.8.



**Figure 6-1: Example of a UAS Datalink Local Set Packet**

Any combination of metadata items can be included in a UAS Datalink LS packet. Also, the items within the UAS Datalink LS can be arranged in any order. However, the timestamp is always positioned at the beginning of a LS packet, and the checksum always appears as the last metadata item, which aids algorithms surrounding its computation and creation (see requirements in Section 6.2).

### 6.5.1 Bit and Byte Ordering

All metadata is represented using big-endian (Most Significant Byte (MSB) first) encoding, and Bytes using big-endian bit encoding (most significant bit (msb) first) (see requirement in Section 6.1).


### 6.5.2 Tag and Length Field Encoding

The UAS Datalink LS item tag and length fields are encoded using basic encoding rules (BER) for either short or long form encoding of octets (see requirements in Section 6.1). This encoding method provides the greatest level of flexibility for variable length data contained within a KLV packet.

See SMPTE ST 336 for further details.

### 6.5.2.1 BER Short Form Length Encoding Example

For UAS Datalink LS packets and data elements shorter than 128 bytes, the length field is encoded using the BER short form. The Length field when using the short form is represented with a single byte (8 bits). The most significant bit in this byte signals whether short or long form is used. A zero (0) bit indicates short form encoding. The last seven bits indicate the number of bytes that follow the BER-encoded length. In short form encoding, the allowed length of the Value is 127 bytes. An example LS packet using a short form encoded length is shown in Figure 6-2:




**Figure 6-2: Example Short Form Length Encoding**

Although this example depicts the length field of the entire UAS Datalink LS packet, short form BER encoding also applies to the individual item lengths within the LS packet, which are coded using Tags.

### 6.5.2.2 BER Long Form Length Encoding

For UAS Datalink LS packets and data elements longer than 127 bytes, the length field is encoded using BER long form. The most significant bit in the first byte of the Length field signals long form when set to one (1). The long form encodes the length field using multiple bytes. The remaining 7 bits of the first byte indicate the number of subsequent bytes that represent the Length. The bytes that follow the leading byte are the encoding of an unsigned binary integer equal to the number of bytes in the packet. An example UAS Datalink LS packet using a long form encoded length is shown in Figure 6-3:



**Figure 6-3: Example Long Form Length Encoding**

Although this example shows long form BER encoding for the entire UAS Datalink LS packet, long form BER encoding also applies to the individual item lengths within the LS packet, which are coded using Tags (i.e. TLV items).

### 6.5.2.3 BER-OID Encoding for Tags

Also known as “primitive BER”, or “ASN.1 OID BER”, BER-OID encoding of tags differs from short and long form BER encoding used for KLV lengths as described in Sections 6.5.2.1 and 6.5.2.2.

KLV local sets employing the use of BER-OID encoded tags can represent an almost limitless number of metadata items. BER-OID binary encoding allows the size of a tag space to increase through the inclusion of additional bytes when the tag number passes a certain threshold.


For instance, one BER-OID byte (or octet) can represent up to 127 different metadata items. Two bytes can represent 16,383 items. Generalizing for any number of bytes “N” used as a BER-OID tag, the number of tags that can be represented is  $2^{7 \cdot N} - 1$ .

When using BER-OID encoding for tags, each tag is represented as a series of one or more bytes. Bit 8 (msb) of each byte indicates whether it is the last in the series: bit 8 of the last byte (LSB) is zero, while bit 8 of each preceding byte (MSB’s) is one. Bits 7 to 1 of the bytes in the series collectively encode the metadata tag.

Conceptually, these groups of bits are concatenated to form an unsigned binary number whose most significant bit is bit 7 of the first byte, and whose least significant bit is bit 1 of the last octet.


A BER-OID encoded tag must use the fewest bytes possible. Equivalently, the leading byte(s) of the BER-OID tag must not have the value of 0x80.

BER-OID encoding examples for one, two, and three-byte encodings are shown in Figure 6-4, Figure 6-5 and Figure 6-6 respectively.



**Figure 6-4: BER-OID Tag Encoding Using One Byte**


Note that only 127 different tags are encoded using a single byte. Decoding is the reverse of encoding. This is the only tag encoding currently encountered in the UAS Datalink LS.



**Figure 6-5: BER-OID Tag Encoding Using Two Bytes**



Note that logical tags 128 through 16,383 are encoded using two bytes. Decoding is the reverse of encoding.



**Figure 6-6: BER-OID Tag Encoding Using Three Bytes**

Note that logical tags 16,384 through 2,097,151 are encoded using three bytes. Decoding is the reverse of encoding.

Although not currently in use, BER-OID tags could grow to two bytes in future ST 0601 revisions.

### 6.5.3 Nesting Local Sets within the UAS Datalink LS

Nesting another Local Set within the UAS Datalink LS provides flexibility to system implementers. A nested Local Set is treated the same as any standalone metadata item defined within the UAS Datalink LS. A Tag for the nested Local Set is defined in this document, and the Length field is the size of the Value, which would include one or more tags-length-value triplets from the defining Local Set document. Figure 6-7 shows an example where a RVT LS (MISB ST 0806 [7]) is nested within the UAS Datalink LS.

### 6.5.4 Segment LS/Amend LS within the UAS Datalink LS

New use cases require changing, adding, and sharing of one or more Tags within a metadata set; in this case, two news tags are available in the ST 0601 Local Set. The Segment LS – Tag 100 enables defining a number of shared common metadata elements, while reusing a number of metadata elements in describing multiple unique image areas within an image (see for example, the Composite Imaging LS). The Amend LS – Tag 101 enables editing, adding, and deleting metadata, while preserving existing metadata (see for example, the Geo-Registration LS). The Motion Imagery Handbook [8] discusses the theory underlying these new Local Set constructs, while MISB ST 1607 [9] provides guidance for their use.




Figure 6-7: Nested Packet Example

## 6.6 Data Collection and Dissemination – Informative

Within the air vehicle, metadata is collected, processed, and then distributed by the flight computer (or equivalent) through the most appropriate interface (Serial Digital Interface, GigeVision, etc.). See Figure 6-8.




Figure 6-8: Example System Architecture

Sensors and other metadata sources pass metadata to the flight computer. The flight computer (or equivalent) places a timestamp in the UAS Datalink LS packet prior to passing it to the Motion

Imagery Encoder / Packet Multiplexer. See Section 6.7 for more information about using timestamps in the LS packet.

Typically, the flight computer merges all appropriate metadata items into a LS packet and forwards the data to a Motion Imagery encoder/packet multiplexer, which produces a unified data stream for off-platform transmission. Once passed through the communications link, a receiving client decodes and processes the Motion Imagery and metadata.

## 6.7 Timestamping

Every UAS Datalink LS packet is required to include a Precision Time Stamp as defined in MISB ST 0603 [6], which relates the metadata to a known time reference. The Precision Time Stamp (Tag 2) is an eight-byte unsigned integer representing the number of SI Seconds (in microseconds) which have elapsed since midnight (00:00:00), January 1, 1970 (1970-01-01T00:00:00Z). This section describes how to include the mandatory timestamp within a UAS Datalink LS packet according to the requirements in Section 6.2

Metadata sources and the flight computer (or equivalent) are coordinated to operate on the same time reference, which is typically GPS derived. The metadata source provides a timestamp for inclusion in a UAS Datalink LS packet as well as the Motion Imagery for assisting in synchronizing each Motion Imagery frame to its corresponding metadata.

When receiving packets of ST 0601 metadata, the timestamp represents the time of birth of all metadata items contained within the UAS Datalink LS packet in accordance with the requirements in Section 6.2. When generating UAS Datalink LS packets, the most current metadata samples since the last metadata packet (with timestamp) are intended to be used and assigned the current time.

Generation of metadata packets introduces a situation where the time of birth timestamp may not directly correspond to when a metadata value was actually sampled. In this case, the maximum timestamp error encountered is the difference in time between the current metadata packet, and the packet which immediately precedes it.

Systems producing or accepting ST 0601 metadata streams are allowed to adjust metadata repetition rates to meet timestamp precision needs.

### 6.7.1 Packet Timestamp

A UAS Datalink LS packet timestamp is inserted at the beginning of the value portion of a UAS Datalink LS packet.

The timestamp, represented by Tag 2 (Precision Time Stamp), applies to all metadata in the UAS Datalink LS packet, and corresponds to the time of birth of all the data within the packet. This timestamp can be used to associate the metadata with a particular Motion Imagery frame and be displayed or monitored appropriately.

An example packet containing a timestamp is shown in Figure 6-9:




Figure 6-9: Packet Timestamp Example

## 6.8 Error Detection

To help prevent erroneous metadata from being presented with the Motion Imagery, it is required that a 16-bit checksum is included in every UAS Datalink LS packet as the last item (see requirements in Section 6.2). The checksum is a running 16-bit sum through the entire packet starting with the 16-byte Local Set key and ending with summing the length field of the checksum data item.

Figure 6-10 shows the data range that the checksum is performed over:




Figure 6-10: Checksum Computation Range

An example algorithm for calculating the checksum is shown below:

---

```

unsigned short bcc_16 (
    unsigned char * buff, // Pointer to the first byte in the 16-byte UAS LS key.
    unsigned short len ) // Length from 16-byte US key up to 1-byte checksum length.
{
    // Initialize Checksum and counter variables.
    unsigned short bcc = 0, i;

    // Sum each 16-bit chunk within the buffer into a checksum
    for ( i = 0 ; i < len; i++)
        bcc += buff[i] << (8 * ((i + 1) % 2));
    return bcc;
} // end of bcc_16 ()

```

---

If the calculated checksum of the received packet does not match the checksum stored in the packet, the user must discard this packet as being invalid (see requirements in Section 6.1). The lost packet is of little concern, since another packet is available within reasonable proximity (in both data and time) to this lost packet.

## 6.9 Motion Imagery/Metadata Synchronization

The accuracy of synchronization or time-alignment of a Motion Imagery frame with metadata is the responsibility of the system designer. The Precision Time Stamp is specified in MISB ST

0603. Requirements for timestamping compressed Class 1/Class 2 Motion Imagery with a Precision Time Stamp are outlined in MISB ST 0604 [9]. Methods and requirements for synchronizing Class 1/Class 2 Motion Imagery and metadata within a MPEG-2 Transport Stream are described in MISB ST 1402 [10]. Requirements for timestamping and metadata carriage in uncompressed Class 0 Motion Imagery are outlined in MISB ST 0605 [11].

Numerous considerations need to be weighed in synchronizing a Motion Imagery frame with metadata. These include: sufficient bandwidth to accommodate the metadata without limiting the Motion Imagery; required update rates of metadata; presentation of synchronized Motion Imagery with metadata at a client receiver; and receiver decoder buffer (delay). Different applications will have differing requirements for synchronization, and whether sufficient information is available to guarantee a desired relationship between the Motion Imagery and the metadata. Metrics for the timing of Motion Imagery and metadata are application specific; in general, it is best to ensure that the Precision Time Stamp inserted into a Motion Imagery frame and into metadata is as close to the point of collection as possible for both.

## 7 UAS Datalink Local Set

This section defines the content of the UAS Datalink LS as well as translation between LS & ESD, and LS and US data types.

For guidance on which items are mandatory to include in ST 0601 packets, refer to MISB ST 0902 [12] for a listing of the minimum set of UAS Datalink LS metadata items.

### 7.1 UAS Datalink Local Set Items

Each UAS Datalink LS item is assigned an integer value for its tag, a descriptive name, and also fields indicating the units, range, format, and length of the data item. More detailed information about the data item is included in the Notes column.

- The columns labeled “Mapped US”, “Units”, “Format”, “Len” (for length), “FLP” (for Floating Length Pack), and “Notes” all apply to the Local Set ONLY and not ESD or US data types.
- “ESD Name” is the name assigned to an ESD metadata item labeled as a two-character digraph in the “ESD” column.
- An “x” within a field below indicates that no data is available.
- The “Mapped US” column is the Universal Set metadata key reserved to represent the length and data format specified by the referring LS metadata item. The key is the only parameter which differs between US and tag of the LS item. Note that LS items which state “Use EG 0104 US Key” may require conversion between LS and US data types prior to representing an LS item as a US item.
- The “US” column is an existing metadata key, which the UAS Datalink LS is mapped to in some applications (i.e.: MISB EG 0104). Note that the LS and EG 0104 data formats often differ between one another, and a US key could not be used to represent the data in an LS item without proper conversion first.

## ST 0601.10 UAS Datalink Local Set

- The “FLP” column indicates those LS items which may be used within the Standard Deviation Correlation Coefficient Floating Length Pack (SDCC-FLP) structure. A “Y” denotes “Yes” this element can be used, while a “N” denotes “No” it may not be used. The SDCC-FLP construct is defined in MISB ST 1010 [13].
- Functional use of IMAPB is found in MISB ST 1201 [14].

**Table 1: UAS Datalink Local Set**

TAG	LS Name	Mapped US	ESD	ESD Name	US	US Name	Units	Format	Len	SDCC FLP	LS Notes
1	Checksum	06 0E 2B 34 01 01 01 01 0E 01 02 03 01 00 00 00 (CRC 56132)	x	x	x	x	None	uint16	2	N	Checksum used to detect errors within a UAS Datalink LS packet. Lower 16-bits of summation. Performed on entire LS packet, including 16-byte US key and 1-byte checksum length.
2	Precision Time Stamp	Use EG 0104 US Key	x	x	06 0E 2B 34 01 01 01 03 07 02 01 01 01 05 00 00 (CRC 64827)	User Defined Time Stamp – Microseconds since 1970	Micro- seconds	uint64	8	N	Represented in the number of microseconds elapsed since midnight (00:00:00), January 1, 1970 not including leap seconds. See MISB ST 0603. Resolution: 1 microsecond.
3	Mission ID	06 0E 2B 34 01 01 01 01 0E 01 04 01 03 00 00 00 (CRC 65358)	Mn	Mission Number	06 0E 2B 34 01 01 01 01 01 05 05 00 00 00 00 00 (CRC 37735)	Episode Number	String	ISO 646	V	N	Descriptive Mission Identifier to distinguish event or sortie. Value field is Free Text. Maximum 127 characters.
4	Platform Tail Number	06 0E 2B 34 01 01 01 01 0E 01 04 01 02 00 00 00 (CRC 35322)	Pt	Platform Tail Number	x	x	String	ISO 646	V	N	Identifier of platform as posted. E.g.: "AF008", "BP101", etc. Value field is Free Text. Maximum 127 characters.
5	Platform Heading Angle	Use EG0104 US Key	Ih	UAV Heading (INS)	06 0E 2B 34 01 01 01 07 07 01 10 01 06 00 00 00 (CRC 23727)	Platform Heading Angle	Degrees	uint16	2	Y	Aircraft heading angle. Relative between longitudinal axis and True North measured in the horizontal plane. Map 0..(2 <sup>16</sup> -1) to 0..360. Resolution: ~5.5 milli degrees.
6	Platform Pitch Angle	Use EG 0104 US Key	Ip	UAV Pitch (INS)	06 0E 2B 34 01 01 01 07 07 01 10 01 05 00 00 00 (CRC 51059)	Platform Pitch Angle	Degrees	int16	2	Y	Aircraft pitch angle. Angle between longitudinal axis and horizontal plane. Positive angles above horizontal plane. Map -(2 <sup>15</sup> -1)..(2 <sup>15</sup> -1) to +/-20. Use -(2 <sup>15</sup> ) as "out of range" indicator. -(2 <sup>15</sup> ) = 0x8000. Resolution: ~610 micro degrees.
7	Platform Roll Angle	Use EG 0104 US Key	Ir	UAV Roll (INS)	06 0E 2B 34 01 01 01 07 07 01 10 01 04 00 00 00 (CRC 45511)	Platform Roll Angle	Degrees	int16	2	Y	Platform roll angle. Angle between transverse axis and transvers-longitudinal plane. Positive angles for lowered right wing. Map -(2 <sup>15</sup> -1)..(2 <sup>15</sup> -1) to +/-50. Use -(2 <sup>15</sup> ) as "out of range" indicator.

## ST 0601.10 UAS Datalink Local Set

TAG	LS Name	Mapped US	ESD	ESD Name	US	US Name	Units	Format	Len	SDCC FLP	LS Notes
											$-(2^{15}) = 0 \times 8000$ . Res: $\sim 1525$ micro deg.
8	Platform True Airspeed	06 0E 2B 34 01 01 01 01 0E 01 01 01 0A 00 00 00 (CRC 20280)	As	True Airspeed	x	x	Meters /Second	uint8	1	Y	True airspeed (TAS) of platform. Indicated Airspeed adjusted for temperature and altitude. 0..255 meters/sec. 1 m/s = 1.94384449 knots. Resolution: 1 meter/second.
9	Platform Indicated Airspeed	06 0E 2B 34 01 01 01 01 0E 01 01 01 0B 00 00 00 (CRC 14732)	Ai	Indicated Airspeed	x	x	Meters /Second	uint8	1	Y	Indicated airspeed (IAS) of platform. Derived from Pitot tube and static pressure sensors. 0..255 meters/sec. 1 m/s = 1.94384449 knots. Resolution: 1 meter/second.
10	Platform Designation	Use EG 0104 US Key	Pc	Project ID Code	06 0E 2B 34 01 01 01 01 01 01 20 01 00 00 00 00 (CRC 36601)	Device Designation	String	ISO 646	V	N	Use Platform Designation String e.g.: 'Predator', 'Reaper', 'Outrider', 'Pioneer', 'IgnatER', 'Warrior', 'Shadow', 'Hunter II', 'Global Hawk', 'Scan Eagle', etc. Value field is Free Text. Maximum 127 characters.
11	Image Source Sensor	Use EG0104 US Key	Sn	Sensor Name	06 0E 2B 34 01 01 01 01 04 20 01 02 01 01 00 00 (CRC 53038)	Image Source Device	String	ISO 646	V	N	String of image source sensor. E.g.: 'EO Nose', 'EO Zoom (DLTV)', 'EO Spotter', 'IR Mitsubishi PtSi Model 500', 'IR InSb Amber Model TBT', 'LYNX SAR Imagery', 'TESAR Imagery', etc. Value field is Free Text. Maximum 127 characters.
12	Image Coordinate System	Use EG 0104 US Key	Ic	Image Coordinate System	06 0E 2B 34 01 01 01 01 07 01 01 01 00 00 00 00 (CRC 32410)	Image Coordinate System	String	ISO 646	V	N	String of the image coordinate system used. E.g.: 'Geodetic WGS84', 'Geocentric WGS84', 'UTM', 'None', etc.
13	Sensor Latitude	Use EG 0104 US Key	Sa	Sensor Latitude	06 0E 2B 34 01 01 01 03 07 01 02 01 02 04 02 00 (CRC 8663)	Device Latitude	Degrees	int32	4	Y	Sensor Latitude. Based on WGS84 ellipsoid. Map $-(2^{31}-1) \dots (2^{31}-1)$ to $\pm 90$ . Use $-(2^{31})$ as an "error" indicator. $-(2^{31}) = 0 \times 80000000$ . Resolution: $\sim 42$ nano degrees.
14	Sensor Longitude	Use EG 0104 US Key	So	Sensor Longitude	06 0E 2B 34 01 01 01 03 07 01 02 01 02 06 02 00 (CRC 20407)	Device Longitude	Degrees	int32	4	Y	Sensor Longitude. Based on WGS84 ellipsoid. Map $-(2^{31}-1) \dots (2^{31}-1)$ to $\pm 180$ . Use $-(2^{31})$ as an "error" indicator. $-(2^{31}) = 0 \times 80000000$ . Resolution: $\sim 84$ nano degrees.
15	Sensor True Altitude	Use EG 0104 US Key	SI	Sensor Altitude	06 0E 2B 34 01 01 01 01 07 01 02 01 02 02 00 00 (CRC 13170)	Device Altitude	Meters	uint16	2	Y	Altitude of sensor as measured from Mean Sea Level (MSL). Map $0 \dots (2^{16}-1)$ to $-900 \dots 19000$ meters. 1 meter = 3.2808399 feet. Resolution: $\sim 0.3$ meters.
16	Sensor Horizontal field of View	Use EG 0104 US Key	Fv	Field of View	06 0E 2B 34 01 01 01 02 04 20 02 01 01 08 00 00	Field of View (FOV-Horizontal)	Degrees	uint16	2	Y	Horizontal field of view of selected imaging sensor. Map $0 \dots (2^{16}-1)$ to $0 \dots 180$ . Resolution: $\sim 2.7$ milli degrees.

## ST 0601.10 UAS Datalink Local Set

TAG	LS Name	Mapped US	ESD	ESD Name	US	US Name	Units	Format	Len	SDCC FLP	LS Notes
					(CRC 23753)						
17	Sensor Vertical Field of View	06 0E 2B 34 01 01 01 07 04 20 02 01 01 0A 01 00 (CRC 30292)	Vv	Vertical Field of View	x	x	Degrees	uint16	2	Y	Vertical field of view of selected imaging sensor. Map 0..(2 <sup>16</sup> -1) to 0..180. Resolution: ~2.7 milli degrees. Requires data conversion between LS value and SMPTE Mapped US Key.
18	Sensor Relative Azimuth Angle	06 0E 2B 34 01 01 01 01 0E 01 01 02 04 00 00 00 (CRC 944)	Az	Sensor Relative Azimuth Angle	x	x	Degrees	uint32	4	Y	Relative rotation angle of sensor to platform longitudinal axis. Rotation angle between platform longitudinal axis and camera pointing direction as seen from above the platform. Map 0..(2 <sup>32</sup> -1) to 0..360. Resolution: ~84 nano degrees.
19	Sensor Relative Elevation Angle	06 0E 2B 34 01 01 01 01 0E 01 01 02 05 00 00 00 (CRC 29956)	De	Sensor Relative Elevation Angle	x	x	Degrees	int32	4	Y	Relative Elevation Angle of sensor to platform longitudinal-transverse plane. Negative angles down. Map -(2 <sup>31</sup> -1)..(2 <sup>31</sup> -1) to +/- 180. Use -(2 <sup>31</sup> ) as an "error" indicator. -(2 <sup>31</sup> ) = 0x80000000. Res: ~84 ndeg.
20	Sensor Relative Roll Angle	06 0E 2B 34 01 01 01 01 0E 01 01 02 06 00 00 00 (CRC 61144)	Ro	Sensor Relative Roll Angle	x	x	Degrees	uint32	4	Y	Relative roll angle of sensor to aircraft platform. Twisting angle of camera about lens axis. Top of image is zero degrees. Positive angles are clockwise when looking from behind camera. Map 0..(2 <sup>32</sup> -1) to 0..360. Resolution: ~84 nano degrees.
21	Slant Range	Use EG 0104 US Key	Sr	Slant Range	06 0E 2B 34 01 01 01 01 07 01 08 01 01 00 00 00 (CRC 16588)	Slant Range	Meters	uint32	4	Y	Slant range in meters. Distance to target. Map 0..(2 <sup>32</sup> -1) to 0..5000000 meters. 1 nautical mile (knot) = 1852 meters. Resolution: ~1.2 milli meters.
22	Target Width	Use EG 0104 US Key	Tw	Target Width	06 0E 2B 34 01 01 01 01 07 01 09 02 01 00 00 00 (CRC 60350)	Target Width	Meters	uint16	2	Y	Target Width within sensor field of view. Map 0..(2 <sup>16</sup> -1) to 0..10000 meters. 1 meter = 3.2808399 feet. Resolution: ~.16 meters.
23	Frame Center Latitude	Use EG 0104 US Key	Ta	Target Latitude	06 0E 2B 34 01 01 01 01 07 01 02 01 03 02 00 00 (CRC 17862)	Frame Center Latitude	Degrees	int32	4	N	Terrain Latitude of frame center. Based on WGS84 ellipsoid. Map -(2 <sup>31</sup> -1)..(2 <sup>31</sup> -1) to +/-90. Use -(2 <sup>31</sup> ) as an "error" indicator. -(2 <sup>31</sup> ) = 0x80000000. Resolution: ~42 nano degrees.
24	Frame Center Longitude	Use EG 0104 US Key	To	Target Longitude	06 0E 2B 34 01 01 01 01 07 01 02 01 03 04 00 00 (CRC 63334)	Frame Center Longitude	Degrees	int32	4	N	Terrain Longitude of frame center. Based on WGS84 ellipsoid. Map -(2 <sup>31</sup> -1)..(2 <sup>31</sup> -1) to +/- 180. Use -(2 <sup>31</sup> ) as an "error" indicator. -(2 <sup>31</sup> ) = 0x80000000. Resolution: ~84 nano degrees.



## ST 0601.10 UAS Datalink Local Set

TAG	LS Name	Mapped US	ESD	ESD Name	US	US Name	Units	Format	Len	SDCC FLP	LS Notes
25	Frame Center Elevation	06 0E 2B 34 01 01 01 0A 07 01 02 01 03 16 00 00 (CRC 57054)	Te	Frame Center Elevation	x	x	Meters	uint16	2	N	Terrain elevation at frame center relative to Mean Sea Level (MSL). Map 0..(2 <sup>16</sup> -1) to -900..19000 meters. Resolution: ~0.3 meters.
26	Offset Corner Latitude Point 1	Use EG 0104 US Key	Rg	SAR Latitude 4	06 0E 2B 34 01 01 01 03 07 01 02 01 03 07 01 00 (CRC 23392)	Corner Latitude Point 1 (Decimal Degrees)	Degrees	int16	2	N	Frame Latitude, offset for upper left corner. Based on WGS84 ellipsoid. Use with Frame Center Latitude. Map -(2 <sup>15</sup> -1)..(2 <sup>15</sup> -1) to +/- 0.075. Use -(2 <sup>15</sup> ) as an "error" indicator. -(2 <sup>15</sup> ) = 0x8000. Resolution: ~1.2micro deg, ~0.25meters at equator.
27	Offset Corner Longitude Point 1	Use EG 0104 US Key	Rh	SAR Longitude 4	06 0E 2B 34 01 01 01 03 07 01 02 01 03 0B 01 00 (CRC 11777)	Corner Longitude Point 1 (Decimal Degrees)	Degrees	int16	2	N	Frame Longitude, offset for upper left corner. Based on WGS84 ellipsoid. Use with Frame Center Longitude. Map -(2 <sup>15</sup> -1)..(2 <sup>15</sup> -1) to +/- 0.075. Use -(2 <sup>15</sup> ) as an "error" indicator. -(2 <sup>15</sup> ) = 0x8000. Resolution: ~1.2micro deg, ~0.25meters at equator.
28	Offset Corner Latitude Point 2	Use EG 0104 US Key	Ra	SAR Latitude 1	06 0E 2B 34 01 01 01 03 07 01 02 01 03 08 01 00 (CRC 30545)	Corner Latitude Point 2 (Decimal Degrees)	Degrees	int16	2	N	Frame Latitude, offset for upper right corner. Based on WGS84 ellipsoid. Use with Frame Center Latitude. Map -(2 <sup>15</sup> -1)..(2 <sup>15</sup> -1) to +/- 0.075. Use -(2 <sup>15</sup> ) as an "error" indicator. -(2 <sup>15</sup> ) = 0x8000. Resolution: ~1.2micro deg, ~0.25meters at equator.
29	Offset Corner Longitude Point 2	Use EG 0104 US Key	Rb	SAR Longitude 1	06 0E 2B 34 01 01 01 03 07 01 02 01 03 0C 01 00 (CRC 43921)	Corner Longitude Point 2 (Decimal Degrees)	Degrees	int16	2	N	Frame Longitude, offset for upper right corner. Based on WGS84 ellipsoid. Use with Frame Center Longitude. Map -(2 <sup>15</sup> -1)..(2 <sup>15</sup> -1) to +/- 0.075. Use -(2 <sup>15</sup> ) as an "error" indicator. -(2 <sup>15</sup> ) = 0x8000. Resolution: ~1.2micro deg, ~0.25meters at equator.
30	Offset Corner Latitude Point 3	Use EG 0104 US Key	Rc	SAR Latitude 2	06 0E 2B 34 01 01 01 03 07 01 02 01 03 09 01 00 (CRC 16481)	Corner Latitude Point 3 (Decimal Degrees)	Degrees	int16	2	N	Frame Latitude, offset for lower right corner. Based on WGS84 ellipsoid. Use with Frame Center Latitude. Map -(2 <sup>15</sup> -1)..(2 <sup>15</sup> -1) to +/- 0.075. Use -(2 <sup>15</sup> ) as an "error" indicator. -(2 <sup>15</sup> ) = 0x8000. Resolution: ~1.2micro deg, ~0.25meters at equator.
31	Offset Corner Longitude Point 3	Use EG0104 US Key	Rd	SAR Longitude 2	06 0E 2B 34 01 01 01 03	Corner Longitude Point 3	Degrees	int16	2	N	Frame Longitude, offset for lower right corner. Based on WGS84 ellipsoid.

## ST 0601.10 UAS Datalink Local Set

TAG	LS Name	Mapped US	ESD	ESD Name	US	US Name	Units	Format	Len	SDCC FLP	LS Notes
					07 01 02 01 03 0D 01 00 (CRC 40097)	(Decimal Degrees)					Use with Frame Center Longitude. Map $-(2^{15}-1)..(2^{15}-1)$ to $\pm 0.075$ . Use $-(2^{15})$ as an "error" indicator. $-(2^{15}) = 0x8000$ . Resolution: $\sim 1.2$ micro deg, $\sim 0.25$ meters at equator.
32	Offset Corner Latitude Point 4	Use EG0104 US Key	Re	SAR Latitude 3	06 0E 2B 34 01 01 01 03 07 01 02 01 03 0A 01 00 (CRC 6449)	Corner Latitude Point 4 (Decimal Degrees)	Degrees	int16	2	N	Frame Latitude, offset for lower left corner. Based on WGS84 ellipsoid. Use with Frame Center Latitude. Map $-(2^{15}-1)..(2^{15}-1)$ to $\pm 0.075$ . Use $-(2^{15})$ as an "error" indicator. $-(2^{15}) = 0x8000$ . Resolution: $\sim 1.2$ micro deg, $\sim 0.25$ meters at equator.
33	Offset Corner Longitude Point 4	Use EG0104 US Key	Rf	SAR Longitude 3	06 0E 2B 34 01 01 01 03 07 01 02 01 03 0E 01 00 (CRC 50673)	Corner Longitude Point 4 (Decimal Degrees)	Degrees	int16	2	N	Frame Longitude, offset for lower left corner. Based on WGS84 ellipsoid. Use with Frame Center Longitude. Map $-(2^{15}-1)..(2^{15}-1)$ to $\pm 0.075$ . Use $-(2^{15})$ as an "error" indicator. $-(2^{15}) = 0x8000$ . Resolution: $\sim 1.2$ micro deg, $\sim 0.25$ meters at equator.
34	Icing Detected	06 0E 2B 34 01 01 01 01 0E 01 01 01 0C 00 00 00 (CRC 26785)	Id	Icing Detected	x	x	Icing Code	uint8	1	N	Flag for icing detected at aircraft location. 0: Detector off 1: No icing Detected 2: Icing Detected
35	Wind Direction	06 0E 2B 34 01 01 01 01 0E 01 01 01 0D 00 00 00 (CRC 7701)	Wd	Wind Direction	x	x	Degrees	uint16	2	N	Wind direction at aircraft location. This is the direction the wind is coming from relative to true north. Map $0..(2^{16}-1)$ to $0..360$ . Resolution: $\sim 5.5$ milli degrees.
36	Wind Speed	06 0E 2B 34 01 01 01 01 0E 01 01 01 0E 00 00 00 (CRC 34249)	Ws	Wind Speed	x	x	Meters /Second	uint8	1	N	Wind speed at aircraft location. Map $0..255$ to $0..100$ meters/second. $1 \text{ m/s} = 1.94384449 \text{ knots}$ . Resolution: $\sim 0.4$ meters/second.
37	Static Pressure	06 0E 2B 34 01 01 01 01 0E 01 01 01 0F 00 00 00 (CRC 62333)	Ps	Static Pressure	x	x	Millibar	uint16	2	N	Static pressure at aircraft location. Map $0..(2^{16}-1)$ to $0..5000$ mbar. $1 \text{ mbar} = 0.0145037738 \text{ PSI}$ . Resolution: $\sim 0.08$ Millibar
38	Density Altitude	06 0E 2B 34 01 01 01 01 0E 01 01 01 10 00 00 00 (CRC 15412)	Da	Density Altitude	x	x	Meters	uint16	2	N	Density altitude at aircraft location. Relative aircraft performance metric based on outside air temperature, static pressure, and humidity. Map $0..(2^{16}-1)$ to $-900..19000$ meters. Offset = $-900$ . $1 \text{ meter} = 3.2808399 \text{ feet}$ . Resolution: $\sim 0.3$ meters.
39	Outside Air Temperature	06 0E 2B 34 01 01 01 01	At	Air Temperature	x	x	Celsius	int8	1	N	Temperature outside of aircraft. $-128..127$ Degrees Celsius.

## ST 0601.10 UAS Datalink Local Set

TAG	LS Name	Mapped US	ESD	ESD Name	US	US Name	Units	Format	Len	SDCC FLP	LS Notes
		0E 01 01 01 11 00 00 00 (CRC 19072)									Resolution: 1 degree celsius.
40	Target Location Latitude	06 0E 2B 34 01 01 01 01 0E 01 01 03 02 00 00 00 (CRC 36472)	x	x	x	x	Degrees	int32	4	N	Calculated Target latitude. This is the crosshair location if different from frame center. Based on WGS84 ellipsoid. Map $-(2^{31}-1)..(2^{31}-1)$ to $\pm 90$ . Use $-(2^{31})$ as an "error" indicator. $-(2^{31}) = 0x80000000$ . Resolution: ~42 nano degrees.
41	Target Location Longitude	06 0E 2B 34 01 01 01 01 0E 01 01 03 03 00 00 00 (CRC 63692)	x	x	x	x	Degrees	int32	4	N	Calculated Target longitude. This is the crosshair location if different from frame center. Based on WGS84 ellipsoid. Map $-(2^{31}-1)..(2^{31}-1)$ to $\pm 180$ . Use $-(2^{31})$ as an "error" indicator. $-(2^{31}) = 0x80000000$ . Resolution: ~84 nano degrees.
42	Target Location Elevation	06 0E 2B 34 01 01 01 01 0E 01 01 03 04 00 00 00 (CRC 43489)	x	x	x	x	Meters	uint16	2	N	Calculated target elevation. This is the crosshair location if different from frame center. Map $0..(2^{16}-1)$ to $-900..19000$ meters. Offset = $-900$ . 1 meter = 3.2808399 feet. Resolution: ~0.3 meters.
43	Target Track Gate Width	06 0E 2B 34 01 01 01 01 0E 01 01 03 05 00 00 00 (CRC 57173)	x	x	x	x	Pixels	uint8	1	N	Tracking gate width (x value) of tracked target within field of view. Closely tied to source video resolution in pixels.
44	Target Track Gate Height	06 0E 2B 34 01 01 01 01 0E 01 01 03 06 00 00 00 (CRC 17545)	x	x	x	x	Pixels	uint8	1	N	Tracking gate height (y value) of tracked target within field of view. Closely tied to source video resolution in pixels.
45	Target Error Estimate – CE90	06 0E 2B 34 01 01 01 01 0E 01 01 03 07 00 00 00 (CRC 12861)	x	x	x	x	Meters	uint16	2	N	Circular Error 90 (CE90) is the estimated error distance in the horizontal direction. Specifies the radius of 90% probability on a plane tangent to the earth's surface. Res: ~0.0624 meters
46	Target Error Estimate – LE90	06 0E 2B 34 01 01 01 01 0E 01 01 03 08 00 00 00 (CRC 59091)	x	x	x	x	Meters	uint16	2	N	Lateral Error 90 (LE90) is the estimated error distance in the vertical (or lateral) direction. Specifies the interval of 90% probability in the local vertical direction. Res: 0.0625 meters
47	Generic Flag Data 01	06 0E 2B 34 01 01 01 01 0E 01 01 03 01 00 00 00 (CRC 5540)	x	x	x	x	None	uint8	1	N	Generic Flagged Metadata Position Format msb8..l1sb 1– Laser Range 1on,0off 2– Auto–Track 1on,0off 3– IR Polarity 1blk,0wht

## ST 0601.10 UAS Datalink Local Set

TAG	LS Name	Mapped US	ESD	ESD Name	US	US Name	Units	Format	Len	SDCC FLP	LS Notes
											4- Icing detected 1ice,0(off/no ice) 5- Slant Range 1measured, 0calc 6- Image Invalid 1invalid, 0valid 7,8- Use 0
48	Security Local Set	Use ST0102 US key for Local Sets.	x	x	06 0E 2B 34 02 03 01 01 0E 01 03 03 02 00 00 00 (CRC 40980)	Security Local Set	None	Set	x	N	Local set tag to include the ST0102 Local Set Security Metadata items within ST0601. Use the ST0102 Local Set Tags within the ST0601 tag 0d48. The length field is the size of all ST0102 metadata items to be packaged within tag 0d48.
49	Differential Pressure	06 0E 2B 34 01 01 01 01 0E 01 01 01 01 00 00 00 (CRC 20775)	x	x	x	x	Millibar	uint16	2	N	Differential pressure at aircraft location. Measured as the Stagnation/impact/total pressure minus static pressure. Map 0..(2 <sup>16</sup> -1) to 0..5000 mbar. 1 mbar = 0.0145037738 PSI. Res: ~0.08 mbar
50	Platform Angle of Attack	06 0E 2B 34 01 01 01 01 0E 01 01 01 02 00 00 00 (CRC 51963)	x	x	x	x	Degrees	int16	2	Y	Platform Attack Angle. Angle between platform longitudinal axis and relative wind. Positive angles for upward relative wind. Map -(2 <sup>15</sup> -1)..(2 <sup>15</sup> -1) to +/-20. Use -(2 <sup>15</sup> ) as an "out of range" indicator. -(2 <sup>15</sup> ) = 0x8000. Res: ~610 micro degrees.
51	Platform Vertical Speed	06 0E 2B 34 01 01 01 01 0E 01 01 01 03 00 00 00 (CRC 48207)	x	x	x	x	Meters /Second	int16	2	Y	Vertical speed of the aircraft relative to zenith. Positive ascending, negative descending. Map-(2 <sup>15</sup> -1)..(2 <sup>15</sup> -1) to +/-180 Use -(2 <sup>15</sup> ) as an "out of range" indicator. -(2 <sup>15</sup> ) = 0x8000. Resolution: ~ 0.0055 meters/second.
52	Platform Sideslip Angle	06 0E 2B 34 01 01 01 01 0E 01 01 01 04 00 00 00 (CRC 60770)	x	x	x	x	Degrees	int16	2	Y	The sideslip angle is the angle between the platform longitudinal axis and relative wind. Positive angles to right wing, neg to left. Map -(2 <sup>15</sup> -1)..(2 <sup>15</sup> -1) to +/-20. Use -(2 <sup>15</sup> ) as an "out of range" indicator. -(2 <sup>15</sup> ) = 0x8000. Res: ~610 micro deg.
53	Airfield Barometric Pressure	06 0E 2B 34 01 01 01 01 0E 01 01 02 02 00 00 00 (CRC 9257)	x	x	x	x	Millibar	uint16	2	N	Local pressure at airfield of known height. Pilot's responsibility to update. Map 0..(2 <sup>16</sup> -1) to 0..5000 mbar. 1013.25mbar = 29.92inHg Min/max recorded values of 870/1086mbar. Resolution: ~0.08 Millibar

## ST 0601.10 UAS Datalink Local Set

TAG	LS Name	Mapped US	ESD	ESD Name	US	US Name	Units	Format	Len	SDCC FLP	LS Notes
54	Airfield Elevation	06 0E 2B 34 01 01 01 01 0E 01 01 02 03 00 00 00 (CRC 21149)	x	x	x	x	Meters	uint16	2	N	Elevation of Airfield corresponding to Airfield Barometric Pressure. Map 0..(2 <sup>16</sup> -1) to -900..19000 meters. Offset = -900. 1 meter = 3.2808399 feet. Resolution: ~0.3 meters.
55	Relative Humidity	06 0E 2B 34 01 01 01 01 0E 01 01 01 09 00 00 00 (CRC 54500)	x	x	x	x	Percent	uint8	1	N	Relative Humidity at aircraft location. Map 0..(2 <sup>8</sup> -1) to 0..100. Resolution: ~0.4%.
56	Platform Ground Speed	06 0E 2B 34 01 01 01 01 0E 01 01 01 05 00 00 00 (CRC 39894)	Gv	Platform Ground Speed	x	x	Meters /Second	uint8	1	N	Speed projected to the ground of an airborne platform passing overhead. 0..255 meters/sec. 1 m/s = 1.94384449 knots. Resolution: 1 meter/second.
57	Ground Range	06 0E 2B 34 01 01 01 01 0E 01 01 01 06 00 00 00 (CRC 10)	Gr	Ground Range	x	x	Meters	uint32	4	N	Horizontal distance from ground position of aircraft relative to nadir, and target of interest. Dependent upon Slant Range and Depression Angle. Map 0..(2 <sup>32</sup> -1) to 0..5000000 meters. 1 nautical mile (knot) = 1852 meters. Resolution: ~1.2 milli meters.
58	Platform Fuel Remaining	06 0E 2B 34 01 01 01 01 0E 01 01 01 07 00 00 00 (CRC 30398)	Fr	Platform Fuel Remaining	x	x	Kilogram	uint16	2	N	Remaining fuel on airborne platform. Metered as fuel weight remaining. Map 0..(2 <sup>16</sup> -1) to 0..10000 Kilograms. 1 kilogram = 2.20462262 pounds. Resolution: ~.16 kilograms.
59	Platform Call Sign	06 0E 2B 34 01 01 01 01 0E 01 04 01 01 00 00 00 (CRC 4646)	Cs	Platform Call Sign	x	x	String	ISO 646	V	N	Call Sign of platform or operating unit. Value field is Free Text.
60	Weapon Load	06 0E 2B 34 01 01 01 01 0E 01 01 01 12 00 00 00 (CRC 53596)	Wl	Weapon Load	x	x	uint16	nibble	2	N	Current weapons stored on aircraft broken into two bytes: [K][L][V] = [0x41][0x02][[byte1][byte2]] [byteN] = [[nib1][nib2]], nib1 = msn byte1-nib1 = Station Number byte1-nib2 = Substation Number byte2-nib1 = Weapon Type byte2-nib2 = Weapon Variant
61	Weapon Fired	06 0E 2B 34 01 01 01 01 0E 01 01 01 13 00 00 00 (CRC 42984)	Wf	Weapon Fired	x	x	uint8	nibble	1	N	Indication when a particular weapon is released. Correlate with Precision Time Stamp. Identical format to Weapon Load byte 2: [byteN] = [[nib1][nib2]] nib1 = Station Number nib2 = Substation Number

## ST 0601.10 UAS Datalink Local Set

TAG	LS Name	Mapped US	ESD	ESD Name	US	US Name	Units	Format	Len	SDCC FLP	LS Notes
62	Laser PRF Code	06 0E 2B 34 01 01 01 01 0E 01 02 02 01 00 00 00 (CRC 28949)	Lc	Laser PRF Code	x	x	None	uint16	2	N	A laser's Pulse Repetition Frequency (PRF) code used to mark a target. The Laser PRF code is a three or four digit number consisting of the values 1..8. Only the values 1111..8888 can be used without 0's or 9's.
63	Sensor Field of View Name	06 0E 2B 34 01 01 01 01 0E 01 02 02 02 00 00 00 (CRC 60105)	Vn	Sensor Field of View Name	x	x	List	uint8	1	N	Names sensor field of view quantized steps: 00 = Ultranarrow 01 = Narrow 02 = Medium 03 = Wide 04 = Ultrawide 05 = Narrow Medium 06 = 2x Ultranarrow 07 = 4x Ultranarrow
64	Platform Magnetic Heading	06 0E 2B 34 01 01 01 01 0E 01 01 01 08 00 00 00 (CRC 41552)	Mh	Platform Magnetic Heading	x	x	Degrees	uint16	2	Y	Aircraft magnetic heading angle. Relative between longitudinal axis and Magnetic North measured in the horizontal plane. Map 0..(2 <sup>16</sup> -1) to 0..360. Resolution: ~5.5 milli degrees.
65	UAS Datalink LS Version Number	06 0E 2B 34 01 01 01 01 0E 01 02 03 03 00 00 00 (CRC 13868)	Iv	ESD ICD Version	x	x	Number	uint8	1	N	Version number of the UAS LS document used to generate a source of UAS LS KLV metadata. 0 is pre-release, initial release (0601.0), or test data. 1..255 corresponds to document revisions ST0601.1 thru ST0601.255.
66	Target Location Covariance Matrix	06 0E 2B 34 02 05 01 01 0E 01 03 03 14 00 00 00 (CRC 28126)	x	x	x	x	TBD	TBD	TBD	N	Covariance Matrix of the error associated with a targeted location. Details TBD.
67	Alternate Platform Latitude	06 0E 2B 34 01 01 01 01 0E 01 01 01 14 00 00 00 (CRC 63173)	x	x	x	x	Degrees	int32	4	N	Alternate Platform Latitude. Represents latitude of platform connected with UAS. Based on WGS84 ellipsoid. Map -(2 <sup>31</sup> -1)..(2 <sup>31</sup> -1) to +/-90. Use -(2 <sup>31</sup> ) as an "error" indicator. -(2 <sup>31</sup> ) = 0x80000000. Resolution: ~42 nano degrees.
68	Alternate Platform Longitude	06 0E 2B 34 01 01 01 01 0E 01 01 01 15 00 00 00 (CRC 32881)	x	x	x	x	Degrees	int32	4	N	Alternate Platform Longitude. Represents longitude of platform connected with UAS. Based on WGS84 ellipsoid. Map -(2 <sup>31</sup> -1)..(2 <sup>31</sup> -1) to +/-180. Use -(2 <sup>31</sup> ) as an "error" indicator. -(2 <sup>31</sup> ) = 0x80000000. Resolution: ~84 nano degrees.
69	Alternate Platform Altitude	06 0E 2B 34 01 01 01 01 0E 01 01 01 16 00 00 00	x	x	x	x	Meters	uint16	2	N	Altitude of alternate platform as measured from Mean Sea Level (MSL). Represents altitude of platform connected with UAS.

## ST 0601.10 UAS Datalink Local Set

TAG	LS Name	Mapped US	ESD	ESD Name	US	US Name	Units	Format	Len	SDCC FLP	LS Notes
		(CRC 7085)									Map 0..(2 <sup>16</sup> -1) to -900..19000 meters. 1 meter = 3.2808399 feet. Resolution: ~0.3 meters.
70	Alternate Platform Name	06 0E 2B 34 01 01 01 01 0E 01 01 01 17 00 00 00 (CRC 27929)	x	x	x	x	String	ISO 646	V	N	Name of alternate platform connected to UAS. E.g.: 'Apache', 'Rover', 'Predator', 'Reaper', 'Outrider', 'Pioneer', 'IgnatER', 'Warrior', 'Shadow', 'Hunter II', 'Global Hawk', 'Scan Eagle', etc. Value field is Free Text. Maximum 127 characters.
71	Alternate Platform Heading	06 0E 2B 34 01 01 01 01 0E 01 01 01 18 00 00 00 (CRC 47607)	x	x	x	x	Degrees	uint16	2	N	Heading angle of alternate platform connected to UAS. Relative between longitudinal axis and True North measured in the horizontal plane. Map 0..(2 <sup>16</sup> -1) to 0..360. Resolution: ~5.5 milli degrees.
72	Event Start Time – UTC	Use EG 0104 US Key	x	Mission Start Time, Date, and Date of Collection	06 0E 2B 34 01 01 01 01 07 02 01 02 07 01 00 00 (CRC 11991)	Event Start Date Time – UTC	Micro-seconds	uint64	8	N	Start time of scene, project, event, mission, editing event, license, publication, etc. Represented as the microseconds elapsed since midnight (00:00:00), January 1, 1970. Resolution: 1 microsecond.
73	RVT Local Set	Use ST 0806 RVT LS 16-byte Key	x	x	06 0E 2B 34 02 0B 01 01 0E 01 03 01 02 00 00 00 (CRC 17945)	Remote Video Terminal Local Set	None	Set	x	N	Local set tag to include the ST0806 RVT Local Set metadata items within ST0601. Use the ST0806 Local Set Tags within the ST0601 tag 0d73. The length field is the size of all RVT LS metadata items to be packaged within tag 0d73.
74	VMTI Local Set	Use ST 0903 VMTI LS 16-byte Key	x	x	06 0E 2B 34 02 0B 01 01 0E 01 03 03 06 00 00 00 (CRC 51307)	Video Moving Target Indicator Local Set	None	Set	x	N	Local set tag to include the ST0903 VMTI Local Set metadata items within ST0601. Use the ST0903 Local Set Tags within the ST0601 tag 0d74. The length field is the size of all VMTI LS metadata items to be packaged within tag 0d74.
75	Sensor Ellipsoid Height	06 0E 2B 34 01 01 01 01 0E 01 02 01 82 47 00 00 (CRC 16670)	x	x	x	x	Meters	uint16	2	Y	Sensor Ellipsoid Height as measured from the reference WGS84 Ellipsoid. Map 0..(2 <sup>16</sup> -1) to -900..19000 meters. 1 meter = 3.2808399 feet. Resolution: ~0.3 meters.
76	Alternate Platform Ellipsoid Height	06 0E 2B 34 01 01 01 01 0E 01 02 01 82 48 00 00 (CRC 27951)	x	x	x	x	Meters	uint16	2	N	Alternate Platform Ellipsoid Height as measured from the reference WGS84 Ellipsoid. Map 0..(2 <sup>16</sup> -1) to -900..19000 meters. 1 meter = 3.2808399 feet. Resolution: ~0.3 meters.
77	Operational Mode	06 0E 2B 34 01 01 01 01 0E 01 01 03 21 00 00 00	x	x	x	x	None	uint8	1	N	Indicates the mode of operations of the event portrayed in metadata. Enumerated. 0x00 = "Other"

## ST 0601.10 UAS Datalink Local Set

TAG	LS Name	Mapped US	ESD	ESD Name	US	US Name	Units	Format	Len	SDCC FLP	LS Notes
		(CRC 8938)									0x01 = "Operational" 0x02 = "Training" 0x03 = "Exercise" 0x04 = "Maintenance" 0x05 = "Test"
78	Frame Center Height Above Ellipsoid	06 0E 2B 34 01 01 01 01 0E 01 02 03 48 00 00 00 (CRC 18095)	x	x	x	x	Meters	uint16	2	N	Frame Center Ellipsoid Height as measured from the reference WGS84 Ellipsoid. Map 0..(2 <sup>16</sup> -1) to -900..19000 meters. 1 meter = 3.2808399 feet. Resolution: ~0.3 meters.
79	Sensor North Velocity	06 0E 2B 34 01 01 01 01 0E 01 02 02 7E 00 00 00 (CRC 59278)	x	x	x	x	Meters /Second	int16	2	Y	Northing velocity of the sensor or platform. Positive towards True North Map-(2 <sup>15</sup> -1)..(2 <sup>15</sup> -1) to +/-327 Use -(2 <sup>15</sup> ) as an "out of range" indicator. -(2 <sup>15</sup> ) = 0x8000. Resolution: ~ 1 cm/sec.
80	Sensor East Velocity	06 0E 2B 34 01 01 01 01 0E 01 02 02 7F 00 00 00 (CRC 37178)	x	x	x	x	Meters /Second	int16	2	Y	Easting velocity of the sensor or platform. Positive towards East. Map-(2 <sup>15</sup> -1)..(2 <sup>15</sup> -1) to +/-327 Use -(2 <sup>15</sup> ) as an "out of range" indicator. -(2 <sup>15</sup> ) = 0x8000. Resolution: ~ 1 cm/sec.
81	Image Horizon Pixel Pack	06 0E 2B 34 02 05 01 01 0E 01 03 02 08 00 00 00 (CRC 37658)	x	x	x	x	Pack	Pack		N	<tag 81><length> < start x0, start y0 // point p0 end x1, end y1 // point p1 start lat, start lon end lat, end lon >
82	Corner Latitude Point 1 (Full)	Use EG 0104 US Key	Rg	SAR Latitude 4	06 0E 2B 34 01 01 01 03 07 01 02 01 03 07 01 00 (CRC 23392)	Corner Latitude Point 1 (Decimal Degrees)	Degrees	int32	4	N	Frame Latitude for upper left corner. Full Range. Based on WGS84 ellipsoid. Map -(2 <sup>31</sup> -1)..(2 <sup>31</sup> -1) to +/-90. Use -(2 <sup>31</sup> ) as an "error" indicator. -(2 <sup>31</sup> ) = 0x80000000. Resolution: ~42 nano degrees.
83	Corner Longitude Point 1 (Full)	Use EG 0104 US Key	Rh	SAR Longitude 4	06 0E 2B 34 01 01 01 03 07 01 02 01 03 0B 01 00 (CRC 11777)	Corner Longitude Point 1 (Decimal Degrees)	Degrees	int32	4	N	Frame Longitude for upper left corner. Full Range. Based on WGS84 ellipsoid. Map -(2 <sup>31</sup> -1)..(2 <sup>31</sup> -1) to +/-180. Use -(2 <sup>31</sup> ) as an "error" indicator. -(2 <sup>31</sup> ) = 0x80000000. Resolution: ~84 nano degrees.
84	Corner Latitude Point 2 (Full)	Use EG 0104 US Key	Ra	SAR Latitude 1	06 0E 2B 34 01 01 01 03 07 01 02 01 03 08 01 00 (CRC 30545)	Corner Latitude Point 2 (Decimal Degrees)	Degrees	int32	4	N	Frame Latitude for upper right corner. Full Range. Based on WGS84 ellipsoid. Map -(2 <sup>31</sup> -1)..(2 <sup>31</sup> -1) to +/-90. Use -(2 <sup>31</sup> ) as an "error" indicator. -(2 <sup>31</sup> ) = 0x80000000. Resolution: ~42 nano degrees.



## ST 0601.10 UAS Datalink Local Set

TAG	LS Name	Mapped US	ESD	ESD Name	US	US Name	Units	Format	Len	SDCC FLP	LS Notes
85	Corner Longitude Point 2 (Full)	Use EG 0104 US Key	Rb	SAR Longitude 1	06 0E 2B 34 01 01 01 03 07 01 02 01 03 0C 01 00 (CRC 43921)	Corner Longitude Point 2 (Decimal Degrees)	Degrees	int32	4	N	Frame Longitude for upper right corner. Full Range. Based on WGS84 ellipsoid. Map $-(2^{31}-1)..(2^{31}-1)$ to $\pm 180$ . Use $-(2^{31})$ as an "error" indicator. $-(2^{31}) = 0x80000000$ . Resolution: $\sim 84$ nano degrees.
86	Corner Latitude Point 3 (Full)	Use EG 0104 US Key	Rc	SAR Latitude 2	06 0E 2B 34 01 01 01 03 07 01 02 01 03 09 01 00 (CRC 16481)	Corner Latitude Point 3 (Decimal Degrees)	Degrees	int32	4	N	Frame Latitude for lower right corner. Full Range. Based on WGS84 ellipsoid. Map $-(2^{31}-1)..(2^{31}-1)$ to $\pm 90$ . Use $-(2^{31})$ as an "error" indicator. $-(2^{31}) = 0x80000000$ . Resolution: $\sim 42$ nano degrees.
87	Corner Longitude Point 3 (Full)	Use EG 0104 US Key	Rd	SAR Longitude 2	06 0E 2B 34 01 01 01 03 07 01 02 01 03 0D 01 00 (CRC 40097)	Corner Longitude Point 3 (Decimal Degrees)	Degrees	int32	4	N	Frame Longitude for lower right corner. Full Range. Based on WGS84 ellipsoid. Map $-(2^{31}-1)..(2^{31}-1)$ to $\pm 180$ . Use $-(2^{31})$ as an "error" indicator. $-(2^{31}) = 0x80000000$ . Resolution: $\sim 84$ nano degrees.
88	Corner Latitude Point 4 (Full)	Use EG 0104 US Key	Re	SAR Latitude 3	06 0E 2B 34 01 01 01 03 07 01 02 01 03 0A 01 00 (CRC 6449)	Corner Latitude Point 4 (Decimal Degrees)	Degrees	int32	4	N	Frame Latitude for lower left corner. Full Range. Based on WGS84 ellipsoid. Map $-(2^{31}-1)..(2^{31}-1)$ to $\pm 90$ . Use $-(2^{31})$ as an "error" indicator. $-(2^{31}) = 0x80000000$ . Resolution: $\sim 42$ nano degrees.
89	Corner Longitude Point 4 (Full)	Use EG 0104 US Key	Rf	SAR Longitude 3	06 0E 2B 34 01 01 01 03 07 01 02 01 03 0E 01 00 (CRC 50673)	Corner Longitude Point 4 (Decimal Degrees)	Degrees	int32	4	N	Frame Longitude for lower left corner. Full Range. Based on WGS84 ellipsoid. Map $-(2^{31}-1)..(2^{31}-1)$ to $\pm 180$ . Use $-(2^{31})$ as an "error" indicator. $-(2^{31}) = 0x80000000$ . Resolution: $\sim 84$ nano degrees.
90	Platform Pitch Angle (Full)	Use EG 0104 US Key	Ip	UAV Pitch (INS)	06 0E 2B 34 01 01 01 07 07 01 10 01 05 00 00 00 (CRC 51059)	Platform Pitch Angle	Degrees	int32	4	Y	Aircraft pitch angle. Angle between longitudinal axis and horizontal plane. Positive angles above horizontal plane. Map $-(2^{31}-1)..(2^{31}-1)$ to $\pm 90$ . Use $-(2^{31})$ as an "out of range" indicator. $-(2^{31}) = 0x80000000$ . Res: $\sim 42$ nano deg.
91	Platform Roll Angle (Full)	Use EG 0104 US Key	Ir	UAV Roll (INS)	06 0E 2B 34 01 01 01 07 07 01 10 01 04 00 00 00 (CRC 45511)	Platform Roll Angle	Degrees	int32	4	Y	Platform roll angle. Angle between transverse axis and transvers-longitudinal plane. Positive angles for lowered right wing. Map $-(2^{31}-1)..(2^{31}-1)$ to $\pm 90$ .

# ST 0601.10 UAS Datalink Local Set

TAG	LS Name	Mapped US	ESD	ESD Name	US	US Name	Units	Format	Len	SDCC FLP	LS Notes
											Use $-(2^{31})$ as an "error" indicator. $-(2^{31}) = 0x80000000$ . Resolution: ~42 nano degrees.
92	Platform Angle of Attack (Full)	06 0E 2B 34 01 01 01 01 0E 01 01 01 02 00 00 00 (CRC 51963)	x	x	x	x	Degrees	int32	4	Y	Platform Attack Angle. Angle between platform longitudinal axis and relative wind. Positive angles for upward relative wind. Map $-(2^{31}-1)..(2^{31}-1)$ to $\pm 90$ . Use $-(2^{31})$ as an "out of range" indicator. $-(2^{31}) = 0x80000000$ . Res: ~42 nano deg.
93	Platform Sideslip Angle (Full)	06 0E 2B 34 01 01 01 01 0E 01 01 01 04 00 00 00 (CRC 60770)	x	x	x	x	Degrees	int32	4	Y	Angle between the platform longitudinal axis and relative wind. Full Range. Positive angles to right wing, neg to left. Map $-(2^{31}-1)..(2^{31}-1)$ to $\pm 90$ . Use $-(2^{31})$ as an "out of range" indicator. $-(2^{31}) = 0x80000000$ . Res: ~42 nano deg.
94	MIIS Core Identifier	Use ST1204 MIIS Core 16-byte Key.	x	x	06 0E 2B 34 01 01 01 01 0E 01 04 05 03 00 00 00 (CRC 30280)	Motion Imagery Identification System Core	None	Binary Value	x	N	Local set tag to include the ST1204 MIIS Core Identifier binary value within ST0601. Use according to the rules and requirements defined in ST1204.
95	SAR Motion Imagery Local Set	Use ST 1206 SARMI 16-byte Key	x	x	06 0E 2B 34 02 0B 01 01 0E 01 03 03 0D 00 00 00 (CRC 54900)	SAR Motion Imagery Local Set	None	Set	x	N	Local set tag to include the ST1206 SAR Motion Imagery Metadata Local Set data within ST0601. Use according to the rules and requirements defined in ST1206.
96	Target Width Extended	Use EG 0104 US Key	Tw	Target Width	06 0E 2B 34 01 01 01 01 07 01 09 02 01 00 00 00 (CRC 60350)	Target Width	Meters	IMAPB	V	Y	Target Width within sensor field of view. Range of 0 to 1,500,000 m established as maximum distance visible from an altitude of 40,000 m. To be consistent with Tag 22 Target Width, recommend a length of 3 bytes which provides ~0.25 meters of resolution.
97	Range Image Local Set	Use ST 1002 Range Imaging LS 16-byte key	x	x	06 0E 2B 34 02 0B 01 01 0E 01 03 03 0C 00 00 00 (CRC 41152)	Range Image Local Set	None	Set	x	N	Local Set tag to include ST 1002 Range Imaging LS within ST 0601.
98	Geo-Registration Local Set	Use ST 1601 Geo-Registration LS 16-byte key	x	x	06 0E 2B 34 02 0B 01 01 0E 01 03 03 01 00 00 00 (CRC 39238)	Geo-Registration Local Set	None	Set	x	N	Local Set tag to include the ST 1601 Geo-Registration LS within ST 0601.
100	Segment Local Set	Use ST 1607 Segment LS 16-byte key	x	x	06 0E 2B 34 02 0B 01 01 0E 01 03 03 03 00 00 00	Segment Local Set	None	Set	v	N	Local Set tag to include ST 1607 Segment LS within ST 0601.

## ST 0601.10 UAS Datalink Local Set

TAG	LS Name	Mapped US	ESD	ESD Name	US	US Name	Units	Format	Len	SDCC FLP	LS Notes
					(CRC 29742)						
101	Amend Local Set	Use ST 1607 Amend LS 16-byte key	x	x	06 0E 2B 34 02 0B 01 01 0E 01 03 03 03 01 00 00 (CRC 17182)	Amend Local Set	None	Set	v	N	Local Set tag to include ST 1607 Amend LS within ST 0601.
102	SDCC-FLP	Use ST 1010 SDCC-FLP 16-byte key	x	x	06 0E 2B 34 02 05 01 01 0E 01 03 03 21 00 00 00 (CRC 64882)	SDCC-FLP	Pack	Pack	v	N/A	SDCC-FLP defined in MISB ST 1010.

## 7.2 Platform and Sensor Position and Rotation Metadata

To better assist the understanding and interoperability of the UAS LS, this section describes the collective relationship between the multiple platform and sensor position and rotation metadata items available within the UAS LS.

Together the platform location and attitude, along with the sensor relative pointing angles define the location of an image or image sequence. Metadata items for sensor location (Tags 13, 14, & 15/75), platform rotations (Tags 5, 6, & 7), and sensor rotations (Tags 18, 19, & 20), along with Euler Angle order of operation rules are discussed in more detail in the subsections that follow.

### 7.2.1 Sensor Location

The metadata items associated with sensor location are:

1. *Latitude* - Sensor Latitude (Tag 13)
2. *Longitude* - Sensor Longitude (Tag 14)
3. *Height* - Sensor Altitude (Tag 15), or Sensor Ellipsoid Height (Tag 75)

### 7.2.2 Platform Rotations

The metadata items associated with platform attitude and rotations are:

1. Platform Yaw - Platform Heading Angle (Tag 5)

The platform heading angle is defined as the angle between the platform longitudinal axis (line made by the fuselage) and true north measured in the horizontal plane. Angles increase in a clockwise direction when looking from above the platform. North is 0 degrees, east is 90, south is 180, and west is 270 degrees from true north.

2. Platform Pitch - Platform Pitch Angle (Tag 6), or full-range Platform Pitch (Tag 90)

The pitch angle of the platform is the angle between the longitudinal axis (line made by the fuselage) and the horizontal plane. Angles are positive when the platform nose is above the horizontal plane. Take special care for Platform Pitch angles equal to +/- 90.

3. Platform Roll - Platform Roll Angle (Tag 7), or full-range Platform Roll (Tag 91)

The rotation operation performed about the longitudinal axis forms the roll angle between the previous aircraft transverse-longitudinal plane and the new transverse axis location (line from wing tip to wing tip). Positive angles correspond to the starboard (right) wing lowered below the previous aircraft transverse-longitudinal plane.

### 7.2.3 Sensor Rotations

The metadata items associated with sensor rotations are:

1. Sensor Relative Yaw - Sensor Relative Azimuth Angle (Tag 18)

The sensor relative azimuth angle is defined as the angle between the platform longitudinal axis (line made by the fuselage) and the sensor pointing direction, measured in the plane formed by the platform longitudinal and transverse axes (line from wing tip to wing tip). Angles increase in a clockwise direction when looking from above the platform, with 0 degrees forward along the longitudinal axis.

2. Sensor Relative Pitch - Sensor Relative Elevation Angle (Tag 19)

The relative elevation angle of the sensor to the aircraft is the downward (or upward) pointing angle of the sensor relative to the plane formed by the longitudinal axis (line made by the fuselage) and the transverse axis (line from wing tip to wing tip). Sensor pointing angles below the platform longitudinal-transverse plane are negative.

3. Sensor Relative Roll - Sensor Relative Roll Angle (Tag 20)


Sensors that are able to rotate their camera about the lens axis make use of this sensor relative roll angle. A roll angle of zero degrees occurs when the top and bottom edges of the captured image lie perpendicular to the plane created by the sensor relative depression angle axis. Positive angles are clockwise when looking from behind the camera.

### 7.2.4 Euler Angle Order of Operations

In order to properly determine the orientation of a sensor on an airborne platform using the UAS LS metadata items outlined in Section 7.2, a specific order of position, and rotation angles must be followed. The order of operations required to determine a sensor's orientation is as follows:

1. Move a sensor to the geodetic Latitude, Longitude, and altitude using
  - a. Tag 13, Sensor Latitude
  - b. Tag 14, Sensor Longitude
  - c. Tag 15, Sensor Altitude (or Tag 75: Sensor Ellipsoid Height)
2. Convert the geodetic coordinates to a geocentric system, then use a local-level North-East-Down (NED, right hand rule) sensor orientation.
3. Perform a Platform Rotation. Start with Yaw, then Pitch, the Roll.
  - a. Tag 5: Platform Heading Angle
  - b. Tag 6: Platform Pitch Angle
  - c. Tag 7: Platform Roll Angle


Refer to Figure 7-1 for the different platform rotations outlined in steps 2 and 3 above.



**Figure 7-1 : Platform Rotation Angle Example**

4. Perform a Sensor Rotation. Start with Yaw, then Pitch, then Roll.
  - a. Tag 18: Sensor Relative Azimuth Angle
  - b. Tag 19: Sensor Relative Elevation Angle
  - c. Tag 20: Sensor Relative Roll Angle

Refer to Figure 7-2 for the different sensor rotations outlined in steps 4 above.




**Figure 7-2 : Sensor Rotation Angle Example**

Once the platform and sensor attitude is known, the user is free to use other metadata items like horizontal and vertical field of view to suit the purpose of an intended application.

### 7.3 Sensor Image Geoposition Corner Metadata

An example of corner-coordinate metadata as used in a Motion Imagery system is shown in Figure 7-3 below.




**Figure 7-3: Corner Coordinate Metadata**

The Sensor Image Corner Latitude/Longitude metadata consists of the items shown in Figure 7-4. Corner coordinates are numbered to conform to National Imagery Transmission Format (NITF) Standard numbering convention for single image frame corner coordinates.

See the NITF Standards document MIL-STD-2500C Version 2.1 [15] for more information about corner coordinates. Corners not corresponding to geographic locations, i.e., above the horizon, are not to be included. This numbering scheme is different than the one used in the ESD interface described in [16].

Figure 7-4 shows a detailed mapping between metadata items for each corner point.



**Figure 7-4: Corner Point Mapping**

The LS makes use of Offset Corner Point metadata items and requires addition with the LS Frame Center coordinates to determine the actual corner points. This differs from the US and ESD data types which use corner point items that are independent of the frame center items and explicitly define actual corner coordinates without needing computation.

The LS Offset Corner Points use a mapped 2-byte signed integer which is converted to a decimal and added as an offset to the respective decimal representation of LS Frame Center Latitude or Longitude to determine the actual corner point. This offset method used in the LS only covers a finite area about an image center point (16.6km x 16.6km square area at the Equator) yet still adequately represents a typical Motion Imagery sequence while it conserves significant bandwidth over the US implementation. In comparison, each Latitude and Longitude US corner point has one 8-byte floating point value corresponding to decimal degrees which covers the entire globe.



## 7.4 Alternate Platform Guideline

Within the UAS LS there are multiple metadata items which provide position and other relevant data about an “Alternate Platform”. These items differ from the “Platform” or “Sensor” metadata field in that the “Alternate Platform” items provide no position or attitude information about an image sequence to which a UAS LS stream is tied.

Whenever a MISP-conformant Motion Imagery stream is created (a binary sequence typically containing metadata (i.e. UAS LS) and compressed Motion Imagery within an MPEG-2 transport stream) within a sensor/platform system, the sensor and platform metadata field directly relate to the imagery while the “Alternate Platform” field describe an external platform.

For instance, suppose Platform B is receiving a Motion Imagery stream from Platform A. The metadata Platform B receives would describe where Platform A is, as well as its sensor’s pointing angles. Should Platform A also include “Alternate Platform” metadata, those metadata field would represent position data for Platform C, or D, or even Platform B, but Platform A must not represent itself within “Alternate Platform” field.

As a general guideline, “Alternate Platform” field do not directly describe a Motion Imagery sequence, but aid situational awareness to a Motion Imagery stream already described through metadata by the host platform.

## 7.5 Out of Range and Error Values

Various ST 0601 metadata items have special bit-pattern representations which indicate either the item is “Out of Range”, or there is an “Error”.

For instance, some angles within this standard (such as platform pitch and roll) are represented as mapped integer values lying between a maximum and minimum angular value. Should the measured angular value lie outside the maximum or minimum value defined in this Standard, the metadata source is given the ability to convey information that a value was measured and is “Out of Range”.

Other items such as latitudes and longitudes span entire angular dimensions and are not limited to an artificial minimum by this standard. In this case a single bit sequence is reserved to indicate that the metadata value is an “Error” instead of “Out of Range”.

While not all mapped integer metadata items have “Error” or “Out of Range” bit sequences, those that do should only use these special values sparingly.

Systems receiving ST 0601 metadata should also take care when parsing mapped integer items to check for “Error” or “Out of Range” values prior to using the data value being represented.

## 8 Conversions and Mappings between Metadata Types

Metadata items that are common amongst UAS LS, Predator US, and ESD data formats each convey identical information. However, since each metadata format represents the same metadata items differently (e.g. mapped integer, float, string, etc.), the data resolution between format types is different. This section provides conversions and mappings between LS, US, and ESD metadata items.

Fields marked with an “x” are to be considered not applicable.

Example conversions tables only containing information for the LS do not have equivalent US or ESD representations.

## 8.1 Tag 1: Checksum Conversion

LS Tag	1	Units		Range		Format	
LS Name	Checksum	None		0..(2 <sup>16</sup> -1)		uint16	
US Mapped Key	06 0E 2B 34 01 01 01 01 0E 01 02 03 01 00 00 00 (CRC 56132)						
Notes		Conversion Formula					
<ul style="list-style-type: none"> <li>- Checksum used to detect errors within a UAS Datalink LS packet.</li> <li>- Lower 16-bits of summation.</li> <li>- Performed on entire LS packet, including 16-byte US key and 1-byte checksum length.</li> </ul>							
		<div>x</div> <div>x</div>					
Example Value		Example LS Packet					
0x8C ED		[K][L][V] = [0d1][0d2][0x8C ED]					

### 8.1.1 Example 16-bit Checksum Code

```
unsigned short bcc_16 (
    unsigned char * buff, // Pointer to the first byte in the 16-byte UAS LS key.
    unsigned short len ) // Length from 16-byte US key up to 1-byte checksum length.
{
    unsigned short bcc = 0, i; // Initialize Checksum and counter variables.
    for ( i = 0 ; i < len; i++)
        bcc += buff[i] << (8 * ((i + 1) % 2));
    return bcc;
} // end of bcc_16 ()
```

### 8.1.2 Sample Checksum Data

64 bits to checksum: 060E 2B34 0200 81BB

```

060E
+ 2B34
-----
3142
+ 0200
-----
3342
+ 81BB
-----
B4FD <-- Final Checksum
```

## 8.2 Tag 2: Precision Time Stamp Conversion

LS Tag	2	Units	Range	Format
LS Name	Precision Time Stamp	Micro-seconds	0..(2 <sup>64</sup> -1)	uint64
US Mapped Key	Use EG 0104 US Key (CRC 56132)			
Notes		Conversion Formula		
<ul style="list-style-type: none"> <li>- Represented in the number of microseconds elapsed since midnight (00:00:00), January 1, 1970 not including leap seconds.</li> <li>- See MISB ST 0603.</li> <li>- Resolution: 1 microsecond.</li> </ul>		x		
		x		
Example Value		Example LS Packet		
Oct. 24, 2008. 00:13:29.913		[K][L][V] = [0d2][0d8][0x00 04 59 F4 A6 AA 4A A8]		
US Key	06 0E 2B 34 01 01 01 03 07 02 01 01 01 05 00 00 (CRC 64827)	ESD Digraph	x	
US Name	User Defined Time Stamp - Microseconds since 1970	ESD Name	x	
Units	Range	Format	Units	Range
uSec	uint64	uint64	x	x
Notes		Notes		
<ul style="list-style-type: none"> <li>- Precision Time Stamp defined by user.</li> <li>- 64-bit integer which represents the number of microseconds since Jan 1, 1970, not including leap seconds. See MISB ST 0603.</li> </ul>		- x		
US Conversion		ESD Conversion		
x		x		
<u>To US:</u>		<u>To ESD:</u>		
- x		- x		
<u>To LS:</u>		<u>To LS:</u>		
- x		- x		

### 8.2.1 Example Precision Time Stamp

This metadata element represents time as the number of microseconds elapsed since January 1, 1970 (1970-01-01T00:00:00Z), and is specified using 8 bytes.

A Precision Time Stamp discretely labels a scale of time. This system is widely used within systems of differing underlying architectures. The Precision Time Stamp is specified in MISB ST 0603.

### 8.3 Tag 3: Mission ID Conversion

LS Tag	3	Units	Range	Format	
LS Name	Mission ID	String	1..127	ISO 646	
US Mapped Key	06 0E 2B 34 01 01 01 01 0E 01 04 01 03 00 00 00 (CRC 65358)				
Notes		Conversion Formula			
- Descriptive Mission Identifier to distinguish event or sortie.		x			
- Value field is Free Text.		x			
- Maximum 127 characters.					
Example Value		Example LS Packet			
MISSION01		[K][L][V] = [0d3][0d9][0x4D 49 53 53 49 4F 4E 30 31]			
US Key	06 0E 2B 34 01 01 01 01 01 05 05 00 00 00 00 00 (CRC 37735)	ESD Digraph	Mn		
US Name	Episode Number	ESD Name	Mission Number		
Units	Range	Format	Units	Range	Format
Number	x	Float	Alpha-Numeric	1..9	String
Notes		Notes			
- x		- Number to distinguish different missions started on a given day			
US Conversion		ESD Conversion			
x		x			
<u>To US:</u>		<u>To ESD:</u>			
- x		- x			
<u>To LS:</u>		<u>To LS:</u>			
- x		- x			

#### 8.3.1 Example Mission ID

Format and contents of a Mission ID are to be determined.

## 8.4 Tag 4: Platform Tail Number Conversion

LS Tag	4	Units	Range	Format	
LS Name	Platform Tail Number	String	1..127	ISO 646	
US Mapped Key	06 0E 2B 34 01 01 01 01 0E 01 04 01 02 00 00 00 (CRC 35322)				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- Identifier of platform as posted.</li><li>- E.g.: "AF008", "BP101", etc.</li><li>- Value field is Free Text.</li><li>- Maximum 127 characters.</li></ul>		x			
		x			
Example Value		Example LS Packet			
AF-101		[K][L][V] = [0d4][0d6][0x41 46 2D 31 30 31]			
US Key	x	ESD Digraph	Pt		
US Name	x	ESD Name	Platform Tail Number		
Units	Range	Format	Units	Range	Format
x	x	x	Number	0..3	N
Notes		Notes			
- x		- x			
US Conversion		ESD Conversion			
x		x			
<u>To US:</u>		<u>To ESD:</u>			
- x		- x			
<u>To LS:</u>		<u>To LS:</u>			
- x		- x			

### 8.4.1 Example Platform Tail Number


Format and contents of a Platform Tail Number are to be determined.

## 8.5 Tag 5: Platform Heading Angle Conversion

LS Tag	5	Units	Range	Format	
LS Name	Platform Heading Angle	Degrees	0..360	uint16	
US Mapped Key	Use EG0104 US Key (CRC 56132)				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- Aircraft heading angle. Relative between longitudinal axis and True North measured in the horizontal plane.</li><li>- Map 0..(2^16-1) to 0..360.</li><li>- Resolution: ~5.5 milli degrees.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{int\_range} * LS\_int \right)$ $LS\_5\_dec = \left( \frac{360}{65535} * LS\_5 \right)$			
Example Value		Example LS Packet			
159.9744 Degrees		[K] [L] [V] = [0d5] [0d2] [0x71 C2]			
US Key	06 0E 2B 34 01 01 01 07 07 01 10 01 06 00 00 00 (CRC 23727)	ESD Digraph	Ih		
US Name	Platform Heading Angle	ESD Name	UAV Heading (INS)		
Units	Range	Format	Units	Range	Format
Degrees	0..360	Float	Degrees	0..359.99	DDD.HH
Notes		Notes			
<ul style="list-style-type: none"><li>- Heading angle of platform expressed in degrees.</li><li>- The Heading of an airborne platform is the angle from True North of its longitudinal axis projected onto the horizontal plane.</li></ul>		<ul style="list-style-type: none"><li>- True heading of the aircraft.</li></ul>			
US Conversion		ESD Conversion			
$US\_dec = \left( \frac{360}{65535} * LS\_uint \right)$ <p><u>To US:</u></p> <ul style="list-style-type: none"><li>- US = (float)(360/0xFFFF * LS)</li></ul> <p><u>To LS:</u></p> <ul style="list-style-type: none"><li>- LS = (uint16)round(0xFFFF/360 * US)</li></ul>		$ESD\_dec = \left( \frac{360}{65535} * LS\_uint \right)$ <p><u>To ESD:</u></p> <ul style="list-style-type: none"><li>- Convert LS to decimal.</li><li>- Convert decimal to ASCII.</li></ul> <p><u>To LS:</u></p> <ul style="list-style-type: none"><li>- Convert ASCII to decimal.</li><li>- Map decimal to uint16.</li></ul>			

### 8.5.1 Example Platform Heading Angle

The platform heading angle is defined as the angle between longitudinal axis (line made by the fuselage) and true north measured in the horizontal plane. Angles increase in a clockwise direction when looking from above the platform. North is 0 degrees, east is 90, south is 180, and west is 270 degrees from true north. Refer to Figure 8-1:



**Figure 8-1: Platform True Heading Angle**

## 8.6 Tag 6: Platform Pitch Angle Conversion

LS Tag	6	Units	Range	Format	
LS Name	Platform Pitch Angle	Degrees	+/- 20	int16	
US Mapped Key	Use EG 0104 US Key				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- Aircraft pitch angle. Angle between longitudinal axis and horizontal plane.</li><li>- Positive angles above horizontal plane.</li><li>- Map -(2^15-1)..(2^15-1) to +/-20.</li><li>- Use -(2^15) as "out of range" indicator.</li><li>- -(2^15) = 0x8000.</li><li>- Resolution: ~610 micro degrees.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{int\_range} * LS\_int \right)$ $LS\_06\_dec = \left( \frac{40}{65534} * LS\_int \right)$			
Example Value		Example LS Packet			
-0.4315251 Degrees		[K][L][V] = [0d6][0d2][0xFD 3D]			
US Key	06 0E 2B 34 01 01 01 07 07 01 10 01 05 00 00 00 (CRC 51059)	ESD Digraph	Ip		
US Name	Platform Pitch Angle	ESD Name	UAV Pitch (INS)		
Units	Range	Format	Units	Range	Format
Degrees	+/- 90	Float	Degrees	+/- 20.00	PDD.HH
Notes		Notes			
<ul style="list-style-type: none"><li>- Pitch angle of platform expressed in degrees.</li><li>- The Pitch of an airborne platform describes the angle the longitudinal axis makes with the horizontal (i.e., equi-potential gravitational surface);</li></ul>		<ul style="list-style-type: none"><li>- Pitch angle of the aircraft.</li></ul>			
US Conversion		ESD Conversion			
$US\_dec = \left( \frac{40}{65534} * LS\_int \right)$ <p><u>To US:</u></p> <ul style="list-style-type: none"><li>- US = (float)(40/0xFFFFE * LS)</li></ul> <p><u>To LS:</u></p> <ul style="list-style-type: none"><li>- LS = (int16)round(0xFFFFE/40 * US)</li></ul>		$ESD\_dec = \left( \frac{40}{65534} * LS\_int \right)$ <p><u>To ESD:</u></p> <ul style="list-style-type: none"><li>- Convert LS to decimal.</li><li>- Convert decimal to ASCII.</li></ul> <p><u>To LS:</u></p> <ul style="list-style-type: none"><li>- Convert ASCII to decimal.</li><li>- Map decimal to int16.</li></ul>			

### 8.6.1 Example Platform Pitch Angle


*For legacy purposes, both range-restricted (Tag 6) and full-range (Tag 90) representations of Platform Pitch Angle MAY appear in the same ST 0601 packet. A single representation is preferred favoring the full-range version (Tag 90) as per Section 6.3.*

The pitch angle of the platform is the angle between the longitudinal axis (line made by the fuselage) and the horizontal plane. Angles are positive when the platform nose is above the horizontal plane (see Figure 8-2).



Pitch angles are limited to  $\pm 20$  degrees to increase metadata resolution within this range. Should the aircraft experience flight maneuvers beyond this range, an “out of range” indication shall be made within this metadata item. Refer to the Figure 8-2.

Note that the int16 used in the LS value is encoded using two’s complement.



**Figure 8-2: Platform Pitch Angle**

## 8.7 Tag 7: Platform Roll Angle Conversion

LS Tag	7	Units	Range	Format	
LS Name	Platform Roll Angle	Degrees	+/- 50	int16	
US Mapped Key	Use EG 0104 US Key				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- Platform roll angle. Angle between transverse axis and transvers-longitudinal plane. Positive angles for lowered right wing.</li><li>- Map <math>(-2^{15}-1) \dots (2^{15}-1)</math> to +/-50.</li><li>- Use <math>-(2^{15})</math> as "out of range" indicator.</li><li>- <math>-(2^{15}) = 0x8000</math>.</li><li>- Res: ~1525 micro deg.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{int\_range} * LS\_int \right)$ $LS\_07\_dec = \left( \frac{100}{65534} * LS\_int \right)$			
Example Value		Example LS Packet			
3.405814 Degrees		[K][L][V] = [0d7][0d2][0x08 B8]			
US Key	06 0E 2B 34 01 01 01 07 07 01 10 01 04 00 00 00 (CRC 45511)	ESD Digraph	Ir		
US Name	Platform Roll Angle	ESD Name	UAV Roll (INS)		
Units	Range	Format	Units	Range	Format
Degrees	+/- 90	Float	Degrees	+/- 50.00	PDD.HH
Notes		Notes			
<ul style="list-style-type: none"><li>- Roll angle of platform expressed in degrees.</li><li>- The Roll of an airborne platform is rotation about its longitudinal (front-to-back) axis;</li><li>- Wings level is zero degrees, positive (negative) angles describe a platform orientation with the right wing down(up).</li></ul>		<ul style="list-style-type: none"><li>- Roll angle of the aircraft</li></ul>			
US Conversion		ESD Conversion			
$US\_dec = \left( \frac{100}{65534} * LS\_int \right)$ <p><u>To US:</u></p> <ul style="list-style-type: none"><li>- US = (float)(100/0xFFFF * LS)</li></ul> <p><u>To LS:</u></p> <ul style="list-style-type: none"><li>- LS = (int16)round(0xFFFF/100 * US)</li></ul>		$ESD\_dec = \left( \frac{100}{65534} * LS\_int \right)$ <p><u>To ESD:</u></p> <ul style="list-style-type: none"><li>- Convert LS to decimal.</li><li>- Convert decimal to ASCII.</li></ul> <p><u>To LS:</u></p> <ul style="list-style-type: none"><li>- Convert ASCII to decimal.</li><li>- Map decimal to int16.</li></ul>			


### 8.7.1 Example Platform Roll Angle

*For legacy purposes, both range-restricted (Tag 7) and full-range (Tag 91) representations of Platform Roll Angle MAY appear in the same ST 0601 packet. A single representation is preferred favoring the full-range version (Tag 91) as per Section 6.3.*

The rotation operation performed about the longitudinal axis forms the roll angle between the previous aircraft transverse-longitudinal plane and the new transverse axis location (line from wing tip to wing tip). Positive angles correspond to the starboard (right) wing lowered below the previous aircraft transverse-longitudinal plane (see Figure 8-3).

Roll angles are limited to  $\pm 50$  degrees to increase metadata resolution within this range. Should the aircraft experience flight maneuvers beyond this range, an “out of range” indication shall be made within this metadata item. Refer to Figure 8-3.

Note that the int16 used in the LS value is encoded using two’s complement.



**Figure 8-3: Platform Roll Angle**

## 8.8 Tag 8: Platform True Airspeed Conversion

LS Tag	8	Units	Range	Format	
LS Name	Platform True Airspeed	Meters /Second	0..255	uint8	
US Mapped Key	06 0E 2B 34 01 01 01 01 0E 01 01 01 0A 00 00 00 (CRC 20280)				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- True airspeed (TAS) of platform. Indicated Airspeed adjusted for temperature and altitude.</li><li>- 0..255 meters/sec.</li><li>- 1 m/s = 1.94384449 knots.</li><li>- Resolution: 1 meter/second.</li></ul>		$\text{LS\_dec} = \text{LS\_int}$ $\text{LS\_08\_dec} = \text{round}(\text{LS\_08})$			
Example Value		Example LS Packet			
147 m/Sec		[K][L][V] = [0d8][0d1][0x93]			
US Key	x	ESD Digraph	As		
US Name	x	ESD Name	True Airspeed		
Units	Range	Format	Units	Range	Format
x	x	x	Knots	0..999	N
Notes		Notes			
<ul style="list-style-type: none"><li>- x</li></ul>		<ul style="list-style-type: none"><li>- True airspeed of the aircraft</li></ul>			
US Conversion		ESD Conversion			
$\text{To US:}$ <ul style="list-style-type: none"><li>- x</li></ul> $\text{To LS:}$ <ul style="list-style-type: none"><li>- x</li></ul>		$\text{ESD\_dec} = \left( \text{LS\_uint} * \frac{1.94384449 \text{ knots}}{1 \text{ meters/second}} \right)$ $\text{To ESD:}$ <ul style="list-style-type: none"><li>- Map LS to integer.</li><li>- Convert integer value to ASCII.</li></ul> $\text{To LS:}$ <ul style="list-style-type: none"><li>- Convert ASCII to integer.</li><li>- Map integer to uint8.</li></ul>			

### 8.8.1 Example Platform True Airspeed

True airspeed is the actual speed an aircraft is traveling relative through the air mass in which it flies. Without a relative wind condition, the true airspeed is equal to the speed over the ground. The true airspeed of the aircraft is calculated using the outside temperature, impact pressure (pitot tube), and static pressure.

## 8.9 Tag 9: Platform Indicated Airspeed Conversion

LS Tag	9	Units	Range	Format	
LS Name	Platform Indicated Airspeed	Meters /Second	0..255	uint8	
US Mapped Key	06 0E 2B 34 01 01 01 01 0E 01 01 01 0B 00 00 00 (CRC 14732)				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- Indicated airspeed (IAS) of platform. Derived from Pitot tube and static pressure sensors.</li><li>- 0..255 meters/sec.</li><li>- 1 m/s = 1.94384449 knots.</li><li>- Resolution: 1 meter/second.</li></ul>		$LS\_dec = LS\_int$ $LS\_09\_dec = round(LS\_09)$			
Example Value		Example LS Packet			
159 m/Sec		[K][L][V] = [0d9][0d1][0x9F]			
US Key	x	ESD Digraph	Ai		
US Name	x	ESD Name	Indicated Airspeed		
Units	Range	Format	Units	Range	Format
x	x	x	Knots	0..999	N
Notes		Notes			
<ul style="list-style-type: none"><li>- x</li></ul>		<ul style="list-style-type: none"><li>- Indicated airspeed of the aircraft</li></ul>			
US Conversion		ESD Conversion			
$x$ <u>To US:</u> <ul style="list-style-type: none"><li>- x</li></ul> <u>To LS:</u> <ul style="list-style-type: none"><li>- x</li></ul>		$ESD\_dec = \left( LS\_uint * \frac{1.94384449 \text{ knots}}{1 \text{ meters/second}} \right)$ <u>To ESD:</u> <ul style="list-style-type: none"><li>- Map LS to integer.</li><li>- Convert integer value to ASCII.</li></ul> <u>To LS:</u> <ul style="list-style-type: none"><li>- Convert ASCII to integer.</li><li>- Map integer to uint8.</li></ul>			

### 8.9.1 Example Platform Indicated Airspeed

The indicated airspeed of an aircraft is calculated from the difference between static pressure, and impact pressure. Static pressure is measured by a sensor not directly in the air stream and impact pressure is measured by a Pitot tube positioned strategically within the air stream. The difference in pressure while moving provides a way to calculate the indicated platform airspeed.

## 8.10 Tag 10: Platform Designation Conversion

LS Tag	10	Units	Range	Format	
LS Name	Platform Designation	String	1..127	ISO 646	
US Mapped Key	Use EG 0104 US Key				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- Use Platform Designation String</li><li>- e.g.: 'Predator', 'Reaper', 'Outrider', 'Pioneer', 'IgnatER', 'Warrior', 'Shadow', 'Hunter II', 'Global Hawk', 'Scan Eagle', etc.</li><li>- Value field is Free Text.</li><li>- Maximum 127 characters.</li></ul>		<div>x</div> <div>x</div>			
Example Value		Example LS Packet			
MQ1-B		[K][L][V] = [0d10][0d5][0x4D 51 31 2D 42]			
US Key	06 0E 2B 34 01 01 01 01 01 01 20 01 00 00 00 00 (CRC 36601)	ESD Digraph	Pc		
US Name	Device Designation	ESD Name	Project ID Code		
Units	Range	Format	Units	Range	Format
String	1..32	ISO 646	Number	0..99	N
Notes		Notes			
<ul style="list-style-type: none"><li>- Identifies the "house name" of the device used in capturing or generating the essence.</li><li>- 32 characters maximum.</li><li>- ISO7 character set.</li></ul>		<ul style="list-style-type: none"><li>- The Project ID of the Collection Platform.</li><li>- (e.g., Predator, Outrider, Pioneer, etc.)</li></ul>			
US Conversion		ESD Conversion			
x		x			
<u>To US:</u>		<u>To ESD:</u>			
<ul style="list-style-type: none"><li>- x</li></ul>		<ul style="list-style-type: none"><li>- Convert string to Project ID Code.</li></ul>			
<u>To LS:</u>		<u>To LS:</u>			
<ul style="list-style-type: none"><li>- x</li></ul>		<ul style="list-style-type: none"><li>- Convert Project ID Code to string.</li></ul>			

### 8.10.1 Example Platform Designation

The platform designation metadata item distinguishes which platform is carrying the Motion Imagery generating payload equipment. Some current platforms are shown in Figure 8-4:



**Figure 8-4: Example Platforms**

Note: Some systems use the US key 06 0E 2B 34 01 01 01 03 01 01 21 01 00 00 00 00 to represent Platform Designation instead of the 16-byte key shown above (Device Designation) as used in EG 0104.5.

## 8.11 Tag 11: Image Source Sensor Conversion

LS Tag	11	Units	Range	Format	
LS Name	Image Source Sensor	String	1..127	ISO 646	
US Mapped Key	Use EG0104 US Key				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- String of image source sensor.</li><li>- E.g.: 'EO Nose', 'EO Zoom (DLTV)', 'EO Spotter', 'IR Mitsubishi PtSi Model 500', 'IR InSb Amber Model TBT', 'LYNX SAR Imagery', 'TESAR Imagery', etc.</li><li>- Value field is Free Text.</li><li>- Maximum 127 characters.</li></ul>		<ul style="list-style-type: none"><li>x</li><li>x</li></ul>			
Example Value		Example LS Packet			
EO		[K][L][V] = [0d11][0d2][0x45 4F]			
US Key	06 0E 2B 34 01 01 01 01 04 20 01 02 01 01 00 00	ESD Digraph	Sn		
US Name	Image Source Device	ESD Name	Sensor Name		
Units	Range	Format	Units	Range	Format
String	1..32	ISO 646	Name Code	0..7	N
Notes		Notes			
<ul style="list-style-type: none"><li>- Indicates the type of the image source.</li><li>- 32 characters maximum.</li><li>- ISO7 character set.</li></ul>		<ul style="list-style-type: none"><li>- Identifies the source of the video image:</li><li>- 0: EO Nose</li><li>- 1: EO Zoom (DLTV)</li><li>- 2: EO Spotter</li><li>- 3: IR Mitsubishi PtSi Model 500</li><li>- 4: IR Mitsubishi PtSi Model 600</li><li>- 5: IR InSb Amber Model TBD</li><li>- 6: Lynx SAR Imagery</li><li>- 7: TESAR Imagery</li></ul>			
US Conversion		ESD Conversion			
x		x			
<u>To US:</u>		<u>To ESD:</u>			
<ul style="list-style-type: none"><li>- x</li></ul>		<ul style="list-style-type: none"><li>- Convert string to ID code.</li></ul>			
<u>To LS:</u>		<u>To LS:</u>			
<ul style="list-style-type: none"><li>- x</li></ul>		<ul style="list-style-type: none"><li>- Convert ID code to string.</li></ul>			

### 8.11.1 Example Image Source Sensor

A sample imaging source sensor is shown in Figure 8-5:



Figure 8-5: Sample Imaging Sensor



## 8.12 Tag 12: Image Coordinate System Conversion

LS Tag	12	Units	Range	Format	
LS Name	Image Coordinate System	String	1..127	ISO 646	
US Mapped Key	Use EG 0104 US Key				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- String of the image coordinate system used.</li><li>- E.g.: 'Geodetic WGS84', 'Geocentric WGS84', 'UTM', 'None', etc.</li></ul>		x			
		x			
Example Value		Example LS Packet			
WGS-84		[K][L][V] = [0d12][0d6][0x57 47 53 2D 38 34]			
US Key	06 0E 2B 34 01 01 01 01 07 01 01 01 00 00 00 00 (CRC 32410)	ESD Digraph	Ic		
US Name	Image Coordinate System	ESD Name	Image Coordinate System		
Units	Range	Format	Units	Range	Format
String	1..4	ISO 646	Code	0..3	N
Notes		Notes			
<ul style="list-style-type: none"><li>- Identifies the Digital Geographic Information Exchange Standard (DIGEST) geo-referenced coordinate system used at image capture.</li><li>- ISO7 character set.</li></ul>		<ul style="list-style-type: none"><li>- Identifies the image coordinate system used:</li><li>- 0: Geodetic WGS84</li><li>- 1: Geocentric WGS 84</li><li>- 2: UTM</li><li>- 3: None</li></ul>			
US Conversion		ESD Conversion			
x		x			
<u>To US:</u>		<u>To ESD:</u>			
<ul style="list-style-type: none"><li>- x</li></ul>		<ul style="list-style-type: none"><li>- Convert string to ID code.</li></ul>			
<u>To LS:</u>		<u>To LS:</u>			
<ul style="list-style-type: none"><li>- x</li></ul>		<ul style="list-style-type: none"><li>- Convert ID code to string.</li></ul>			

### 8.12.1 World Geodetic System – 1984 (WGS 84)

The World Geodetic System of 1984 (WGS 84) is a 3-D, Earth-centered reference system developed originally by the U.S. Defense Mapping Agency. This system is the official GPS reference system.

### 8.12.2 Universal Transverse Mercator (UTM)

UTM is the projection of the earth onto a cylinder. The Universal Transverse Mercator Projection (UTM) divides the globe, excluding the extreme polar areas, into 100km x100km sections and projects each section onto a separate plane that is tangent to the globe at a point within that section. An orthorectifying grid is applied to the projection and results in very minor distortions as no location is greater than 140 km from the point of tangency. Distances, angles and shapes are very accurately depicted within each plane using this earth coordinate system.

Applications exist which convert between UTM and WGS84 coordinate systems and their different datum references.

### 8.12.3 Notes and Clarification

As of ST 0601.4, a reference to “DIGEST V2.1 Part 3 Sec 6.4” within the UAS LS section has been removed due to the reference’s inapplicability to the Image Coordinate System metadata item.

“Geodetic WGS84” is the preferred Image Coordinate System. “UTM” and other values are provided for sake of completeness to map items between legacy metadata sets.

## 8.13 Tag 13: Sensor Latitude Conversion

LS Tag	13	Units	Range	Format	
LS Name	Sensor Latitude	Degrees	+/- 90	int32	
US Mapped Key	Use EG 0104 US Key				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- Sensor Latitude. Based on WGS84 ellipsoid.</li><li>- Map -(2^31-1)..(2^31-1) to +/-90.</li><li>- Use -(2^31) as an "error" indicator.</li><li>- -(2^31) = 0x80000000.</li><li>- Resolution: ~42 nano degrees.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{int\_range} * LS\_int \right)$ $LS\_13\_dec = \left( \frac{180}{4294967294} * LS\_13 \right)$			
Example Value		Example LS Packet			
60.1768229669783 Degrees		[K][L][V] = [0d13][0d4][0x55 95 B6 6D]			
US Key	06 0E 2B 34 01 01 01 03 07 01 02 01 02 04 02 00 (CRC 8663)	ESD Digraph	Sa		
US Name	Device Latitude	ESD Name	Sensor Latitude		
Units	Range	Format	Units	Range	Format
Degrees	+/- 90	Double	Degrees	+/- 90.00	PDDMMSSST
Notes		Notes			
<ul style="list-style-type: none"><li>- Specifies a sensor's geographic location in decimal degrees of latitude.</li><li>- Positive values indicate northern hemisphere.</li><li>- Negative values indicate southern hemisphere.</li></ul>		<ul style="list-style-type: none"><li>- Latitude of the aircraft. + Means North Latitude. All Latitude coordinates use WGS84.</li></ul>			
US Conversion		ESD Conversion			
$US\_dec = \left( \frac{180}{4294967294} * LS\_int \right)$		$ESD\_dec = \left( \frac{180}{4294967294} * LS\_int \right)$			
<u>To US:</u> <ul style="list-style-type: none"><li>- US = (double)(180/0xFFFFFFFF * LS)</li></ul>		<u>To ESD:</u> <ul style="list-style-type: none"><li>- Convert LS to decimal.</li><li>- Convert decimal to ASCII.</li></ul>			
<u>To LS:</u> <ul style="list-style-type: none"><li>- LS = (int32)round(0xFFFFFFFF/180 * US)</li></ul>		<u>To LS:</u> <ul style="list-style-type: none"><li>- Convert ASCII to decimal.</li><li>- Map decimal to int32.</li></ul>			

### 8.13.1 Example Latitude

Latitude is the angular distance north or south of the earth's equator, measured in degrees along a meridian. Generated from GPS/INS information and based on the WGS84 coordinate system.

Note that this LS item for Sensor Latitude represents the imaging sensor location versus the aircraft position as represented by the ESD digraph.

In a realized system, this LS item takes into account the lever arm distance between a platform's GPS antenna (or known central platform position) to a sensor's general location (like the center of a gimbaled sensor).

While accounting for a lever arm in this crude way is sufficient for many Motion Imagery systems, it is recommended for the user to explore use of Photogrammetric metadata sets (i.e. MISB ST 0801 [17]) for improved representations of system accuracies.

Note that the int32 used in the LS value is encoded using two's complement.

## 8.14 Tag 14: Sensor Longitude Conversion

LS Tag	14	Units	Range	Format	
LS Name	Sensor Longitude	Degrees	+/- 180	int32	
US Mapped Key	Use EG 0104 US Key				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- Sensor Longitude. Based on WGS84 ellipsoid.</li><li>- Map -(2^31-1)..(2^31-1) to +/-180.</li><li>- Use -(2^31) as an "error" indicator.</li><li>- -(2^31) = 0x80000000.</li><li>- Resolution: ~84 nano degrees.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{int\_range} * LS\_int \right)$ $LS\_14\_dec = \left( \frac{360}{4294967294} * LS\_14 \right)$			
Example Value		Example LS Packet			
128.426759042045 Degrees		[K][L][V] = [0d14][0d4][0x5B 53 60 C4]			
US Key	06 0E 2B 34 01 01 01 03 07 01 02 01 02 06 02 00 (CRC 20407)	ESD Digraph	So		
US Name	Device Longitude	ESD Name	Sensor Longitude		
Units	Range	Format	Units	Range	Format
Degrees	+/- 180	Double	Degrees	+/- 180.00	PDDMMSSST
Notes		Notes			
<ul style="list-style-type: none"><li>- Specifies a sensor's geographic location in decimal degrees of longitude.</li><li>- Positive values indicate eastern hemisphere.</li><li>- Negative values indicate western hemisphere.</li></ul>		<ul style="list-style-type: none"><li>- Longitude of the aircraft. + Means East Longitude. All Longitude coordinates use WGS84.</li></ul>			
US Conversion		ESD Conversion			
$US\_dec = \left( \frac{360}{4294967294} * LS\_int \right)$		$ESD\_dec = \left( \frac{360}{4294967294} * LS\_int \right)$			
<u>To US:</u> <ul style="list-style-type: none"><li>- US = (double) (360/0xFFFFFFFF * LS)</li></ul>		<u>To ESD:</u> <ul style="list-style-type: none"><li>- Convert LS to decimal.</li><li>- Convert decimal to ASCII.</li></ul>			
<u>To LS:</u> <ul style="list-style-type: none"><li>- LS = (int32)round(0xFFFFFFFF/360 * US)</li></ul>		<u>To LS:</u> <ul style="list-style-type: none"><li>- Convert ASCII to decimal.</li><li>- Map decimal to int32.</li></ul>			

### 8.14.1 Example Longitude

Longitude is the angular distance on the earth's surface, measured east or west from the prime meridian at Greenwich, England, to the meridian passing through a position of interest. Generated from GPS/INS information and based on the WGS84 coordinate system.

Note that this LS item for Sensor Longitude represents the imaging sensor location versus the aircraft position as represented by the ESD digraph.

In a realized system, this LS item takes into account the lever arm distance between a platform's GPS antenna (or known central platform position) to a sensor's general location (like the center of a gimbaled sensor).

While accounting for a lever arm in this crude way is sufficient for many Motion Imagery systems, it is recommended for the user to explore use of Photogrammetric metadata sets (i.e. MISB ST 0801) for improved representations of system accuracies.

Note that the int32 used in the LS value is encoded using two's complement.

## 8.15 Tag 15: Sensor True Altitude Conversion

LS Tag	15	Units	Range	Format	
LS Name	Sensor True Altitude	Meters	-900..19000	uint16	
US Mapped Key	Use EG 0104 US Key				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- Altitude of sensor as measured from Mean Sea Level (MSL).</li><li>- Map 0..(2^16-1) to -900..19000 meters.</li><li>- 1 meter = 3.2808399 feet.</li><li>- Resolution: ~0.3 meters.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{uint\_range} * LS\_uint \right) - Offset$ $LS\_15\_dec = \left( \frac{19900}{65535} * LS\_15 \right) - 900$			
Example Value		Example LS Packet			
14190.72 Meters		[K][L][V] = [0d15][0d2][0xC2 21]			
US Key	06 0E 2B 34 01 01 01 01 07 01 02 01 02 02 00 00 (CRC 13170)	ESD Digraph	S1		
US Name	Device Altitude	ESD Name	Sensor Altitude		
Units	Range	Format	Units	Range	Format
Meters	Float	Float	Feet	+/- 0..99,999	PN
Notes		Notes			
<ul style="list-style-type: none"><li>- Altitude of sensor as measured from Mean Sea Level (MSL), (default metres).</li></ul>		<ul style="list-style-type: none"><li>- Altitude of the aircraft (MSL)</li></ul>			
US Conversion		ESD Conversion			
$US\_dec = \left( \frac{19900}{65535} * LS\_uint \right) - 900$		$ESD\_dec = \left( \frac{19900}{65535} * LS\_uint - 900 \right) * \frac{3.2808399ft}{1m}$			
<u>To US:</u> <ul style="list-style-type: none"><li>- US = (float)((19900/0xFFFF) * LS - 900)</li></ul>		<u>To ESD:</u> <ul style="list-style-type: none"><li>- Convert LS to decimal.</li><li>- Account for units.</li><li>- Convert decimal to ASCII.</li></ul>			
<u>To LS:</u> <ul style="list-style-type: none"><li>- LS = (uint16)round(0xFFFF/19900 * (US + 900))</li></ul>		<u>To LS:</u> <ul style="list-style-type: none"><li>- Convert ESD ASCII to decimal.</li><li>- Account for units.</li><li>- Map decimal to uint16.</li></ul>			

### 8.15.1 Example True Altitude

*For legacy purposes, both MSL (Tag 15) and HAE (Tag 75) representations of Sensor True Altitude MAY appear in the same ST 0601 packet. A single representation is preferred favoring the HAE version (Tag 75).*

True Altitude is the true vertical distance above mean sea level.

For improved modeling accuracy it is suggested to alternatively use Sensor Ellipsoid Height (Tag 75) should GPS be used to determine altitude.

Note that this LS item for Sensor Altitude represents the imaging sensor location versus the aircraft position as represented by the ESD digraph.

In a realized system, this LS item takes into account the lever arm distance between a platform's GPS antenna (or known central platform position) to a sensor's general location (like the center of a gimbaled sensor).

While accounting for a lever arm in this crude way is sufficient for many Motion Imagery systems, it is recommended for the user to explore use of Photogrammetric metadata sets (i.e. MISB ST 0801) for improved representations of system accuracies.


## 8.16 Tag 16: Sensor Horizontal field of View Conversion

LS Tag	16	Units	Range	Format	
LS Name	Sensor Horizontal field of View	Degrees	0..180	uint16	
US Mapped Key	Use EG 0104 US Key				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- Horizontal field of view of selected imaging sensor.</li><li>- Map 0..(2^16-1) to 0..180.</li><li>- Resolution: ~2.7 milli degrees.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{uint\_range} * LS\_uint \right)$ $LS\_16\_dec = \left( \frac{180}{65535} * LS\_16 \right)$			
Example Value		Example LS Packet			
144.5713 Degrees		[K][L][V] = [0d16][0d2][0xCD 9C]			
US Key	06 0E 2B 34 01 01 01 02 04 20 02 01 01 08 00 00 (CRC 23753)	ESD Digraph	Fv		
US Name	Field of View (FOV-Horizontal)	ESD Name	Field of View		
Units	Range	Format	Units	Range	Format
Degrees	0..180	Float	Degrees	0..180.00	DDD.HH
Notes			Notes		
<ul style="list-style-type: none"><li>- Sensor Horizontal field of view.</li></ul>			<ul style="list-style-type: none"><li>- Angle of view of the lens on the selected camera. Horizontal, across baseline of image, projected onto the terrain (flat terrain model at DTED or other best available elevation data).</li></ul>		
US Conversion			ESD Conversion		
$US\_dec = \left( \frac{180}{65535} * LS\_uint \right)$ <p><u>To US:</u></p> <ul style="list-style-type: none"><li>- US = (float)(180/0xFFFF * LS)</li></ul> <p><u>To LS:</u></p> <ul style="list-style-type: none"><li>- LS = (uint16)round(0xFFFF/180 * US)</li></ul>			$ESD\_dec = \left( \frac{180}{65535} * LS\_uint \right)$ <p><u>To ESD:</u></p> <ul style="list-style-type: none"><li>- Convert LS to decimal.</li><li>- Convert decimal to ASCII.</li></ul> <p><u>To LS:</u></p> <ul style="list-style-type: none"><li>- Convert ESD ASCII to decimal.</li><li>- Map decimal to uint16.</li></ul>		

### 8.16.1 Example Sensor Horizontal Field of View

The field of view of a lens is defined as the angle over the focal plane where objects are recorded on a film or electro-optical sensor. Field of view is dependent upon the focal length of the lens, and the physical size of the sensor. Typical imaging devices have a square or rectangular imaging sensor. The image (or sequence of images) is typically captured as a square or rectangle and displayed to a user with image edges perpendicular to level sight.

The distance between left edge and right edge is represented as an angle in the horizontal field of view metadata item. Refer to Figure 8-6:



**Figure 8-6: Horizontal Field of View**

### 8.17 Tag 17: Sensor Vertical Field of View Conversion


LS Tag	17	Units	Range	Format	
LS Name	Sensor Vertical Field of View	Degrees	0..180	uint16	
US Mapped Key	06 0E 2B 34 01 01 01 07 04 20 02 01 01 0A 01 00 (CRC 30292)				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- Vertical field of view of selected imaging sensor.</li><li>- Map 0..(2^16-1) to 0..180.</li><li>- Resolution: ~2.7 milli degrees.</li><li>- Requires data conversion between LS value and SMPTE Mapped US Key.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{uint\_range} * LS\_uint \right)$ $LS\_17\_dec = \left( \frac{180}{65535} * LS\_17 \right)$			
Example Value		Example LS Packet			
152.6436 Degrees		[K][L][V] = [0d17][0d2][0xD9 17]			
US Key	x	ESD Digraph	Vv		
US Name	x	ESD Name	Vertical Field of View		
Units	Range	Format	Units	Range	Format
x	x	x	Degrees	0..180.00	DDD.HH
Notes		Notes			
<ul style="list-style-type: none"><li>- x</li></ul>		<ul style="list-style-type: none"><li>- Angle of view of the lens on the selected camera. Vertical across baseline of image, projected onto the terrain (flat terrain model at DTED or other best available elevation data).</li></ul>			
US Conversion		ESD Conversion			
x		$ESD\_dec = \left( \frac{180}{65535} * LS\_uint \right)$			
<u>To US:</u> <ul style="list-style-type: none"><li>- x</li></ul> <u>To LS:</u> <ul style="list-style-type: none"><li>- x</li></ul>		<u>To ESD:</u> <ul style="list-style-type: none"><li>- Convert LS to decimal.</li><li>- Convert decimal to ASCII.</li></ul> <u>To LS:</u> <ul style="list-style-type: none"><li>- Convert ESD ASCII to decimal.</li><li>- Map decimal to uint16.</li></ul>			

#### 8.17.1 Example Sensor Vertical Field of View

The field of view of a lens is defined as the angle over the focal plane where objects are recorded on a film or electro-optical sensor. Field of view is dependent upon the focal length of the lens, and the physical size of the sensor. Typical imaging devices have a square or rectangular imaging sensor. The image (or sequence of images) is typically captured as a square or rectangle and displayed to a user with image edges perpendicular to level sight.

The distance between top edge and bottom edge is represented as an angle in the vertical field of view metadata item. Refer to Figure 8-7:






**Figure 8-7: Vertical Field of View**

### 8.18 Tag 18: Sensor Relative Azimuth Angle Conversion

LS Tag	18	Units	Range	Format	
LS Name	Sensor Relative Azimuth Angle	Degrees	0..360	uint32	
US Mapped Key	06 0E 2B 34 01 01 01 01 0E 01 01 02 04 00 00 00 (CRC 944)				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- Relative rotation angle of sensor to platform longitudinal axis. Rotation angle between platform longitudinal axis and camera pointing direction as seen from above the platform.</li><li>- Map 0..(2^32-1) to 0..360.</li><li>- Resolution: ~84 nano degrees.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{uint\_range} * LS\_uint \right)$ $LS\_18\_dec = \left( \frac{360}{4294967295} * LS\_18 \right)$			
Example Value		Example LS Packet			
160.719211474396 Degrees		[K][L][V] = [0d18][0d4][0x72 4A 0A 20]			
US Key	x	ESD Digraph	Az		
US Name	x	ESD Name	Sensor Relative Azimuth Angle		
Units	Range	Format	Units	Range	Format
x	x	x	Degrees	0..359.99	DDD.HH
Notes		Notes			
<ul style="list-style-type: none"><li>- x</li></ul>		<ul style="list-style-type: none"><li>- Relative rotation angle of sensor to aircraft platform in azimuth. Rotation angle between aircraft fuselage chord and camera pointing direction as seen from above the platform.</li></ul>			
US Conversion		ESD Conversion			
<p style="text-align: center;">x</p> <p><u>To US:</u></p> <ul style="list-style-type: none"><li>- x</li></ul> <p><u>To LS:</u></p> <ul style="list-style-type: none"><li>- x</li></ul>		$ESD\_dec = \left( \frac{360}{4294967294} * LS\_int \right)$ <p><u>To ESD:</u></p> <ul style="list-style-type: none"><li>- Convert LS to decimal.</li><li>- Convert decimal to ASCII.</li></ul> <p><u>To LS:</u></p> <ul style="list-style-type: none"><li>- Convert ESD ASCII to decimal.</li><li>- Map decimal to uint32.</li></ul>			

#### 8.18.1 Example Sensor Relative Azimuth Angle

The relative rotation angle of the sensor is the angle formed between the platform longitudinal axis (line made by the fuselage) and the sensor pointing direction as measured in the plane formed by the platform longitudinal and transverse axis (line from wing tip to wing tip). Refer to Figure 8-8




**Figure 8-8: Relative Rotation Angle**

## 8.19 Tag 19: Sensor Relative Elevation Angle Conversion

LS Tag	19	Units	Range	Format	
LS Name	Sensor Relative Elevation Angle	Degrees	+/- 180	int32	
US Mapped Key	06 0E 2B 34 01 01 01 01 0E 01 01 02 05 00 00 00 (CRC 29956)				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- Relative Elevation Angle of sensor to platform longitudinal-transverse plane. Negative angles down.</li><li>- Map -(2^31-1)..(2^31-1) to +/-180.</li><li>- Use -(2^31) as an "error" indicator.</li><li>- -(2^31) = 0x80000000.</li><li>- Res: ~84 ndeg.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{int\_range} * LS\_int \right)$ $LS\_19\_dec = \left( \frac{360}{4294967294} * LS\_19 \right)$			
Example Value		Example LS Packet			
-168.792324833941 Degrees		[K][L][V] = [0d19][0d4][0x87 F8 4B 86]			
US Key	x	ESD Digraph	De		
US Name	x	ESD Name	Sensor Relative Elevation Angle		
Units	Range	Format	Units	Range	Format
x	x	x	Degrees	+/- 180.00	PDDD.HH
Notes		Notes			
<ul style="list-style-type: none"><li>- x</li></ul>		<ul style="list-style-type: none"><li>- Relative Elevation Angle of sensor to aircraft platform. Level flight with camera pointing forward is zero degrees. Negative angles down.</li></ul>			
US Conversion		ESD Conversion			
x		$ESD\_dec = \left( \frac{360}{4294967294} * LS\_int \right)$			
<u>To US:</u>		<u>To ESD:</u>			
<ul style="list-style-type: none"><li>- x</li></ul>		<ul style="list-style-type: none"><li>- Convert LS to decimal.</li><li>- Convert decimal to ASCII.</li></ul>			
<u>To LS:</u>		<u>To LS:</u>			
<ul style="list-style-type: none"><li>- x</li></ul>		<ul style="list-style-type: none"><li>- Convert ESD ASCII to decimal.</li><li>- Map decimal to uint32.</li></ul>			

### 8.19.1 Example Sensor Relative Elevation Angle

The relative elevation angle of the sensor to the aircraft is the downward (or upward) pointing angle of the sensor relative to the plane formed by the longitudinal axis (line made by the fuselage) and the transverse axis (line from wing tip to wing tip). Sensor pointing angles below the platform longitudinal-transverse plane are negative. Refer to Figure 8-9:



**Figure 8-9: Sensor Relative Elevation Angle**

Note that the int32 used in the LS value is encoded using two's complement.

## 8.20 Tag 20: Sensor Relative Roll Angle Conversion

LS Tag	20	Units	Range	Format	
LS Name	Sensor Relative Roll Angle	Degrees	0..360	uint32	
US Mapped Key	06 0E 2B 34 01 01 01 01 0E 01 01 02 06 00 00 00 (CRC 61144)				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- Relative roll angle of sensor to aircraft platform. Twisting angle of camera about lens axis. Top of image is zero degrees. Positive angles are clockwise when looking from behind camera.</li><li>- Map 0..(2^32-1) to 0..360.</li><li>- Resolution: ~84 nano degrees.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{uint\_range} * LS\_uint \right)$ $LS\_20\_dec = \left( \frac{360}{4294967295} * LS\_20 \right)$			
Example Value		Example LS Packet			
176.865437690572 Degrees		[K][L][V] = [0d20][0d4][0x7D C5 5E CE]			
US Key	x	ESD Digraph	Ro		
US Name	x	ESD Name	Sensor Relative Roll Angle		
Units	Range	Format	Units	Range	Format
x	x	x	Degrees	0..359.99	DDD.HH
Notes		Notes			
<ul style="list-style-type: none"><li>- x</li></ul>		<ul style="list-style-type: none"><li>- Relative roll angle of sensor to aircraft platform. Twisting angle of camera about lens axis. Top of image is zero degrees. Positive angles are clockwise when looking from behind camera.</li></ul>			
US Conversion		ESD Conversion			
x		$ESD\_dec = \left( \frac{360}{4294967294} * LS\_uint \right)$			
<u>To US:</u> <ul style="list-style-type: none"><li>- x</li></ul>		<u>To ESD:</u> <ul style="list-style-type: none"><li>- Convert LS to decimal.</li><li>- Convert decimal to ASCII.</li></ul>			
<u>To LS:</u> <ul style="list-style-type: none"><li>- x</li></ul>		<u>To LS:</u> <ul style="list-style-type: none"><li>- Convert ESD ASCII to decimal.</li><li>- Map decimal to uint32.</li></ul>			

### 8.20.1 Example Sensor Relative Roll Angle

Sensors that are able to rotate their camera about the lens axis make use of this sensor relative roll angle. A roll angle of zero degrees occurs when the top and bottom edges of the captured image lie perpendicular to the plane created by the sensor relative depression angle axis.

Positive angles are clockwise when looking from behind the camera.

## 8.21 Tag 21: Slant Range Conversion

LS Tag	21	Units		Range	Format
LS Name	Slant Range	Meters		0..5,000,000	uint32
US Mapped Key	Use EG 0104 US Key				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- Slant range in meters. Distance to target.</li><li>- Map 0..(2^32-1) to 0..5000000 meters.</li><li>- 1 nautical mile (knot) = 1852 meters.</li><li>- Resolution: ~1.2 milli meters.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{uint\_range} * LS\_uint \right)$ $LS\_dec = \left( \frac{5000000}{4294967295} * LS\_uint \right)$			
Example Value		Example LS Packet			
68590.98 Meters		[K][L][V] = [0d21][0d4][0x03 83 09 26]			
US Key	06 0E 2B 34 01 01 01 01 07 01 08 01 01 00 00 00 (CRC 16588)	ESD Digraph	Sr		
US Name	Slant Range	ESD Name	Slant Range		
Units	Range	Format	Units	Range	Format
Meters	Float	Float	Nautical Miles	0..18.00	II.HH
Notes		Notes			
<ul style="list-style-type: none"><li>- Distance from the sensor to the center point on ground of the framed subject (image) depicted in the captured essence, (default meters)</li></ul>		<ul style="list-style-type: none"><li>- Distance between the sensor and the target</li></ul>			
US Conversion		ESD Conversion			
$US\_dec = \left( \frac{5000000}{4294967295} * LS\_uint \right)$		$ESD\_dec = \left( \frac{5000000}{4294967295} * LS\_uint \right) * \frac{1852knot}{1m}$			
<u>To US:</u> <ul style="list-style-type: none"><li>- US = (float)(5000000/0xFFFFFFFF * LS)</li></ul>		<u>To ESD:</u> <ul style="list-style-type: none"><li>- Convert LS to decimal.</li><li>- Account for units.</li><li>- Convert knots to ASCII.</li></ul>			
<u>To LS:</u> <ul style="list-style-type: none"><li>- LS = (uint32)round(0xFFFFFFFF/5000000 * US)</li></ul>		<u>To LS:</u> <ul style="list-style-type: none"><li>- Convert ESD ASCII to decimal.</li><li>- Account for units.</li><li>- Convert feet to uint32.</li></ul>			

### 8.21.1 Example Sensor Slant Range

The slant range is the distance between the sensor and image center. Refer to Figure 8-10.




Figure 8-10: Sensor Slant Range

## ST 0601.10 UAS Datalink Local Set

As of ST 0601.3 Generic Flag Data 01 (Tag 47) contains a flag which indicates whether Slant Range is “Computed” or “Measured”. By default, the Slant Range is set to “Computed”. “Measured” is to be used when a ranging device (radar, or laser) is providing Slant Range estimates.




## 8.22 Tag 22: Target Width Conversion

LS Tag	22	Units	Range	Format	
LS Name	Target Width	Meters	0..10,000	uint16	
US Mapped Key	Use EG 0104 US Key				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- Target Width within sensor field of view.</li><li>- Map 0..(2^16-1) to 0..10000 meters.</li><li>- 1 meter = 3.2808399 feet.</li><li>- Resolution: ~.16 meters.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{uint\_range} * LS\_uint \right)$ $LS\_dec = \left( \frac{10000}{65535} * LS\_uint \right)$			
Example Value		Example LS Packet			
722.8199 Meters		[K] [L] [V] = [0d22] [0d2] [0x12 81]			
US Key	06 0E 2B 34 01 01 01 01 07 01 09 02 01 00 00 00 (CRC 60350)	ESD Digraph	Tw		
US Name	Target Width	ESD Name	Target Width		
Units	Range	Format	Units	Range	Format
Meters	0..10,000	Float	Feet	0..99,999	N
Notes			Notes		
<ul style="list-style-type: none"><li>- Horizontal half width of the target frame image; used to compute the four corner points of the frame, (default meters)</li></ul>			<ul style="list-style-type: none"><li>- Width of the EO/IR Payloads field of view on the ground</li></ul>		
US Conversion			ESD Conversion		
$US\_dec = \left( \frac{10000}{65535} * LS\_uint \right)$			$ESD\_dec = \left( \frac{10000}{65535} * LS\_uint \right) * \frac{3.2808399ft}{1m}$		
<u>To US:</u> <ul style="list-style-type: none"><li>- US = (float)(10000/0xFFFF * LS)</li></ul>			<u>To ESD:</u> <ul style="list-style-type: none"><li>- Convert LS to decimal.</li><li>- Account for units.</li><li>- Convert feet to ASCII.</li></ul>		
<u>To LS:</u> <ul style="list-style-type: none"><li>- LS = (uint16)round(0xFFFF/10000 * US)</li></ul>			<u>To LS:</u> <ul style="list-style-type: none"><li>- Convert ESD ASCII to decimal.</li><li>- Account for units.</li><li>- Convert meters to uint32.</li></ul>		

### 8.22.1 Example Sensor Target Width

*For legacy purposes, both distance-restricted (Tag 22) and distance-extended (Tag 96) representations of Target Width MAY appear in the same ST 0601 packet. A single representation is preferred, with the distance-extended version (Tag 96) being favored as per Section 6.3.*

The target width is the linear ground distance between the center of both sides of the captured image. Refer to Figure 8-11.



**Figure 8-11: Target Width**

Note: SMPTE periodically makes updates to its use of metadata keys and has made a change denoting Target Width as the half-width of the image. Despite this change in the SMPTE definition, the MISB continues to interpret Target Width for ST 0601 as full-width.

## 8.23 Tag 23: Frame Center Latitude Conversion

LS Tag	23	Units	Range	Format	
LS Name	Frame Center Latitude	Degrees	+/- 90	int32	
US Mapped Key	Use EG 0104 US Key				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- Terrain Latitude of frame center. Based on WGS84 ellipsoid.</li><li>- Map -(2^31-1)..(2^31-1) to +/-90.</li><li>- Use -(2^31) as an "error" indicator.</li><li>- -(2^31) = 0x80000000.</li><li>- Resolution: ~42 nano degrees.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{int\_range} * LS\_int \right)$ $LS\_23\_dec = \left( \frac{180}{4294967294} * LS\_23 \right)$			
Example Value		Example LS Packet			
-10.5423886331461 Degrees		[K][L][V] = [0d23][0d4][0xF1 01 A2 29]			
US Key	06 0E 2B 34 01 01 01 01 07 01 02 01 03 02 00 00 (CRC 17862)	ESD Digraph	Ta		
US Name	Frame Center Latitude	ESD Name	Target Latitude		
Units	Range	Format	Units	Range	Format
Degrees	+/- 90	Double	Degrees	+/- 90.00	PDDMMSSST
Notes		Notes			
<ul style="list-style-type: none"><li>- Specifies the video frame center point geographic location in decimal degrees of latitude.</li><li>- Positive values indicate northern hemisphere.</li><li>- Negative values indicate southern Hemisphere.</li></ul>		<ul style="list-style-type: none"><li>- Latitude of the EO/IR payload's aimpoint on the ground. + Means North lattitude. All latitude coordinates use WGS84.</li></ul>			
US Conversion		ESD Conversion			
$US\_dec = \left( \frac{180}{4294967294} * LS\_int \right)$ <p><u>To US:</u></p> <ul style="list-style-type: none"><li>- US = (double)(180/0xFFFFFFFF * LS)</li></ul> <p><u>To LS:</u></p> <ul style="list-style-type: none"><li>- LS = (int32)round(0xFFFFFFFF/180 * US)</li></ul>		$ESD\_dec = \left( \frac{180}{4294967294} * LS\_int \right)$ <p><u>To ESD:</u></p> <ul style="list-style-type: none"><li>- Convert LS to decimal.</li><li>- Convert decimal to ASCII.</li></ul> <p><u>To LS:</u></p> <ul style="list-style-type: none"><li>- Convert ASCII to decimal.</li><li>- Map decimal to int32.</li></ul>			

### 8.23.1 Example Frame Center Latitude

The center of the captured image or image sequence has a real earth coordinate represented by a latitude-longitude-altitude triplet. Frame centers that lie above the horizon typically do not correspond to a point on the earth (an example being the tracking of an airborne object) and should either not be reported, or be reported as an "error".

Note that the int32 used in the LS value is encoded using two's complement.

## 8.24 Tag 24: Frame Center Longitude Conversion

LS Tag	24	Units	Range	Format	
LS Name	Frame Center Longitude	Degrees	+/- 180	int32	
US Mapped Key	Use EG 0104 US Key				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- Terrain Longitude of frame center. Based on WGS84 ellipsoid.</li><li>- Map -(2^31-1)..(2^31-1) to +/-180.</li><li>- Use -(2^31) as an "error" indicator.</li><li>- -(2^31) = 0x80000000.</li><li>- Resolution: ~84 nano degrees.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{int\_range} * LS\_int \right)$ $LS\_24\_dec = \left( \frac{360}{4294967294} * LS\_24 \right)$			
Example Value		Example LS Packet			
29.157890122923 Degrees		[K][L][V] = [0d24][0d4][0x14 BC 08 2B]			
US Key	06 0E 2B 34 01 01 01 01 07 01 02 01 03 04 00 00 (CRC 63334)	ESD Digraph	To		
US Name	Frame Center Longitude	ESD Name	Target Longitude		
Units	Range	Format	Units	Range	Format
Degrees	+/- 180	Double	Degrees	+/- 180.00	PDDMMSSST
Notes		Notes			
<ul style="list-style-type: none"><li>- Specifies the video frame center point geographic location in decimal degrees of longitude.</li><li>- Positive values indicate eastern hemisphere.</li><li>- Negative values indicate western Hemisphere.</li></ul>		<ul style="list-style-type: none"><li>- Longitude of the EO/IR payload's aimpoint on the ground. + Means East longitude. All longitude coordinates use WGS84.</li></ul>			
US Conversion		ESD Conversion			
$US\_dec = \left( \frac{360}{4294967294} * LS\_int \right)$ <p><u>To US:</u></p> <ul style="list-style-type: none"><li>- US = (double)(360/0xFFFFFFFF * LS)</li></ul> <p><u>To LS:</u></p> <ul style="list-style-type: none"><li>- LS = (int32)round(0xFFFFFFFF/360 * US)</li></ul>		$ESD\_dec = \left( \frac{360}{4294967294} * LS\_int \right)$ <p><u>To ESD:</u></p> <ul style="list-style-type: none"><li>- Convert LS to decimal.</li><li>- Convert decimal to ASCII.</li></ul> <p><u>To LS:</u></p> <ul style="list-style-type: none"><li>- Convert ASCII to decimal.</li><li>- Map decimal to int32.</li></ul>			

### 8.24.1 Example Frame Center Longitude

The center of the captured image or image sequence has a real earth coordinate represented by a latitude-longitude-altitude triplet. Frame centers that lie above the horizon typically do not correspond to a point on the earth (an example being the tracking of an airborne object) and should either not be reported, or be reported as an "error".

Note that the int32 used in the LS value is encoded using two's complement.

## 8.25 Tag 25: Frame Center Elevation Conversion

LS Tag	25	Units	Range	Format	
LS Name	Frame Center Elevation	Meters	-900..19000	uint16	
US Mapped Key	06 0E 2B 34 01 01 01 0A 07 01 02 01 03 16 00 00 (CRC 57054)				
Notes		Conversion Formula			
- Terrain elevation at frame center relative to Mean Sea Level (MSL). - Map 0..(2^16-1) to -900..19000 meters. - Resolution: ~0.3 meters.		$LS\_dec = \left( \frac{LS\_range}{uint\_range} * LS\_uint \right) - Offset$ $LS\_25\_dec = \left( \frac{19900}{65535} * LS\_25 \right) - 900$			
Example Value		Example LS Packet			
3216.037 Meters		[K] [L] [V] = [0d25] [0d2] [0x34 F3]			
US Key	x	ESD Digraph	Te		
US Name	x	ESD Name	Frame Center Elevation		
Units	Range	Format	Units	Range	Format
x	x	x	Feet	+/- 0..99,999	PN
Notes		Notes			
- x		- Terrain elevation at frame center			
US Conversion		ESD Conversion			
x		$ESD\_dec = \left( \frac{19900}{65535} * LS\_uint - 900 \right) * \frac{3.2808399ft}{1m}$			
<u>To US:</u> - x		<u>To ESD:</u> - Convert LS to decimal. - Account for units. - Convert decimal to ASCII.			
<u>To LS:</u> - x		<u>To LS:</u> - Convert ESD ASCII to decimal. - Account for units. - Map decimal to uint16.			

### 8.25.1 Example Frame Center Elevation

*For legacy purposes, both MSL (Tag 25) and HAE (Tag 78) representations of Frame Center Elevation MAY appear in the same ST 0601 packet. A single representation is preferred favoring the HAE version (Tag 78).*

The center of the captured image or image sequence has a real earth coordinate represented by a latitude-longitude-altitude triplet. Frame centers that lie above the horizon typically do not correspond to a point on the earth (an example being the tracking of an airborne object) and should either not be reported, or be reported as an “error”.

The altitude is represented as height above mean sea level (MSL).


## 8.26 Tag 26: Offset Corner Latitude Point 1 Conversion

LS Tag	26	Units	Range	Format	
LS Name	Offset Corner Latitude Point 1	Degrees	+/-0.075	int16	
US Mapped Key	Use EG 0104 US Key				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- Frame Latitude, offset for upper left corner. Based on WGS84 ellipsoid.</li><li>- Use with Frame Center Latitude.</li><li>- Map -(2^15-1)..(2^15-1) to +/-0.075.</li><li>- Use -(2^15) as an "error" indicator.</li><li>- -(2^15) = 0x8000.</li><li>- Resolution: ~1.2micro deg, ~0.25meters at equator.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{int\_range} * LS\_int \right) + LS\_23\_dec$ $LS\_26\_dec = \left( \frac{0.15}{65534} * LS\_26 \right) + LS\_23\_dec$			
Example Value		Example LS Packet			
-10.579637999887 Corrected Degrees		[K][L][V] = [0d26][0d2][0xC0 6E]			
US Key	06 0E 2B 34 01 01 01 03 07 01 02 01 03 07 01 00 (CRC 23392)	ESD Digraph	Rg		
US Name	Corner Latitude Point 1 (Decimal Degrees)	ESD Name	SAR Latitude 4		
Units	Range	Format	Units	Range	Format
Degrees	+/- 90	Double	Degrees	+/- 90.00	PDDMMSSST
Notes			Notes		
<ul style="list-style-type: none"><li>- Latitude coordinate of corner 1 of an image or bounding rectangle.</li><li>- Positive (+) is northern hemisphere.</li><li>- Negative (-) is southern hemisphere.</li></ul>			<ul style="list-style-type: none"><li>- The latitude of the upper left corner of the SAR image box</li></ul>		
US Conversion			ESD Conversion		
$US\_dec = \left( \frac{0.15}{65534} * LS\_int \right) + LS\_23\_dec$ <p><u>To US:</u></p> <ul style="list-style-type: none"><li>- US = (double)((0.15/0xFFFFE * LS) + LS_23_dec)</li></ul> <p><u>To LS:</u></p> <ul style="list-style-type: none"><li>- LS = (int16)round(0xFFFFE/0.15 * (US - Frame_Center_LAT))</li></ul>			$ESD\_dec = \left( \frac{0.15}{65534} * LS\_int \right) + LS\_23\_dec$ <p><u>To ESD:</u></p> <ul style="list-style-type: none"><li>- Convert LS to decimal.</li><li>- Convert decimal to ASCII.</li></ul> <p><u>To LS:</u></p> <ul style="list-style-type: none"><li>- Convert ASCII to decimal.</li><li>- Map decimal to int16.</li></ul>		

### 8.26.1 Example Corner Latitude Point 1

The corner points of the captured image or image sequence have a real earth coordinate represented by a latitude-longitude pair (Figure 8-12). Corner points that lie above the horizon typically do not correspond to a point on the earth, or corner points lying outside of the mapped range should either not be reported, or be reported as an "error".

Corner point 1 is the upper left corner of the captured image as highlighted in red.



**Figure 8-12: Offset Corner Point 1**

The Offset Corner Latitude Point 1 is added to the Frame Center Latitude metadata item to determine the Latitude of the first corner point of a motion image. Both KLV data items must be converted to decimal prior to addition to determine the actual measured or calculated Motion Imagery corner point. Value is encoded using two's complement.

## 8.27 Tag 27: Offset Corner Longitude Point 1 Conversion

LS Tag	27	Units	Range	Format	
LS Name	Offset Corner Longitude Point 1	Degrees	+/-0.075	int16	
US Mapped Key	Use EG 0104 US Key				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- Frame Longitude, offset for upper left corner. Based on WGS84 ellipsoid.</li><li>- Use with Frame Center Longitude.</li><li>- Map -(2^15-1)..(2^15-1) to +/-0.075.</li><li>- Use -(2^15) as an "error" indicator.</li><li>- -(2^15) = 0x8000.</li><li>- Resolution: ~1.2micro deg, ~0.25meters at equator.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{int\_range} * LS\_int \right) + LS\_24\_dec$ $LS\_27\_dec = \left( \frac{0.15}{65534} * LS\_27 \right) + LS\_24\_dec$			
Example Value		Example LS Packet			
29.1273677986333 Corrected Degrees		[K][L][V] = [0d27][0d2][0xCB E9]			
US Key	06 0E 2B 34 01 01 01 03 07 01 02 01 03 0B 01 00 (CRC 11777)	ESD Digraph	Rh		
US Name	Corner Longitude Point 1 (Decimal Degrees)	ESD Name	SAR Longitude 4		
Units	Range	Format	Units	Range	Format
Degrees	+/- 180	Double	Degrees	+/- 180.00	PDDMMSSST
Notes			Notes		
<ul style="list-style-type: none"><li>- Longitude coordinate of corner 1 of an image or bounding rectangle.</li><li>- Positive (+) is eastern hemisphere.</li><li>- Negative (-) is western hemisphere.</li></ul>			<ul style="list-style-type: none"><li>- The longitude of the upper left corner of the SAR image box</li></ul>		
US Conversion			ESD Conversion		
$US\_dec = \left( \frac{0.15}{65534} * LS\_int \right) + LS\_24\_dec$ <p><u>To US:</u></p> <ul style="list-style-type: none"><li>- US = (double)((0.15/0xFFFFE * LS) + LS_24_dec)</li></ul> <p><u>To LS:</u></p> <ul style="list-style-type: none"><li>- LS = (int16)round(0xFFFFE/0.15 * (US - Frame Center LON))</li></ul>			$ESD\_dec = \left( \frac{0.15}{65534} * LS\_int \right) + LS\_24\_dec$ <p><u>To ESD:</u></p> <ul style="list-style-type: none"><li>- Convert LS to decimal.</li><li>- Convert decimal to ASCII.</li></ul> <p><u>To LS:</u></p> <ul style="list-style-type: none"><li>- Convert ASCII to decimal.</li><li>- Map decimal to int16.</li></ul>		

### 8.27.1 Example Corner Longitude Point 1

The corner points of the captured image or image sequence have a real earth coordinate represented by a latitude-longitude pair. Corner points that lie above the horizon typically do not correspond to a point on the earth, or corner points lying outside of the mapped range, should either not be reported, or be reported as an "error".

Corner point 1 is the upper left corner of the captured image. See Figure 8-12 for Tag 26 above.

The Offset Corner Longitude Point 1 is added to the Frame Center Longitude metadata item to determine the Longitude of the first corner point of a motion image. Both KLV data items must be converted to decimal prior to addition to determine the actual measured or calculated Motion Imagery corner point. Value is encoded using two's complement.




## 8.28 Tag 28: Offset Corner Latitude Point 2 Conversion

LS Tag	28	Units	Range	Format	
LS Name	Offset Corner Latitude Point 2	Degrees	+/-0.075	int16	
US Mapped Key	Use EG 0104 US Key				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- Frame Latitude, offset for upper right corner. Based on WGS84 ellipsoid.</li><li>- Use with Frame Center Latitude.</li><li>- Map -(2^15-1)..(2^15-1) to +/-0.075.</li><li>- Use -(2^15) as an "error" indicator.</li><li>- -(2^15) = 0x8000.</li><li>- Resolution: ~1.2micro deg, ~0.25meters at equator.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{int\_range} * LS\_int \right) + LS\_23\_dec$ $LS\_28\_dec = \left( \frac{0.15}{65534} * LS\_28 \right) + LS\_23\_dec$			
Example Value		Example LS Packet			
-10.5661816260963 Corrected Degrees		[K] [L] [V] = [0d28][0d2][0xD7 65]			
US Key	06 0E 2B 34 01 01 01 03 07 01 02 01 03 08 01 00 (CRC 30545)	ESD Digraph	Ra		
US Name	Corner Latitude Point 2 (Decimal Degrees)	ESD Name	SAR Latitude 1		
Units	Range	Format	Units	Range	Format
Degrees	+/- 90	Double	Degrees	+/- 90.00	PDDMMSSST
Notes			Notes		
<ul style="list-style-type: none"><li>- Latitude coordinate of corner 2 of an image or bounding rectangle.</li><li>- Positive (+) is northern hemisphere.</li><li>- Negative (-) is southern hemisphere.</li></ul>			<ul style="list-style-type: none"><li>- The latitude of the upper right corner of the SAR image box</li></ul>		
US Conversion			ESD Conversion		
$US\_dec = \left( \frac{0.15}{65534} * LS\_int \right) + LS\_23\_dec$ <p><u>To US:</u></p> <ul style="list-style-type: none"><li>- US = (double)((0.15/0xFFFFE * LS) + LS_23_dec)</li></ul> <p><u>To LS:</u></p> <ul style="list-style-type: none"><li>- LS = (int16)round(0xFFFFE/0.15 * (US - Frame Center LAT))</li></ul>			$ESD\_dec = \left( \frac{0.15}{65534} * LS\_int \right) + LS\_23\_dec$ <p><u>To ESD:</u></p> <ul style="list-style-type: none"><li>- Convert LS to decimal.</li><li>- Convert decimal to ASCII.</li></ul> <p><u>To LS:</u></p> <ul style="list-style-type: none"><li>- Convert ASCII to decimal.</li><li>- Map decimal to int16.</li></ul>		

### 8.28.1 Example Corner Latitude Point 2

The corner points of the captured image or image sequence have a real earth coordinate represented by a latitude-longitude pair. Corner points that lie above the horizon typically do not correspond to a point on the earth, or corner points lying outside of the mapped range, should either not be reported, or be reported as an "error".

Corner point 2 is the upper right corner of the captured image as highlighted in red (Figure 8-13).



**Figure 8-13: Offset Corner Point 2**

The Offset Corner Latitude Point 2 is added to the Frame Center Latitude metadata item to determine the Latitude of the second corner point of a motion image. Both KLV data items must be converted to decimal prior to addition to determine the actual measured or calculated Motion Imagery corner point. Value is encoded using two's complement.

## 8.29 Tag 29: Offset Corner Longitude Point 2 Conversion

LS Tag	29	Units	Range	Format	
LS Name	Offset Corner Longitude Point 2	Degrees	+/-0.075	int16	
US Mapped Key	Use EG 0104 US Key				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- Frame Longitude, offset for upper right corner. Based on WGS84 ellipsoid.</li><li>- Use with Frame Center Longitude.</li><li>- Map -(2^15-1)..(2^15-1) to +/-0.075.</li><li>- Use -(2^15) as an "error" indicator.</li><li>- -(2^15) = 0x8000.</li><li>- Resolution: ~1.2micro deg, ~0.25meters at equator.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{int\_range} * LS\_int \right) + LS\_24\_dec$ $LS\_29\_dec = \left( \frac{0.15}{65534} * LS\_29 \right) + LS\_24\_dec$			
Example Value		Example LS Packet			
29.140824172424 Corrected Degrees		[K][L][V] = [0d29][0d2][0xE2 E0]			
US Key	06 0E 2B 34 01 01 01 03 07 01 02 01 03 0C 01 00 (CRC 43921)	ESD Digraph	Rb		
US Name	Corner Longitude Point 2 (Decimal Degrees)	ESD Name	SAR Longitude 1		
Units	Range	Format	Units	Range	Format
Degrees	+/- 180	Double	Degrees	+/- 180.00	PDDMMSSST
Notes			Notes		
<ul style="list-style-type: none"><li>- Longitude coordinate of corner 2 of an image or bounding rectangle.</li><li>- Positive (+) is eastern hemisphere.</li><li>- Negative (-) is western hemisphere.</li></ul>			<ul style="list-style-type: none"><li>- The longitude of the upper right corner of the SAR image box</li></ul>		
US Conversion			ESD Conversion		
$US\_dec = \left( \frac{0.15}{65534} * LS\_int \right) + LS\_24\_dec$ <p><u>To US:</u></p> <ul style="list-style-type: none"><li>- US = (double)((0.15/0xFFFE * LS) + LS_24_dec)</li></ul> <p><u>To LS:</u></p> <ul style="list-style-type: none"><li>- LS = (int16)round(0xFFFE/0.15 * (US - Frame Center LON))</li></ul>			$ESD\_dec = \left( \frac{0.15}{65534} * LS\_int \right) + LS\_24\_dec$ <p><u>To ESD:</u></p> <ul style="list-style-type: none"><li>- Convert LS to decimal.</li><li>- Convert decimal to ASCII.</li></ul> <p><u>To LS:</u></p> <ul style="list-style-type: none"><li>- Convert ASCII to decimal.</li><li>- Map decimal to int16.</li></ul>		

### 8.29.1 Example Corner Longitude Point 2

The corner points of the captured image or image sequence have a real earth coordinate represented by a latitude-longitude pair. Corner points that lie above the horizon typically do not correspond to a point on the earth, or corner points lying outside of the mapped range, should either not be reported, or be reported as an "error".

Corner point 2 is the upper right corner of the captured image. See Figure 8-13 for Tag 28 above.

The Offset Corner Longitude Point 2 is added to the Frame Center Longitude metadata item to determine the Longitude of the second corner point of a motion image. Both KLV data items must be converted to decimal prior to addition to determine the actual measured or calculated Motion Imagery corner point. Value is encoded using two's complement.


### 8.30 Tag 30: Offset Corner Latitude Point 3 Conversion

LS Tag	30	Units	Range	Format	
LS Name	Offset Corner Latitude Point 3	Degrees	+/-0.075	int16	
US Mapped Key	Use EG 0104 US Key				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- Frame Latitude, offset for lower right corner. Based on WGS84 ellipsoid.</li><li>- Use with Frame Center Latitude.</li><li>- Map -(2^15-1)..(2^15-1) to +/-0.075.</li><li>- Use -(2^15) as an "error" indicator.</li><li>- -(2^15) = 0x8000.</li><li>- Resolution: ~1.2micro deg, ~0.25meters at equator.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{int\_range} * LS\_int \right) + LS\_23\_dec$ $LS\_30\_dec = \left( \frac{0.15}{65534} * LS\_30 \right) + LS\_23\_dec$			
Example Value		Example LS Packet			
-10.5527275411938 Corrected Degrees		[K][L][V] = [0d30][0d2][0xEE 5B]			
US Key	06 0E 2B 34 01 01 01 03 07 01 02 01 03 09 01 00 (CRC 16481)	ESD Digraph	Rc		
US Name	Corner Latitude Point 3 (Decimal Degrees)	ESD Name	SAR Latitude 2		
Units	Range	Format	Units	Range	Format
Degrees	+/- 90	Double	Degrees	+/- 90.00	PDDMMSSST
Notes			Notes		
<ul style="list-style-type: none"><li>- Latitude coordinate of corner 3 of an image or bounding rectangle.</li><li>- Positive (+) is northern hemisphere.</li><li>- Negative (-) is southern hemisphere.</li></ul>			<ul style="list-style-type: none"><li>- The latitude of the lower right corner of the SAR image box</li></ul>		
US Conversion			ESD Conversion		
$US\_dec = \left( \frac{0.15}{65534} * LS\_int \right) + LS\_23\_dec$ <p><u>To US:</u></p> <ul style="list-style-type: none"><li>- US = (double)((0.15/0xFFFFE * LS) + LS_23_dec)</li></ul> <p><u>To LS:</u></p> <ul style="list-style-type: none"><li>- LS = (int16)round(0xFFFFE/0.15 * (US - Frame_Center_LAT))</li></ul>			$ESD\_dec = \left( \frac{0.15}{65534} * LS\_int \right) + LS\_23\_dec$ <p><u>To ESD:</u></p> <ul style="list-style-type: none"><li>- Convert LS to decimal.</li><li>- Convert decimal to ASCII.</li></ul> <p><u>To LS:</u></p> <ul style="list-style-type: none"><li>- Convert ASCII to decimal.</li><li>- Map decimal to int16.</li></ul>		

#### 8.30.1 Example Corner Latitude Point 3

The corner points of the captured image or image sequence have a real earth coordinate represented by a latitude-longitude pair. Corner points that lie above the horizon typically do not correspond to a point on the earth, or corner points lying outside of the mapped range, should either not be reported, or be reported as an "error".

Corner point 3 is the lower right corner of the captured image as highlighted in red (see Figure 8-14).



**Figure 8-14: Offset Corner Point 3**

The Offset Corner Latitude Point 3 is added to the Frame Center Latitude metadata item to determine the Latitude of the third corner point of a motion image. Both KLV data items must be converted to decimal prior to addition to determine the actual measured or calculated Motion Imagery corner point. Value is encoded using two's complement.

### 8.31 Tag 31: Offset Corner Longitude Point 3 Conversion

LS Tag	31	Units	Range	Format	
LS Name	Offset Corner Longitude Point 3	Degrees	+/-0.075	int16	
US Mapped Key	Use EG0104 US Key				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- Frame Longitude, offset for lower right corner. Based on WGS84 ellipsoid.</li><li>- Use with Frame Center Longitude.</li><li>- Map -(2^15-1)..(2^15-1) to +/-0.075.</li><li>- Use -(2^15) as an "error" indicator.</li><li>- -(2^15) = 0x8000.</li><li>- Resolution: ~1.2micro deg, ~0.25meters at equator.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{int\_range} * LS\_int \right) + LS\_24\_dec$ $LS\_31\_dec = \left( \frac{0.15}{65534} * LS\_31 \right) + LS\_24\_dec$			
Example Value		Example LS Packet			
29.1542782573265 Corrected Degrees		[K][L][V] = [0d31][0d2][0xF9 D6]			
US Key	06 0E 2B 34 01 01 01 03 07 01 02 01 03 0D 01 00 (CRC 40097)	ESD Digraph	Rd		
US Name	Corner Longitude Point 3 (Decimal Degrees)	ESD Name	SAR Longitude 2		
Units	Range	Format	Units	Range	Format
Degrees	+/- 180	Double	Degrees	+/- 180.00	PDDMMSSST
Notes			Notes		
<ul style="list-style-type: none"><li>- Longitude coordinate of corner 3 of an image or bounding rectangle.</li><li>- Positive (+) is eastern hemisphere.</li><li>- Negative (-) is western hemisphere.</li></ul>			<ul style="list-style-type: none"><li>- The longitude of the lower right corner of the SAR image box</li></ul>		
US Conversion			ESD Conversion		
$US\_dec = \left( \frac{0.15}{65534} * LS\_int \right) + LS\_24\_dec$ <p><u>To US:</u></p> <ul style="list-style-type: none"><li>- US = (double)((0.15/0xFFFF * LS) + LS_24_dec)</li></ul> <p><u>To LS:</u></p> <ul style="list-style-type: none"><li>- LS = (int16)round(0xFFFF/0.15 * (US - Frame Center LON))</li></ul>			$ESD\_dec = \left( \frac{0.15}{65534} * LS\_int \right) + LS\_24\_dec$ <p><u>To ESD:</u></p> <ul style="list-style-type: none"><li>- Convert LS to decimal.</li><li>- Convert decimal to ASCII.</li></ul> <p><u>To LS:</u></p> <ul style="list-style-type: none"><li>- Convert ASCII to decimal.</li><li>- Map decimal to int16.</li></ul>		

#### 8.31.1 Example Corner Longitude Point 3

The corner points of the captured image or image sequence have a real earth coordinate represented by a latitude-longitude pair. Corner points that lie above the horizon typically do not correspond to a point on the earth, or corner points lying outside of the mapped range, should either not be reported, or be reported as an "error".

Corner point 3 is the lower right corner of the captured image. See Figure 8-14 for Tag 30 above.

The Offset Corner Longitude Point 3 is added to the Frame Center Longitude metadata item to determine the Longitude of the third corner point of a motion image. Both KLV data items must be converted to decimal prior to addition to determine the actual measured or calculated Motion Imagery corner point. Value is encoded using two's complement.

### 8.32 Tag 32: Offset Corner Latitude Point 4 Conversion

LS Tag	32	Units	Range	Format	
LS Name	Offset Corner Latitude Point 4	Degrees	+/-0.075	int16	
US Mapped Key	Use EG0104 US Key				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- Frame Latitude, offset for lower left corner. Based on WGS84 ellipsoid.</li><li>- Use with Frame Center Latitude.</li><li>- Map -(2^15-1)..(2^15-1) to +/-0.075.</li><li>- Use -(2^15) as an "error" indicator.</li><li>- -(2^15) = 0x8000.</li><li>- Resolution: ~1.2micro deg, ~0.25meters at equator.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{int\_range} * LS\_int \right) + LS\_23\_dec$ $LS\_32\_dec = \left( \frac{0.15}{65534} * LS\_32 \right) + LS\_23\_dec$			
Example Value		Example LS Packet			
-10.5392711674031 Corrected Degrees		[K] [L] [V] = [0d32][0d2][0x05 52]			
US Key	06 0E 2B 34 01 01 01 03 07 01 02 01 03 0A 01 00 (CRC 6449)	ESD Digraph	Re		
US Name	Corner Latitude Point 4 (Decimal Degrees)	ESD Name	SAR Latitude 3		
Units	Range	Format	Units	Range	Format
Degrees	+/- 90	Double	Degrees	+/- 90.00	PDDMMSSST
Notes			Notes		
<ul style="list-style-type: none"><li>- Latitude coordinate of corner 4 of an image or bounding rectangle.</li><li>- Positive (+) is northern hemisphere.</li><li>- Negative (-) is southern hemisphere.</li></ul>			<ul style="list-style-type: none"><li>- The latitude of the lower left corner of the SAR image box</li></ul>		
US Conversion			ESD Conversion		
$US\_dec = \left( \frac{0.15}{65534} * LS\_int \right) + LS\_23\_dec$ <p><u>To US:</u></p> <ul style="list-style-type: none"><li>- US = (double)((0.15/0xFFFFE * LS) + LS_23_dec)</li></ul> <p><u>To LS:</u></p> <ul style="list-style-type: none"><li>- LS = (int16)round(0xFFFFE/0.15 * (US - Frame Center LAT))</li></ul>			$ESD\_dec = \left( \frac{0.15}{65534} * LS\_int \right) + LS\_23\_dec$ <p><u>To ESD:</u></p> <ul style="list-style-type: none"><li>- Convert LS to decimal.</li><li>- Convert decimal to ASCII.</li></ul> <p><u>To LS:</u></p> <ul style="list-style-type: none"><li>- Convert ASCII to decimal.</li><li>- Map decimal to int16.</li></ul>		

#### 8.32.1 Example Corner Latitude Point 4

The corner points of the captured image or image sequence have a real earth coordinate represented by a latitude-longitude pair. Corner points that lie above the horizon typically do not correspond to a point on the earth, or corner points lying outside of the mapped range, should either not be reported, or be reported as an "error".

Corner point 4 is the lower left corner of the captured image as highlighted in red (see Figure 8-15).

Both KLV data items must be measured or calculated Motion



### 8.33 Tag 33: Offset Corner Longitude Point 4 Conversion

LS Tag	33	Units	Range	Format	
LS Name	Offset Corner Longitude Point 4	Degrees	+/-0.075	int16	
US Mapped Key	Use EG0104 US Key				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- Frame Longitude, offset for lower left corner. Based on WGS84 ellipsoid.</li><li>- Use with Frame Center Longitude.</li><li>- Map -(2^15-1)..(2^15-1) to +/-0.075.</li><li>- Use -(2^15) as an "error" indicator.</li><li>- -(2^15) = 0x8000.</li><li>- Resolution: ~1.2micro deg, ~0.25meters at equator.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{int\_range} * LS\_int \right) + LS\_24\_dec$ $LS\_33\_dec = \left( \frac{0.15}{65534} * LS\_33 \right) + LS\_24\_dec$			
Example Value		Example LS Packet			
29.1677346311172 Corrected Degrees		[K][L][V] = [0d33][0d2][0x10 CD]			
US Key	06 0E 2B 34 01 01 01 03 07 01 02 01 03 0E 01 00 (CRC 50673)	ESD Digraph	Rf		
US Name	Corner Longitude Point 4 (Decimal Degrees)	ESD Name	SAR Longitude 3		
Units	Range	Format	Units	Range	Format
Degrees	+/- 180	Double	Degrees	+/- 180.00	PDDMMSSST
Notes			Notes		
<ul style="list-style-type: none"><li>- Longitude coordinate of corner 4 of an image or bounding rectangle.</li><li>- Positive (+) is eastern hemisphere.</li><li>- Negative (-) is western hemisphere.</li></ul>			<ul style="list-style-type: none"><li>- The longitude of the lower left corner of the SAR image box</li></ul>		
US Conversion			ESD Conversion		
$US\_dec = \left( \frac{0.15}{65534} * LS\_int \right) + LS\_24\_dec$ <p><u>To US:</u></p> <ul style="list-style-type: none"><li>- US = (double)((0.15/0xFFFE * LS) + LS_24_dec)</li></ul> <p><u>To LS:</u></p> <ul style="list-style-type: none"><li>- LS = (int16)round(0xFFFE/0.15 * (US - Frame Center LON))</li></ul>			$ESD\_dec = \left( \frac{0.15}{65534} * LS\_int \right) + LS\_24\_dec$ <p><u>To ESD:</u></p> <ul style="list-style-type: none"><li>- Convert LS to decimal.</li><li>- Convert decimal to ASCII.</li></ul> <p><u>To LS:</u></p> <ul style="list-style-type: none"><li>- Convert ASCII to decimal.</li><li>- Map decimal to int16.</li></ul>		

#### 8.33.1 Example Corner Longitude Point 4

The corner points of the captured image or image sequence have a real earth coordinate represented by a latitude-longitude pair. Corner points that lie above the horizon typically do not correspond to a point on the earth, or corner points lying outside of the mapped range, should either not be reported, or be reported as an "error".

Corner point 4 is the lower left corner of the captured image. See Figure 8-15 for Key 32 above.

The Offset Corner Longitude Point 4 is added to the Frame Center Longitude metadata item to determine the Longitude of the fourth corner point of a motion image. Both KLV data items must be converted to decimal prior to addition to determine the actual measured or calculated Motion Imagery corner point. Value is encoded using two's complement.

### 8.34 Tag 34: Icing Detected Conversion

LS Tag	34	Units		Range	Format
LS Name	Icing Detected	Icing Code		0..255	uint8
US Mapped Key	06 0E 2B 34 01 01 01 01 0E 01 01 01 0C 00 00 00 (CRC 26785)				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- Flag for icing detected at aircraft location.</li><li>- 0: Detector off</li><li>- 1: No icing Detected</li><li>- 2: Icing Detected</li></ul>		<div>x</div> <div>x</div>			
Example Value		Example LS Packet			
Invalid Icing Code		[K] [L] [V] = [0d34] [0d1] [0x9B]			
US Key	x	ESD Digraph	Id		
US Name	x	ESD Name	Icing Detected		
Units	Range	Format	Units	Range	Format
x	x	x	Icing Code	0..2	N
Notes		Notes			
<ul style="list-style-type: none"><li>- x</li></ul>		<ul style="list-style-type: none"><li>- Output of the aircrafts icing detector:</li><li>- 0: Detector off</li><li>- 1: No icing detected</li><li>- 2: Icing detected</li></ul>			
US Conversion		ESD Conversion			
x		x			
<u>To US:</u> <ul style="list-style-type: none"><li>- x</li></ul>		<u>To ESD:</u> <ul style="list-style-type: none"><li>- Convert string to ID code.</li></ul>			
<u>To LS:</u> <ul style="list-style-type: none"><li>- x</li></ul>		<u>To LS:</u> <ul style="list-style-type: none"><li>- Convert ID code to string.</li></ul>			

#### 8.34.1 Example Icing Detected

This metadata item signals when the icing sensor detects water forming on its vibrating probe.

### 8.35 Tag 35: Wind Direction Conversion

LS Tag	35	Units	Range	Format	
LS Name	Wind Direction	Degrees	0..360	uint16	
US Mapped Key	06 0E 2B 34 01 01 01 01 0E 01 01 01 0D 00 00 00 (CRC 7701)				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- Wind direction at aircraft location. This is the direction the wind is coming from relative to true north.</li><li>- Map 0..(2^16-1) to 0..360.</li><li>- Resolution: ~5.5 milli degrees.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{uint\_range} * LS\_uint \right)$ $LS\_35\_dec = \left( \frac{360}{65535} * LS\_35 \right)$			
Example Value		Example LS Packet			
235.924 Degrees		[K][L][V] = [0d35][0d2][0xA7 C4]			
US Key	x	ESD Digraph	Wd		
US Name	x	ESD Name	Wind Direction		
Units	Range	Format	Units	Range	Format
x	x	x	Degrees	0..359	DDD
Notes			Notes		
<ul style="list-style-type: none"><li>- x</li></ul>			<ul style="list-style-type: none"><li>- Direction (from North) from which the wind is blowing at the aircraft location</li></ul>		
US Conversion			ESD Conversion		
x			$ESD\_dec = \left( \frac{360}{65534} * LS\_uint \right)$		
<u>To US:</u> <ul style="list-style-type: none"><li>- x</li></ul>			<u>To ESD:</u> <ul style="list-style-type: none"><li>- Convert LS to decimal.</li><li>- Convert decimal to ASCII.</li></ul>		
<u>To LS:</u> <ul style="list-style-type: none"><li>- x</li></ul>			<u>To LS:</u> <ul style="list-style-type: none"><li>- Convert ESD ASCII to decimal.</li><li>- Map decimal to uint16.</li></ul>		

#### 8.35.1 Example Wind Direction

The direction the air body around the aircraft is coming from relative to true north.

### 8.36 Tag 36: Wind Speed Conversion

LS Tag		36	Units		Range	Format
LS Name		Wind Speed	Meters /Second		0..100	uint8
US Mapped Key		06 0E 2B 34 01 01 01 01 0E 01 01 01 0E 00 00 00 (CRC 34249)				
Notes			Conversion Formula			
<ul style="list-style-type: none"><li>- Wind speed at aircraft location.</li><li>- Map 0..255 to 0..100 meters/second.</li><li>- 1 m/s = 1.94384449 knots.</li><li>- Resolution: ~0.4 meters/second.</li></ul>			$LS\_dec = \left( \frac{LS\_range}{uint\_range} * LS\_uint \right)$ $LS\_36\_dec = \left( \frac{100}{255} * LS\_36 \right)$			
Example Value		Example LS Packet				
69.80392 m/s		[K][L][V] = [0d36][0d1][0xB2]				
US Key	x		ESD Digraph	Ws		
US Name	x		ESD Name	Wind Speed		
Units		Range	Format			
x		x	x			
Notes			Notes			
<ul style="list-style-type: none"><li>- x</li></ul>			<ul style="list-style-type: none"><li>- Wind Speed (relative to the Earth) at the aircraft location</li></ul>			
US Conversion			ESD Conversion			
x			$ESD\_dec = \left( \frac{100}{255} * LS\_uint \right) * \frac{1.94384449 \text{knots}}{1 \text{m/s}}$			
<u>To US:</u> <ul style="list-style-type: none"><li>- x</li></ul>			<u>To ESD:</u> <ul style="list-style-type: none"><li>- Convert LS to decimal.</li><li>- Account for units.</li><li>- Convert knots to ASCII.</li></ul>			
<u>To LS:</u> <ul style="list-style-type: none"><li>- x</li></ul>			<u>To LS:</u> <ul style="list-style-type: none"><li>- Convert ESD ASCII to decimal.</li><li>- Account for units.</li><li>- Convert meters to uint8.</li></ul>			

#### 8.36.1 Example Wind Speed

The speed of the body of air that surrounds the aircraft relative to the ground is captured in this wind speed metadata item.

### 8.37 Tag 37: Static Pressure Conversion

LS Tag		37	Units		Range	Format	
LS Name		Static Pressure	Millibar		0..5000	uint16	
US Mapped Key		06 0E 2B 34 01 01 01 01 0E 01 01 01 0F 00 00 00 (CRC 62333)					
Notes			Conversion Formula				
<ul style="list-style-type: none"><li>- Static pressure at aircraft location.</li><li>- Map 0..(2^16-1) to 0..5000 mbar.</li><li>- 1 mbar = 0.0145037738 PSI.</li><li>- Resolution: ~0.08 Millibar</li></ul>			$LS\_dec = \left( \frac{LS\_range}{uint\_range} * LS\_uint \right)$ $LS\_37\_dec = \left( \frac{5000}{65535} * LS\_37 \right)$				
Example Value		Example LS Packet					
3725.185 mbar		[K] [L] [V] = [0d37] [0d2] [0xBE BA]					
US Key	x		ESD Digraph	Ps			
US Name	x		ESD Name	Static Pressure			
Units		Range	Format		Units	Range	Format
x		x	x		PSI	0..99.99	DD.HH
Notes			Notes				
<ul style="list-style-type: none"><li>- x</li></ul>			<ul style="list-style-type: none"><li>- Static Pressure</li></ul>				
US Conversion			ESD Conversion				
x			$ESD\_dec = \left( \frac{5000}{65535} * LS\_uint \right) * \frac{0.0145037738 PSI}{1mbar}$				
<u>To US:</u> <ul style="list-style-type: none"><li>- x</li></ul>			<u>To ESD:</u> <ul style="list-style-type: none"><li>- Convert LS to decimal.</li><li>- Convert decimal to ASCII.</li></ul>				
<u>To LS:</u> <ul style="list-style-type: none"><li>- x</li></ul>			<u>To LS:</u> <ul style="list-style-type: none"><li>- Convert ESD ASCII to decimal.</li><li>- Map decimal to uint16.</li></ul>				

#### 8.37.1 Example Static Pressure

The static pressure is the pressure of the air that surrounds the aircraft. Static pressure is measured by a sensor mounted out of the air stream on the side of the fuselage. This is used with impact pressure to compute indicated airspeed, true airspeed, and density altitude.

### 8.38 Tag 38: Density Altitude Conversion

LS Tag	38	Units	Range	Format	
LS Name	Density Altitude	Meters	-900..19000	uint16	
US Mapped Key	06 0E 2B 34 01 01 01 01 0E 01 01 01 10 00 00 00 (CRC 15412)				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- Density altitude at aircraft location. Relative aircraft performance metric based on outside air temperature, static pressure, and humidity.</li><li>- Map 0..(2^16-1) to -900..19000 meters.</li><li>- Offset = -900.</li><li>- 1 meter = 3.2808399 feet.</li><li>- Resolution: ~0.3 meters.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{uint\_range} * LS\_uint \right) - Offset$ $LS\_38\_dec = \left( \frac{19900}{65535} * LS\_38 \right) - 900$			
Example Value		Example LS Packet			
14818.68 Meters		[K][L][V] = [0d38][0d2][0xCA 35]			
US Key	x	ESD Digraph	Da		
US Name	x	ESD Name	Density Altitude		
Units	Range	Format	Units	Range	Format
x	x	x	Feet	+/- 99,999	PN
Notes		Notes			
<ul style="list-style-type: none"><li>- x</li></ul>		<ul style="list-style-type: none"><li>- Density Altitude of the aircraft</li></ul>			
US Conversion		ESD Conversion			
<p style="text-align: center;">x</p> <p><u>To US:</u></p> <ul style="list-style-type: none"><li>- x</li></ul> <p><u>To LS:</u></p> <ul style="list-style-type: none"><li>- x</li></ul>		$ESD\_dec = \left( \frac{19900}{65535} * LS\_uint - 900 \right) * \frac{3.2808399ft}{1m}$ <p><u>To ESD:</u></p> <ul style="list-style-type: none"><li>- Convert LS to decimal.</li><li>- Account for units.</li><li>- Convert decimal to ASCII.</li></ul> <p><u>To LS:</u></p> <ul style="list-style-type: none"><li>- Convert ESD ASCII to decimal.</li><li>- Account for units.</li><li>- Map decimal to uint16.</li></ul>			

#### 8.38.1 Example Density Altitude

Density altitude is the pressure altitude corrected for non-standard temperature variation. Density altitude is a relative metric of the takeoff, climb, and other performance related parameters of an aircraft.

### 8.39 Tag 39: Outside Air Temperature Conversion

LS Tag	39	Units	Range	Format	
LS Name	Outside Air Temperature	Celsius	-128..+127	int8	
US Mapped Key	06 0E 2B 34 01 01 01 01 0E 01 01 01 11 00 00 00 (CRC 19072)				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- Temperature outside of aircraft.</li><li>- -128..127 Degrees Celsius.</li><li>- Resolution: 1 degree celsius.</li></ul>		LS_dec = LS_int LS_39_dec = LS_39			
Example Value		Example LS Packet			
84 Celcius		[K] [L] [V] = [0d39] [0d1] [0x54]			
US Key	x	ESD Digraph	At		
US Name	x	ESD Name	Air Temperature		
Units	Range	Format	Units	Range	Format
x	x	x	Celsius	+/- 99	PDD
Notes		Notes			
<ul style="list-style-type: none"><li>- x</li></ul>		<ul style="list-style-type: none"><li>- Outside air temperature measured at the aircraft</li></ul>			
US Conversion		ESD Conversion			
x		ESD_dec = LS_int			
<u>To US:</u>		<u>To ESD:</u>			
<ul style="list-style-type: none"><li>- x</li></ul>		<ul style="list-style-type: none"><li>- Convert int8 to string.</li></ul>			
<u>To LS:</u>		<u>To LS:</u>			
<ul style="list-style-type: none"><li>- x</li></ul>		<ul style="list-style-type: none"><li>- Convert string to int8.</li></ul>			

#### 8.39.1 Example Outside Air Temperature

The measured temperature outside of the platform is captured in the outside air temperature metadata item.

Note that the value is encoded using two's complement.

### 8.40 Tag 40: Target Location Latitude Conversion

LS Tag	40	Units	Range	Format
LS Name	Target Location Latitude	Degrees	+/- 90	int32
US Mapped Key	06 0E 2B 34 01 01 01 01 0E 01 01 03 02 00 00 00 (CRC 36472)			
Notes		Conversion Formula		
<ul style="list-style-type: none"> <li>- Calculated Target latitude. This is the crosshair location if different from frame center.</li> <li>- Based on WGS84 ellipsoid.</li> <li>- Map <math>-(2^{31}-1) \dots (2^{31}-1)</math> to <math>\pm 90</math>.</li> <li>- Use <math>-(2^{31})</math> as an "error" indicator.</li> <li>- <math>-(2^{31}) = 0x80000000</math>.</li> <li>- Resolution: ~42 nano degrees.</li> </ul>		$LS\_dec = \left( \frac{LS\_range}{int\_range} * LS\_int \right)$ $LS\_40\_dec = \left( \frac{180}{4294967294} * LS\_40 \right)$		
Example Value		Example LS Packet		
-79.1638500518929 Degrees		[K][L][V] = [0d40][0d4][0x8F 69 52 62]		

#### 8.40.1 Example Target Location Latitude

The crosshair or target location of a captured image or image sequence has a real earth coordinate represented by a latitude-longitude-elevation triplet and may differ from the center of the captured image. Target locations that lie above the horizon do not correspond to a point on the earth and should either not be reported, or be reported as an "error".

Note that the int32 used in the LS value is encoded using two's complement.



## 8.41 Tag 41: Target Location Longitude Conversion

LS Tag	41	Units	Range	Format
LS Name	Target Location Longitude	Degrees	+/-180	int32
US Mapped Key	06 0E 2B 34 01 01 01 01 0E 01 01 03 03 00 00 00 (CRC 63692)			
Notes		Conversion Formula		
<ul style="list-style-type: none"><li>- Calculated Target longitude. This is the crosshair location if different from frame center.</li><li>- Based on WGS84 ellipsoid.</li><li>- Map <math>-(2^{31}-1) \dots (2^{31}-1)</math> to +/-180.</li><li>- Use <math>-(2^{31})</math> as an "error" indicator.</li><li>- <math>-(2^{31}) = 0x80000000</math>.</li><li>- Resolution: ~84 nano degrees.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{int\_range} * LS\_int \right)$ $LS\_41\_dec = \left( \frac{360}{4294967294} * LS\_41 \right)$		
Example Value		Example LS Packet		
166.400812960416 Degrees		[K][L][V] = [0d41][0d4][0x76 54 57 F2]		

### 8.41.1 Example Target Location Longitude

The crosshair or target location of a captured image or image sequence has a real earth coordinate represented by a latitude-longitude-elevation triplet and may differ from the center of the captured image. Target locations that lie above the horizon do not correspond to a point on the earth and should either not be reported, or be reported as an "error".

Note that the int32 used in the LS value is encoded using two's complement.

**8.42 Tag 42: Target Location Elevation Conversion**

LS Tag	42	Units	Range	Format
LS Name	Target Location Elevation	Meters	-900..19000	uint16
US Mapped Key	06 0E 2B 34 01 01 01 01 0E 01 01 03 04 00 00 00 (CRC 43489)			
Notes		Conversion Formula		
<ul style="list-style-type: none"><li>- Calculated target elevation. This is the crosshair location if different from frame center.</li><li>- Map 0..(2^16-1) to -900..19000 meters.</li><li>- Offset = -900.</li><li>- 1 meter = 3.2808399 feet.</li><li>- Resolution: ~0.3 meters.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{uint\_range} * LS\_uint \right) - Offset$ $LS\_42\_dec = \left( \frac{19900}{65535} * LS\_42 \right) - 900$		
Example Value	Example LS Packet			
18389.05 Meters	[K][L][V] = [0d42][0d2][0xF8 23]			

**8.42.1 Example Target Location Elevation**

The crosshair or target location of a captured image or image sequence has a real earth coordinate represented by a latitude-longitude-elevation triplet and may differ from the center of the captured image. Target locations that lie above the horizon do not correspond to a point on the earth and should either not be reported, or be reported as an “error”.

**8.43 Tag 43: Target Track Gate Width Conversion**

LS Tag	43	Units	Range	Format
LS Name	Target Track Gate Width	Pixels	0..512	uint8
US Mapped Key	06 0E 2B 34 01 01 01 01 0E 01 01 03 05 00 00 00 (CRC 57173)			
Notes		Conversion Formula		
<ul style="list-style-type: none"><li>- Tracking gate width (x value) of tracked target within field of view.</li><li>- Closely tied to source video resolution in pixels.</li></ul>		$LS\_dec = 2 * LS\_uint$ $LS\_43\_dec = round(2 * LS\_43)$		
Example Value	Example LS Packet			
6 Pixels	[K] [L] [V] = [0d43] [0d1] [0x03]			

**8.43.1 Example Target Track Gate Width**

The target track gate width is used with Target Tracking Sensors that specify the pixel width of a tracking gate to be displayed about a target location.

### 8.44 Tag 44: Target Track Gate Height Conversion

LS Tag	44	Units	Range	Format
LS Name	Target Track Gate Height	Pixels	0..512	uint8
US Mapped Key	06 0E 2B 34 01 01 01 01 0E 01 01 03 06 00 00 00 (CRC 17545)			
Notes		Conversion Formula		
<ul style="list-style-type: none"><li>- Tracking gate height (y value) of tracked target within field of view.</li><li>- Closely tied to source video resolution in pixels.</li></ul>		<div>LS_dec = 2 * LS_uint</div> <div>LS_44_dec = round(2 * LS_44)</div>		
Example Value	Example LS Packet			
30 Pixels	[K] [L] [V] = [0d44] [0d1] [0x0F]			

#### 8.44.1 Example Target Track Gate Height

The target track gate height is used with Target Tracking Sensors that specify the pixel height of a tracking gate to be displayed about a target location.

### 8.45 Tag 45: Target Error Estimate - CE90 Conversion

LS Tag	45	Units	Meters	Range	0..4095	Format	uint16
LS Name	Target Error Estimate - CE90						
US Mapped Key	06 0E 2B 34 01 01 01 01 0E 01 01 03 07 00 00 00 (CRC 12861)						
Notes	<ul style="list-style-type: none"> <li>- Circular Error 90 (CE90) is the estimated error distance in the horizontal direction.</li> <li>- Specifies the radius of 90% probability on a plane tangent to the earth's surface.</li> <li>- Res: ~0.0624 meters</li> </ul>						<b>Conversion Formula</b>  $LS\_dec = \left( \frac{LS\_range}{uint\_range} * LS\_uint \right)$ $LS\_45\_dec = \left( \frac{4095}{65535} * LS\_45 \right)$
Example Value	425.319 Meters						<b>Example LS Packet</b> [K] [L] [V] = [0d45] [0d2] [0x1A 95]

#### 8.45.1 Example Target Error Estimate – Circular Error 90% (CE90)

Target covariance values are represented in an easting-northing-up coordinate system centered about the target point. This is shown below (refer to Figure 8-16):


**Covariance Matrix:**

$$Q = \begin{bmatrix} \sigma_e^2 & \sigma_{en} & \sigma_{eu} \\ \sigma_{ne} & \sigma_n^2 & \sigma_{nu} \\ \sigma_{ue} & \sigma_{un} & \sigma_u^2 \end{bmatrix}$$

**Min and Max Sigma Values:**

$$\sigma_{max}^2 = \frac{(\sigma_e^2 + \sigma_n^2) + \sqrt{(\sigma_e^2 + \sigma_n^2)^2 - 4(\sigma_e^2 \sigma_n^2 - \sigma_{en}^2)}}{2}$$

$$\sigma_{min}^2 = \frac{(\sigma_e^2 + \sigma_n^2) - \sqrt{(\sigma_e^2 + \sigma_n^2)^2 - 4(\sigma_e^2 \sigma_n^2 - \sigma_{en}^2)}}{2}$$



**Figure 8-16: Target Error Estimate - Circular Error 90%**

CE90 represents the 90 percent probability circular error radius of absolute horizontal accuracy.

With  $\sigma_{max}$  and  $\sigma_{min}$  known, the Circular Error for 90% confidence can be calculated as:

$$CE90 = \sigma_{max} \cdot a\left(\frac{\sigma_{min}}{\sigma_{max}}\right) \text{ where } a(x) = 0.4194x^2 + 0.0774x + 1.648. \text{ This is one means for}$$

determining CE90 from statistical data in the easting-northing-up coordinate system, yet similar calculations are allowed.

### 8.46 Tag 46: Target Error Estimate - LE90 Conversion

LS Tag	46	Units	Range	Format
LS Name	Target Error Estimate - LE90	Meters	0..4095	uint16
US Mapped Key	06 0E 2B 34 01 01 01 01 0E 01 01 03 08 00 00 00 (CRC 59091)			
Notes		Conversion Formula		
<ul style="list-style-type: none"><li>- Lateral Error 90 (LE90) is the estimated error distance in the vertical (or lateral) direction.</li><li>- Specifies the interval of 90% probability in the local vertical direction.</li><li>- Res: 0.0625 meters</li></ul>		$LS\_dec = \left( \frac{LS\_range}{uint\_range} * LS\_uint \right)$ $LS\_46\_dec = \left( \frac{4095}{65535} * LS\_46 \right)$		
Example Value	Example LS Packet			
609.0718 Meters	[K][L][V] = [0d46][0d2][0x26 11]			

#### 8.46.1 Example Target Error Estimate – Linear Error 90% (LE90)

Target covariance values are represented in an easting-northing-up coordinate system centered about the target point. This is shown below:

**Covariance Matrix:**

$$Q = \begin{bmatrix} \sigma_e^2 & \sigma_{en} & \sigma_{eu} \\ \sigma_{ne} & \sigma_n^2 & \sigma_{nu} \\ \sigma_{ue} & \sigma_{un} & \sigma_u^2 \end{bmatrix}$$

**Min and Max Sigma Values:**

$$\sigma_{max}^2 = \frac{(\sigma_e^2 + \sigma_n^2) + \sqrt{(\sigma_e^2 + \sigma_n^2)^2 - 4(\sigma_e^2 \sigma_n^2 - \sigma_{en}^2)}}{2}$$

$$\sigma_{min}^2 = \frac{(\sigma_e^2 + \sigma_n^2) - \sqrt{(\sigma_e^2 + \sigma_n^2)^2 - 4(\sigma_e^2 \sigma_n^2 - \sigma_{en}^2)}}{2}$$

LE90 represents the 90 percent probability linear error of absolute vertical accuracy.

With the vertical (or “up”) variance known ( $\sigma_u$ ), the 90 percent linear error can be calculated as  $LE90 = 1.645 \cdot \sigma_u$ . This is one means for determining LE90 from statistical data in the easting-northing-up coordinate system, yet similar calculations are allowed.

**8.47 Tag 47: Generic Flag Data 01 Conversion**

LS Tag	47	Units	None	Range	uint8	Format	uint8
LS Name	Generic Flag Data 01						
US Mapped Key	06 0E 2B 34 01 01 01 01 0E 01 01 03 01 00 00 00 (CRC 5540)						
Notes		Conversion Formula					
<ul style="list-style-type: none"> <li>- Generic Flagged Metadata</li> <li>- Position Format msb8..1lsb</li> <li>- 1- Laser Range lon,0off</li> <li>- 2- Auto-Track lon,0off</li> <li>- 3- IR Polarity 1blk,0wht</li> <li>- 4- Icing detected 1ice,0(off/no ice)</li> <li>- 5- Slant Range 1measured, 0calc</li> <li>- 6- Image Invalid 1invalid, 0valid</li> <li>- 7,8- Use 0</li> </ul>							
Example Value		Example LS Packet					
49		[K] [L] [V] = [0d47] [0d1] [0x31]					

**8.47.1 Example Generic Flag Data 01**

Miscellaneous yes / no aircraft and image related data items are logged within the Generic Flag Data 01 metadata item.

Updates in ST 0601.3 include an indication (bit 5) that Slant Range (Tag 21) is either “calculated” (0) or “measured” (1).

Updates in ST 0601.5 include the Image Invalid flag (bit 6). This flag indicates the state of the associated Motion Imagery as being “valid” (0) or “invalid” (1). An invalid (or unusable) image can be due to a lens change, bad focus, or other camera parameter which significantly degrades the image quality.

**8.48 Tag 48: Security Local Set Conversion**

LS Tag	48	Units	Range	Format	
LS Name	Security Local Set	None	Set	Set	
US Mapped Key	Use ST0102 US key for Local Sets.				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- Local set tag to include the ST0102 Local Set Security Metadata items within ST0601. Use the ST0102 Local Set Tags within the ST0601 tag 0d48.</li><li>- The length field is the size of all ST0102 metadata items to be packaged within tag 0d48.</li></ul>		x			
		x			
Example Value		Example LS Packet			
x		[K] [L] [V] = [0d48] [0dx] [x]			
US Key	06 0E 2B 34 02 03 01 01 0E 01 03 03 02 00 00 00 (CRC 40980)	ESD Digraph	x		
US Name	Security Local Set	ESD Name	x		
Units	Range	Format	Units	Range	Format
x	x	x	x	x	x
Notes		Notes			
- x		- x			
US Conversion		ESD Conversion			
x		x			
<u>To US:</u>		<u>To ESD:</u>			
- x		- x			
<u>To LS:</u>		<u>To LS:</u>			
- x		- x			

**8.48.1 Example Security Local set**

Both Universal Set tags and Local Set tags are defined for KLV formatted security items in MISB ST 0102. When incorporated within ST 0601, multiple security metadata KLV Local Set triplets are allowed to be contained within the 0d48 UAS LS metadata item.



**8.49 Tag 49: Differential Pressure Conversion**

LS Tag	49	Units	Range	Format
LS Name	Differential Pressure	Millibar	0..5000	uint16
US Mapped Key	06 0E 2B 34 01 01 01 01 0E 01 01 01 01 00 00 00 (CRC 20775)			
Notes		Conversion Formula		
<ul style="list-style-type: none"><li>- Differential pressure at aircraft location. Measured as the Stagnation/impact/total pressure minus static pressure.</li><li>- Map 0..(2^16-1) to 0..5000 mbar.</li><li>- 1 mbar = 0.0145037738 PSI.</li><li>- Res: ~0.08 mbar</li></ul>		$LS\_dec = \left( \frac{LS\_range}{uint\_range} * LS\_uint \right)$ $LS\_49\_dec = \left( \frac{5000}{65535} * LS\_49 \right)$		
Example Value	Example LS Packet			
1191.958 mbar	[K] [L] [V] = [0d49] [0d2] [0x3D 07]			

**8.49.1 Example Differential Pressure**

Differential pressure provides a method of calculating relative velocity of an item as it passes through a fluid, or conversely the velocity of a fluid as it passes by an item. Velocity can be determined by differential pressure by the following:

$$v_1 = \sqrt{\frac{2p_d}{\rho}}$$

where  $p_d$  is the measured differential pressure ( $p_d = \text{impact pressure} - \text{static pressure} = p_i - p_s$ ), and  $\rho$  is the density of the fluid outside the item.


## 8.50 Tag 50: Platform Angle of Attack Conversion

LS Tag	50	Units	Degrees	Range	+/- 20	Format	int16
LS Name	Platform Angle of Attack						
US Mapped Key	06 0E 2B 34 01 01 01 01 0E 01 01 01 02 00 00 00 (CRC 51963)						
Notes		Conversion Formula					
<ul style="list-style-type: none"> <li>- Platform Attack Angle. Angle between platform longitudinal axis and relative wind.</li> <li>- Positive angles for upward relative wind.</li> <li>- Map <math>-(2^{15}-1) \dots (2^{15}-1)</math> to +/-20.</li> <li>- Use <math>-(2^{15})</math> as an "out of range" indicator.</li> <li>- <math>-(2^{15}) = 0x8000</math>.</li> <li>- Res: ~610 micro degrees.</li> </ul>		$LS\_dec = \left( \frac{LS\_range}{int\_range} * LS\_int \right)$					
		$LS\_50\_dec = \left( \frac{40}{65534} * LS\_50 \right)$					
Example Value		Example LS Packet					
-8.670177 Degrees		[K] [L] [V] = [0d50] [0d2] [0xC8 83]					

### 8.50.1 Example Platform Angle of Attack

*For legacy purposes, both range-restricted (Tag 50) and full-range (Tag 92) representations of Platform Angle of Attack MAY appear in the same ST 0601 packet. A single representation is preferred favoring the full-range version (Tag 92).*

The angle of attack of an airborne platform is the angle formed between the relative wind and platform longitudinal axis (line made by the fuselage). Positive angles for wind with a relative upward component. Refer to Figure 8-17.



**Figure 8-17: Platform Angle of Attack**

Note that the int16 used in the LS value is encoded using two's complement.

### 8.51 Tag 51: Platform Vertical Speed Conversion

LS Tag	51	Units	Range	Format
LS Name	Platform Vertical Speed	Meters	+/- 180	int16
US Mapped Key	06 0E 2B 34 01 01 01 01 0E 01 01 01 03 00 00 00 (CRC 48207)	/Second		
Notes		Conversion Formula		
<ul style="list-style-type: none"><li>- Vertical speed of the aircraft relative to zenith. Positive ascending, negative descending.</li><li>- Map-(2^15-1)..(2^15-1) to +/-180</li><li>- Use -(2^15) as an "out of range" indicator.</li><li>- -(2^15) = 0x8000.</li><li>- Resolution: ~ 0.0055 meters/second.</li></ul>		$LS_{dec} = \left( \frac{LS_{range}}{int_{range}} * LS_{int} \right)$ $LS_{51} = \left( \frac{360}{65534} * LS_{51} \right)$		
Example Value		Example LS Packet		
-61.88693 m/s		[K][L][V] = [0d51][0d2][0xD3 FE]		

#### 8.51.1 Example Vertical Speed

The vertical speed metadata item is the climb or decent rate in meters per second of an airborne platform in the zenith direction. Positive values indicate an ascending platform, while negative values indicate descending.

Note that the int16 used in the LS value is encoded using two's complement.


## 8.52 Tag 52: Platform Sideslip Angle Conversion

LS Tag	52	Units	Degrees	Range	+/- 20	Format	int16
LS Name	Platform Sideslip Angle						
US Mapped Key	06 0E 2B 34 01 01 01 01 0E 01 01 01 04 00 00 00 (CRC 60770)						
Notes		Conversion Formula					
<ul style="list-style-type: none"> <li>- The sideslip angle is the angle between the platform longitudinal axis and relative wind.</li> <li>- Positive angles to right wing, neg to left.</li> <li>- Map <math>-(2^{15}-1) \dots (2^{15}-1)</math> to <math>\pm 20</math>.</li> <li>- Use <math>-(2^{15})</math> as an "out of range" indicator.</li> <li>- <math>-(2^{15}) = 0x8000</math>.</li> <li>- Res: ~610 micro deg.</li> </ul>		$LS\_dec = \left( \frac{LS\_range}{int\_range} * LS\_int \right)$					
		$LS\_52\_dec = \left( \frac{40}{65534} * LS\_52 \right)$					
Example Value		Example LS Packet					
-5.082475 Degrees		[K][L][V] = [0d52][0d2][0xDF 79]					

### 8.52.1 Example Platform Sideslip Angle

*For legacy purposes, both range-restricted (Tag 52) and full-range (Tag 93) representations of Platform Sideslip Angle MAY appear in the same ST 0601 packet. A single representation is preferred favoring the full-range version (Tag 93).*

The angle formed between the platform longitudinal axis (line made by the fuselage) and the relative wind is the sideslip angle. A negative sideslip angle is depicted in Figure 8-18:



**Figure 8-18: Platform Sideslip Angle**

Note that the int16 used in the LS value is encoded using two's complement.

### 8.53 Tag 53: Airfield Barometric Pressure Conversion

LS Tag	53	Units	Range	Format
LS Name	Airfield Barometric Pressure	Millibar	0..5000	uint16
US Mapped Key	06 0E 2B 34 01 01 01 01 0E 01 01 02 02 00 00 00 (CRC 9257)			
Notes		Conversion Formula		
<ul style="list-style-type: none"><li>- Local pressure at airfield of known height. Pilot's responsibility to update.</li><li>- Map 0..(2^16-1) to 0..5000 mbar.</li><li>- 1013.25mbar = 29.92inHg</li><li>- Min/max recorded values of 870/1086mbar.</li><li>- Resolution: ~0.08 Millibar</li></ul>		$LS\_dec = \left( \frac{LS\_range}{uint\_range} * LS\_uint \right)$ $LS\_53\_dec = \left( \frac{5000}{65535} * LS\_53 \right)$		
Example Value	Example LS Packet			
2088.96 mbar	[K][L][V] = [0d53][0d2][0x6A F4]			

#### 8.53.1 Example Barometric Pressure at Airfield

Barometric pressure at airfield is used with altimeters to display airfield elevation when on the airfield.

**8.54 Tag 54: Airfield Elevation Conversion**

LS Tag	54	Units	Range	Format
LS Name	Airfield Elevation	Meter	-900..19000	uint16
US Mapped Key	06 0E 2B 34 01 01 01 01 0E 01 01 02 03 00 00 00 (CRC 21149)	s		
Notes		Conversion Formula		
<ul style="list-style-type: none"><li>- Elevation of Airfield corresponding to Airfield Barometric Pressure.</li><li>- Map 0..(2^16-1) to -900..19000 meters.</li><li>- Offset = -900.</li><li>- 1 meter = 3.2808399 feet.</li><li>- Resolution: ~0.3 meters.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{uint\_range} * LS\_int \right) - Offset$ $LS\_54\_dec = \left( \frac{19900}{65535} * LS\_54 \right) - 900$		
Example Value	Example LS Packet			
8306.806 Meters	[K][L][V] = [0d54][0d2][0x76 70]			

**8.54.1 Example Airfield Elevation**

Airfield elevation established at airfield location. This relates to the Barometric Pressure at Airfield metadata item.

8.55 Tag 55: Relative Humidity Conversion

LS Tag	55	Units	Range	Format
LS Name	Relative Humidity	Percent	0..100	uint8
US Mapped Key	06 0E 2B 34 01 01 01 01 0E 01 01 01 09 00 00 00 (CRC 54500)			
Notes		Conversion Formula		
<ul style="list-style-type: none"><li>- Relative Humidity at aircraft location.</li><li>- Map 0..(2^8-1) to 0..100.</li><li>- Resolution: ~0.4%.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{uint\_range} * LS\_uint \right)$ $LS\_55\_dec = \left( \frac{100}{255} * LS\_55 \right)$		
Example Value	Example LS Packet			
50.58823%	[K][L][V] = [0d55][0d1][0x81]			

8.55.1 Example Relative Humidity

Relative humidity is the ratio between the water vapor density and the saturation point of water vapor density and is expressed here as a percentage.

## 8.56 Tag 56: Platform Ground Speed Conversion

LS Tag		56	Units		Range	Format
LS Name		Platform Ground Speed	Meters		0..255	uint8
US Mapped Key		06 0E 2B 34 01 01 01 01 0E 01 01 01 05 00 00 00 (CRC 39894)	/Second			
Notes			Conversion Formula			
<ul style="list-style-type: none"><li>- Speed projected to the ground of an airborne platform passing overhead.</li><li>- 0..255 meters/sec.</li><li>- 1 m/s = 1.94384449 knots.</li><li>- Resolution: 1 meter/second.</li></ul>			$LS\_dec = LS\_int$ $LS\_56\_dec = round(LS\_56)$			
Example Value			Example LS Packet			
140 m/s			[K] [L] [V] = [0d56] [0d1] [0x8C]			
US Key	x		ESD Digraph	Gv		
US Name	x		ESD Name	Platform Ground Speed		
Units	Range	Format	Units	Range	Format	
x	x	x	Knots	0..999	N	
Notes			Notes			
<ul style="list-style-type: none"><li>- x</li></ul>			<ul style="list-style-type: none"><li>- Speed on the ground of an airborne platform passing overhead</li></ul>			
US Conversion			ESD Conversion			
x			ESD_dec = LS_uint			
<u>To US:</u> <ul style="list-style-type: none"><li>- x</li></ul>			<u>To ESD:</u> <ul style="list-style-type: none"><li>- Convert LS to decimal.</li><li>- Convert decimal to ASCII.</li></ul>			
<u>To LS:</u> <ul style="list-style-type: none"><li>- x</li></ul>			<u>To LS:</u> <ul style="list-style-type: none"><li>- Convert ESD ASCII to decimal.</li><li>- Map decimal to uint16.</li></ul>			

### 8.56.1 Example Platform Ground Speed

The ground speed of an airborne platform is the aircraft's speed as projected onto the ground.



**8.57 Tag 57: Ground Range Conversion**

LS Tag		57	Units		Range	Format
LS Name		Ground Range	Meters		0..5,000,000	uint32
US Mapped Key		06 0E 2B 34 01 01 01 01 0E 01 01 01 06 00 00 00 (CRC 10)				
Notes			Conversion Formula			
<ul style="list-style-type: none"><li>- Horizontal distance from ground position of aircraft relative to nadir, and target of interest. Dependent upon Slant Range and Depression Angle.</li><li>- Map 0..(2^32-1) to 0..5000000 meters.</li><li>- 1 nautical mile (knot) = 1852 meters.</li><li>- Resolution: ~1.2 milli meters.</li></ul>			$LS\_dec = \left( \frac{LS\_range}{uint\_range} * LS\_uint \right)$ $LS\_57\_dec = \left( \frac{5000000}{4294967295} * LS\_57 \right)$			
Example Value		Example LS Packet				
3506979 Meters		[K][L][V] = [0d57][0d4][0xB3 8E AC F1]				
US Key	x		ESD Digraph	Gr		
US Name	x		ESD Name	Ground Range		
Units	Range	Format	Units	Range	Format	
x	x	x	Nautical Miles	0..18.00	II.HH	
Notes			Notes			
<ul style="list-style-type: none"><li>- x</li></ul>			<ul style="list-style-type: none"><li>- Horizontal distance between the sensor and the target. Measured in Nautical Miles.</li></ul>			
US Conversion			ESD Conversion			
x			$ESD\_dec = \left( \frac{5000000}{4294967295} * LS\_uint \right) * \frac{1852knot}{1m}$			
<u>To US:</u>			<u>To ESD:</u>			
<ul style="list-style-type: none"><li>- x</li></ul>			<ul style="list-style-type: none"><li>- Convert LS to decimal.</li></ul>			
<u>To LS:</u>			<ul style="list-style-type: none"><li>- Account for units.</li></ul>			
<ul style="list-style-type: none"><li>- x</li></ul>			<ul style="list-style-type: none"><li>- Convert decimal to ASCII.</li></ul>			
			<u>To LS:</u>			
			<ul style="list-style-type: none"><li>- Convert ESD ASCII to decimal.</li></ul>			
			<ul style="list-style-type: none"><li>- Account for units.</li></ul>			
			<ul style="list-style-type: none"><li>- Convert ASCII to uint32.</li></ul>			

**8.57.1 Example Ground Range**

Ground range is the horizontal distance between the aircraft/sensor location and the target of interest and does not account for terrain undulations.

**8.58 Tag 58: Platform Fuel Remaining Conversion**

LS Tag	58	Units	Range	Format	
LS Name	Platform Fuel Remaining	Kilogram	0..10,000	uint16	
US Mapped Key	06 0E 2B 34 01 01 01 01 0E 01 01 01 07 00 00 00 (CRC 30398)				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- Remaining fuel on airborne platform. Metered as fuel weight remaining.</li><li>- Map 0..(2^16-1) to 0..10000 Kilograms.</li><li>- 1 kilogram = 2.20462262 pounds.</li><li>- Resolution: ~.16 kilograms.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{uint\_range} * LS\_uint \right)$ $LS\_58\_dec = \left( \frac{10000}{65535} * LS\_58 \right)$			
Example Value		Example LS Packet			
6420.539 kg		[K] [L] [V] = [0d58] [0d2] [0xA4 5D]			
US Key	x	ESD Digraph	Fr		
US Name	x	ESD Name	Platform Fuel Remaining		
Units	Range	Format	Units	Range	Format
x	x	x	Pounds	0..99,999	N
Notes			Notes		
<ul style="list-style-type: none"><li>- x</li></ul>			<ul style="list-style-type: none"><li>- Remaining fuel on airborne platform. Metered as fuel weight remaining.</li></ul>		
US Conversion			ESD Conversion		
x			$ESD\_dec = \left( \frac{10000}{65535} * LS\_uint \right) * \frac{2.0462262lbs}{1kg}$		
<u>To US:</u> <ul style="list-style-type: none"><li>- x</li></ul>			<u>To ESD:</u> <ul style="list-style-type: none"><li>- Convert LS to decimal.</li><li>- Account for units.</li><li>- Convert decimal to ASCII.</li></ul>		
<u>To LS:</u> <ul style="list-style-type: none"><li>- x</li></ul>			<u>To LS:</u> <ul style="list-style-type: none"><li>- Convert ESD ASCII to decimal.</li><li>- Account for units.</li><li>- Map decimal to uint16.</li></ul>		

**8.58.1 Example Platform Fuel Remaining**

Platform fuel remaining indicates the current weight of fuel present on the host platform and is measured in kilograms.

**8.59 Tag 59: Platform Call Sign Conversion**

LS Tag		59	Units		Range	Format
LS Name		Platform Call Sign	String		1..127	ISO 646
US Mapped Key		06 0E 2B 34 01 01 01 01 0E 01 04 01 01 00 00 00 (CRC 4646)				
Notes			Conversion Formula			
- Call Sign of platform or operating unit.			x			
- Value field is Free Text.			x			
Example Value		Example LS Packet				
TOP GUN		[K][L][V] = [0d59][0d7][0x54 4F 50 20 47 55 4E]				
US Key	x		ESD Digraph	Cs		
US Name	x		ESD Name	Platform Call Sign		
Units		Range	Format			
x		x	x			
Notes			Notes			
- x			- First nine characters of the Call Sign of a group or squadron			
US Conversion			ESD Conversion			
x			x			
<u>To US:</u>			<u>To ESD:</u>			
- x			- Truncate LS String and convert to ESD			
<u>To LS:</u>			<u>To LS:</u>			
- x			- Convert ESD string to LS			

**8.59.1 Example Platform Call Sign**

The platform call sign is used to distinguish groups or squadrons of platforms within different operating units from one another. Call sign is often related to the aircraft tail number.

## 8.60 Tag 60: Weapon Load Conversion

LS Tag	60	Units	Range	Format	
LS Name	Weapon Load	uint16	x	nibble	
US Mapped Key	06 0E 2B 34 01 01 01 01 0E 01 01 01 12 00 00 00 (CRC 53596)				
Notes		Conversion Formula			
- Current weapons stored on aircraft broken into two bytes: - [K][L][V] = [0x41][0x02][[byte1][byte2]] - [byteN] = [[nib1][nib2]], nib1= msn - byte1-nib1 = Station Number - byte1-nib2 = Substation Number - byte2-nib1 = Weapon Type - byte2-nib2 = Weapon Variant		x x			
Example Value		Example LS Packet			
45016		[K][L][V] = [0d60][0d2][0xAF D8]			
US Key	x	ESD Digraph	W1		
US Name	x	ESD Name	Weapon Load		
Units	Range	Format	Units	Range	Format
x	x	x	x	x	x
Notes			Notes		
- x			- x		
US Conversion			ESD Conversion		
x			x		
<u>To US:</u>			<u>To ESD:</u>		
- x			- x		
<u>To LS:</u>			<u>To LS:</u>		
- x			- x		

### 8.60.1 Example Weapon Load

Weapon load is broken into two bytes with the first byte indicates the aircraft store location, and the second byte indicates store type. Each byte is broken into two nibbles with [nib1] being the most significant nibble with bit order [3210] where 3=msb.

Aircraft store location is indicated by station number which starts numbering at the outboard left wing as store location 1 and increases towards the outboard right wing. Each station can have a different weapon installed, or multiple weapons on the same station. In a multiple weapon per station situation, the substation number begins at 1 and increases from there. A substation number of 0 indicates a single store located at the station. The Store Location byte has two nibbles with the first most significant nibble indicating station number, and the second indicating substation number. Note an example store location in the diagram of Figure 8-19:




Figure 8-19: Aircraft Store Location

The weapon type byte is also broken into two nibbles with the first most significant nibble indicating weapon type and the second nibble indicating weapon variant.

A listing of available weapons is TBD.

## 8.61 Tag 61: Weapon Fired Conversion

LS Tag	61	Units	Range	Format	
LS Name	Weapon Fired	uint8	x	nibble	
US Mapped Key	06 0E 2B 34 01 01 01 01 0E 01 01 01 13 00 00 00 (CRC 42984)				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- Indication when a particular weapon is released. Correlate with Precision Time Stamp.</li><li>- Identical format to Weapon Load byte 2:</li><li>- [byteN] = [[nib1][nib2]]</li><li>- nib1 = Station Number</li><li>- nib2 = Substation Number</li></ul>		<ul style="list-style-type: none"><li>x</li><li>x</li></ul>			
Example Value		Example LS Packet			
186		[K] [L] [V] = [0d61] [0d2] [0xBA]			
US Key	x	ESD Digraph	Wf		
US Name	x	ESD Name	Weapon Fired		
Units	Range	Format	Units	Range	Format
x	x	x	x	x	x
Notes		Notes			
- x		- x			
US Conversion		ESD Conversion			
x		x			
<u>To US:</u>		<u>To ESD:</u>			
- x		- x			
<u>To LS:</u>		<u>To LS:</u>			
- x		- x			

### 8.61.1 Example Weapon Fired

The Weapon Fired metadata item has the same format as the first byte of the Weapon Load metadata item indicating station and substation location of a store. Byte 1 is broken into two nibbles with [nib1] being the most significant nibble with bit order [3210] where 3=msb.

When included in a KLV packet, the weapon fired item should be correlated with the mandatory timestamp to determine the release time of a weapon.

## 8.62 Tag 62: Laser PRF Code Conversion

LS Tag		62	Units		Range	Format
LS Name		Laser PRF Code	None		0..65535	uint16
US Mapped Key		06 0E 2B 34 01 01 01 01 0E 01 02 02 01 00 00 00 (CRC 28949)				
Notes			Conversion Formula			
<ul style="list-style-type: none"><li>- A laser's Pulse Repetition Frequency (PRF) code used to mark a target.</li><li>- The Laser PRF code is a three or four digit number consisting of the values 1..8.</li><li>- Only the values 1111..8888 can be used without 0's or 9's.</li></ul>			x			
			x			
Example Value		Example LS Packet				
50895		[K][L][V] = [0d62][0d2][0xC6 CF]				
US Key	x		ESD Digraph		Lc	
US Name	x		ESD Name		Laser PRF Code	
Units	Range	Format	Units	Range	Format	
x	x	x	None	1111..8888	NNNN	
Notes			Notes			
<ul style="list-style-type: none"><li>- x</li></ul>			<ul style="list-style-type: none"><li>- A laser's Pulse Repetition Frequency (PRF) code used to mark a target.</li><li>- The Laser PRF code is a three or four digit number consisting of the values 1..8.</li><li>- Only the values 1111..8888 can be used without 0's or 9's.</li></ul>			
US Conversion			ESD Conversion			
x			x			
<u>To US:</u>			<u>To ESD:</u>			
<ul style="list-style-type: none"><li>- x</li></ul>			<ul style="list-style-type: none"><li>- Convert LS uint to ASCII.</li></ul>			
<u>To LS:</u>			<u>To LS:</u>			
<ul style="list-style-type: none"><li>- x</li></ul>			<ul style="list-style-type: none"><li>- Convert ASCII to LS uint.</li></ul>			

### 8.62.1 Example Laser PRF Code

When enabled, laser designators can generate a pulsed signal according to a Pulse Repetition Frequency (PRF) Code which distinguishes one laser beam from another.

### 8.63 Tag 63: Sensor Field of View Name Conversion

LS Tag		63	Units		Range	Format
LS Name		Sensor Field of View Name		List	0..255	uint8
US Mapped Key		06 0E 2B 34 01 01 01 01 0E 01 02 02 02 00 00 00 (CRC 60105)				
Notes			Conversion Formula			
<ul style="list-style-type: none"><li>- Names sensor field of view quantized steps:</li><li>- 00 = Ultranarrow</li><li>- 01 = Narrow</li><li>- 02 = Medium</li><li>- 03 = Wide</li><li>- 04 = Ultrawide</li><li>- 05 = Narrow Medium</li><li>- 06 = 2x Ultranarrow</li><li>- 07 = 4x Ultranarrow</li></ul>			x			
			x			
Example Value		Example LS Packet				
209		[K] [L] [V] = [0d63] [0d1] [0xD1]				
US Key	x		ESD Digraph		Vn	
US Name	x		ESD Name		Sensor Field of View Name	
Units		Range		Format		
x		x		x		
Notes		Notes				
<ul style="list-style-type: none"><li>- x</li></ul>		<ul style="list-style-type: none"><li>- Names sensor field of view quantized steps.</li><li>- 00 = Ultranarrow</li><li>- 01 = Narrow</li><li>- 02 = Medium</li><li>- 03 = Wide</li><li>- 04 = Ultrawide</li><li>- 05 = Narrow Medium</li><li>- 06 = 2x Ultranarrow</li><li>- 07 = 4x Ultranarrow</li></ul>				
US Conversion			ESD Conversion			
x			x			
<u>To US:</u>			<u>To ESD:</u>			
<ul style="list-style-type: none"><li>- x</li></ul>			<ul style="list-style-type: none"><li>- Convert LS uint to ASCII.</li></ul>			
<u>To LS:</u>			<u>To LS:</u>			
<ul style="list-style-type: none"><li>- x</li></ul>			<ul style="list-style-type: none"><li>- Convert ASCII to LS uint.</li></ul>			

#### 8.63.1 Example Sensor Field of View Name

The field of view name is a way to indicate to the operator the current lens used on the Motion Imagery sensor.

The Sensor Field of View names are for generic guidance and do not correspond to specific field of view values. Refer to Horizontal and Vertical Field of View metadata items (Tags 16 & 17) for specific aperture angles.



## 8.64 Tag 64: Platform Magnetic Heading Conversion

LS Tag		64	Units		Range	Format
LS Name		Platform Magnetic Heading	Degrees		0..360	uint16
US Mapped Key		06 0E 2B 34 01 01 01 01 0E 01 01 01 08 00 00 00 (CRC 41552)				
Notes			Conversion Formula			
<ul style="list-style-type: none"><li>- Aircraft magnetic heading angle. Relative between longitudinal axis and Magnetic North measured in the horizontal plane.</li><li>- Map 0..(2^16-1) to 0..360.</li><li>- Resolution: ~5.5 milli degrees.</li></ul>			$LS\_dec = \left( \frac{LS\_range}{uint\_range} * LS\_uint \right)$			
			$LS\_64\_dec = \left( \frac{360}{65535} * LS\_64 \right)$			
Example Value		Example LS Packet				
311.8682 Degrees		[K][L][V] = [0d64][0d2][0xDD C5]				
US Key	x		ESD Digraph	Mh		
US Name	x		ESD Name	Platform Magnetic Heading		
Units	Range	Format	Units	Range	Format	
x	x	x	Degrees	0..359.99	DDD.HH	
Notes			Notes			
<ul style="list-style-type: none"><li>- x</li></ul>			<ul style="list-style-type: none"><li>- Aircraft magnetic heading angle. Relative between fuselage chord line and Magnetic North.</li></ul>			
US Conversion			ESD Conversion			
x			$ESD\_dec = \left( \frac{360}{65535} * LS\_uint \right)$			
<u>To US:</u>			<u>To ESD:</u>			
<ul style="list-style-type: none"><li>- x</li></ul>			<ul style="list-style-type: none"><li>- Convert LS to decimal.</li><li>- Convert decimal to ASCII.</li></ul>			
<u>To LS:</u>			<u>To LS:</u>			
<ul style="list-style-type: none"><li>- x</li></ul>			<ul style="list-style-type: none"><li>- Convert ESD ASCII to decimal.</li><li>- Map decimal to uint16.</li></ul>			

### 8.64.1 Example Magnetic Heading




Figure 8-20: Magnetic Heading

**8.65 Tag 65: UAS Datalink LS Version Number Conversion**

LS Tag	65	Units	Range	Format	
LS Name	UAS Datalink LS Version Number	Number	0..255	uint8	
US Mapped Key	06 0E 2B 34 01 01 01 01 0E 01 02 03 03 00 00 00 (CRC 13868)				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- Version number of the UAS LS document used to generate a source of UAS LS KLV metadata.</li><li>- 0 is pre-release, initial release (0601.0), or test data.</li><li>- 1..255 corresponds to document revisions ST0601.1 thru ST0601.255.</li></ul>		x			
		x			
Example Value		Example LS Packet			
Version 232		[K] [L] [V] = [0d65] [0d1] [0xE8]			
US Key	x	ESD Digraph	Iv		
US Name	x	ESD Name	ESD ICD Version		
Units	Range	Format	Units	Range	Format
x	x	x	Number	0..99	NN
Notes		Notes			
<ul style="list-style-type: none"><li>- x</li></ul>		<ul style="list-style-type: none"><li>- Version of the ESD System use to encode ESD Data.</li><li>- 0 corresponds to documents ASI-119 and ASI-209.</li><li>- 1..99 corresponds to document revisions of ST0601.1 thru ST 0601.99.</li></ul>			
US Conversion		ESD Conversion			
x		x			
<u>To US:</u>		<u>To ESD:</u>			
<ul style="list-style-type: none"><li>- x</li></ul>		<ul style="list-style-type: none"><li>- Convert uint to ASCII.</li></ul>			
<u>To LS:</u>		<u>To LS:</u>			
<ul style="list-style-type: none"><li>- x</li></ul>		<ul style="list-style-type: none"><li>- Convert ASCII to uint.</li></ul>			

**8.65.1 Example UAS LS Version Number**

The UAS LS version number metadata item is used to indicate which version of ST 0601 is used as the source standard of UAS LS metadata. This item is not required in every packet of metadata, but is useful when included periodically.

**8.66 Tag 66: Target Location Covariance Matrix Conversion**

LS Tag	66	Units	Range	Format
LS Name	Target Location Covariance Matrix	TBD	TBD	TBD
US Mapped Key	06 0E 2B 34 02 05 01 01 0E 01 03 03 14 00 00 00 (CRC 28126)			
Notes		Conversion Formula		
- Covariance Matrix of the error associated with a targeted location.			TBD	
- Details TBD.			TBD	
Example Value		Example LS Packet		
x	[K] [L] [V] = [0d66] [0dTBD] [x]			

**8.66.1 Example Target Location Covariance Matrix**

Details TBD

**8.67 Tag 67: Alternate Platform Latitude Conversion**

LS Tag	67	Units	Range	Format
LS Name	Alternate Platform Latitude	Degrees	+/- 90	int32
US Mapped Key	06 0E 2B 34 01 01 01 01 0E 01 01 01 14 00 00 00 (CRC 63173)			
Notes		Conversion Formula		
<ul style="list-style-type: none"><li>- Alternate Platform Latitude. Represents latitude of platform connected with UAS.</li><li>- Based on WGS84 ellipsoid.</li><li>- Map <math>-(2^{31}-1)..(2^{31}-1)</math> to +/-90.</li><li>- Use <math>-(2^{31})</math> as an "error" indicator.</li><li>- <math>-(2^{31}) = 0x80000000</math>.</li><li>- Resolution: ~42 nano degrees.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{int\_range} * LS\_int \right)$ $LS\_67\_dec = \left( \frac{180}{4294967294} * LS\_67 \right)$		
Example Value		Example LS Packet		
-86.041207348947 Degrees		[K][L][V] = [0d67][0d4][0x85 A1 5A 39]		

**8.67.1 Example Latitude**

Latitude is the angular distance north or south of the earth's equator, measured in degrees along a meridian. Generated from GPS/INS information and based on the WGS84 coordinate system.

The Alternate Platform is an airborne or ground based platform that is connected via direct datalink to a UAS generating Motion Imagery and metadata.

Note that the int32 used in the LS value is encoded using two's complement.

## 8.68 Tag 68: Alternate Platform Longitude Conversion

LS Tag	68	Units	Range	Format
LS Name	Alternate Platform Longitude	Degrees	+/- 180	int32
US Mapped Key	06 0E 2B 34 01 01 01 01 0E 01 01 01 15 00 00 00 (CRC 32881)			
Notes		Conversion Formula		
<ul style="list-style-type: none"><li>- Alternate Platform Longitude. Represents longitude of platform connected with UAS.</li><li>- Based on WGS84 ellipsoid.</li><li>- Map -(2^31-1)..(2^31-1) to +/-180.</li><li>- Use -(2^31) as an "error" indicator.</li><li>- -(2^31) = 0x80000000.</li><li>- Resolution: ~84 nano degrees.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{int\_range} * LS\_int \right)$ $LS\_68\_dec = \left( \frac{360}{4294967294} * LS\_68 \right)$		
Example Value		Example LS Packet		
0.155527554524842 Degrees		[K][L][V] = [0d68][0d4][0x00 1C 50 1C]		

### 8.68.1 Example Longitude

Longitude is the angular distance on the earth's surface, measured east or west from the prime meridian at Greenwich, England, to the meridian passing through a position of interest. Generated from GPS/INS information and based on the WGS84 coordinate system.

The Alternate Platform is an airborne or ground based platform that is connected via direct datalink to a UAS generating Motion Imagery and metadata.

Note that the int32 used in the LS value is encoded using two's complement.

**8.69 Tag 69: Alternate Platform Altitude Conversion**

LS Tag	69	Units	Range	Format
LS Name	Alternate Platform Altitude	Meters	-900..19000	uint16
US Mapped Key	06 0E 2B 34 01 01 01 01 0E 01 01 01 16 00 00 00 (CRC 7085)			
Notes		Conversion Formula		
<ul style="list-style-type: none"><li>- Altitude of alternate platform as measured from Mean Sea Level (MSL). Represents altitude of platform connected with UAS.</li><li>- Map 0..(2^16-1) to -900..19000 meters.</li><li>- 1 meter = 3.2808399 feet.</li><li>- Resolution: ~0.3 meters.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{uint\_range} * LS\_uint \right) - Offset$ $LS\_69\_dec = \left( \frac{19900}{65535} * LS\_69 \right) - 900$		
Example Value	Example LS Packet			
9.445334 Meters	[K][L][V] = [0d69][0d2][0x0B B3]			

**8.69.1 Example Platform Altitude**

The Alternate Platform Altitude is a true altitude or true vertical distance above mean sea level. Measurement is GPS derived.

The Alternate Platform is an airborne or ground based platform that is connected via direct datalink to a UAS generating Motion Imagery and metadata.

## 8.70 Tag 70: Alternate Platform Name Conversion

LS Tag	70	Units	Range	Format
LS Name	Alternate Platform Name	String	1..127	ISO 646
US Mapped Key	06 0E 2B 34 01 01 01 01 0E 01 01 01 17 00 00 00 (CRC 27929)			
Notes		Conversion Formula		
<ul style="list-style-type: none"><li>- Name of alternate platform connected to UAS.</li><li>- E.g.: 'Apachce', 'Rover', 'Predator', 'Reaper', 'Outrider', 'Pioneer', 'IgnatER', 'Warrior', 'Shadow', 'Hunter II', 'Global Hawk', 'Scan Eagle', etc.</li><li>- Value field is Free Text.</li><li>- Maximum 127 characters.</li></ul>		<div>x</div> <div>x</div>		
Example Value		Example LS Packet		
APACHE		[K][L][V] = [0d70][0d6][0x41 50 41 43 48 45]		

### 8.70.1 Example Alternate Platform Name

The Alternate Platform Name metadata item distinguishes which platform is connected with the UAS which is generating Motion Imagery and metadata products. The alternate platform can be airborne or ground based and is to be described sufficiently (yet with brevity) in text using this metadata item.

The Alternate Platform is an airborne or ground based platform that is connected via direct datalink to a UAS generating Motion Imagery and metadata.

**8.71 Tag 71: Alternate Platform Heading Conversion**

LS Tag	71	Units	Range	Format
LS Name	Alternate Platform Heading	Degrees	0..360	uint16
US Mapped Key	06 0E 2B 34 01 01 01 01 0E 01 01 01 18 00 00 00 (CRC 47607)			
Notes		Conversion Formula		
<ul style="list-style-type: none"><li>- Heading angle of alternate platform connected to UAS. Relative between longitudinal axis and True North measured in the horizontal plane.</li><li>- Map 0..(2^16-1) to 0..360.</li><li>- Resolution: ~5.5 milli degrees.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{int\_range} * LS\_int \right)$ $LS\_71\_dec = \left( \frac{360}{65535} * LS\_71 \right)$		
Example Value	Example LS Packet			
32.60242 Degrees	[K][L][V] = [0d71][0d2][0x17 2F]			

**8.71.1 Example Alternate Platform Heading**

The Alternate Platform heading angle is defined as the angle between the alternate platform longitudinal axis (line made by the fuselage) and true north measured in the horizontal plane. Angles increase in a clockwise direction when looking from above the platform. North is 0 degrees, east is 90, south is 180, and west is 270 degrees from true north.

The Alternate Platform is an airborne or ground based platform that is connected via direct datalink to a UAS generating Motion Imagery and metadata.



**8.72 Tag 72: Event Start Time - UTC Conversion**

LS Tag	72	Units	Range	Format	
LS Name	Event Start Time - UTC	Micro-	0..(2^64-1)	uint64	
US Mapped Key	Use EG 0104 US Key	seconds			
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- Start time of scene, project, event, mission, editing event, license, publication, etc.</li><li>- Represented as the microseconds elapsed since midnight (00:00:00), January 1, 1970.</li><li>- Resolution: 1 microsecond.</li></ul>		x			
		x			
Example Value		Example LS Packet			
April 16, 1995. 13:44:54		[K][L][V] = [0d72][0d8][0x00 02 D5 CF 4D DC 9A 35]			
US Key	06 0E 2B 34 01 01 01 01 07 02 01 02 07 01 00 00 (CRC 11991)	ESD Digraph	x		
US Name	Event Start Date Time - UTC	ESD Name	Mission Start Time, Date, and Date of Collection		
Units	Range	Format	Units	Range	Format
Date/Time	'YYYYMMDDhhmmss'	ISO 8601	x	x	x
Notes		Notes			
<ul style="list-style-type: none"><li>- The absolute beginning date and time of the project, mission, scene, editing event, license, publication etc.</li><li>- Formatted text as: 'YYYYMMDDhhmmss'</li></ul>		<ul style="list-style-type: none"><li>- The LS Event Start Time - UTC can be converted to three ESD items:</li><li>- Mission Start Date (Md)</li><li>- Mission Start Time (Mc)</li><li>- Date of Collection (Cd)</li><li>- Refer to EG0104 for details on these ESD items.</li></ul>			
US Conversion		ESD Conversion			
x		x			
<u>To US:</u>		<u>To ESD:</u>			
<ul style="list-style-type: none"><li>- Convert uint64 to formatted string.</li></ul>		<ul style="list-style-type: none"><li>- x</li></ul>			
<u>To LS:</u>		<u>To LS:</u>			
<ul style="list-style-type: none"><li>- Convert formatted string to uint64.</li></ul>		<ul style="list-style-type: none"><li>- x</li></ul>			

**8.72.1 Example Event Start Time – UTC**

A Precision Time Stamp discretely labels a scale of time. This system is widely used within systems of differing underlying architectures. The Precision Time Stamp is specified in MISB ST 0603. In converting the Precision Time Stamp to UTC, leap seconds are added (or subtracted). See the Motion Imagery Handbook [8] for appropriate conversions

The Event Start Time metadata value is used to represent the start time of a mission, or other event related to the Motion Imagery collection.

Event Start Time is to be interpreted as an arbitrary time hack indicating the start of some event.

**8.73 Tag 73: RVT Local Set**

<b>LS Tag</b>	73	<b>Units</b>	<b>Range</b>	<b>Format</b>
<b>LS Name</b>	RVT Local Set	None	Set	Set
<b>US Mapped Key</b>	Use ST 0806 RVT LS 16-byte Key			
<b>Notes</b>		<b>Conversion Formula</b>		
<ul style="list-style-type: none"> <li>- Local set tag to include the ST0806 RVT Local Set metadata items within ST0601. Use the ST0806 Local Set Tags within the ST0601 tag 0d73.</li> <li>- The length field is the size of all RVT LS metadata items to be packaged within tag 0d73.</li> </ul>		<ul style="list-style-type: none"> <li>x</li> <li>x</li> </ul>		
<b>Example Value</b>		<b>Example LS Packet</b>		
x		[K] [L] [V] = [0d73] [0dx] [x]		
<b>US Key</b>	06 0E 2B 34 02 0B 01 01 0E 01 03 01 02 00 00 00 (CRC 17945)	<b>ESD Digraph</b>	x	
<b>US Name</b>	Remote Video Terminal Local Set	<b>ESD Name</b>	x	
<b>Units</b>	<b>Range</b>	<b>Format</b>	<b>Units</b>	<b>Range</b>
None	Set	Set	x	x
<b>Notes</b>		<b>Notes</b>		
- x		- x		
<b>US Conversion</b>		<b>ESD Conversion</b>		
x		x		
<u>To US:</u>		<u>To ESD:</u>		
- x		- x		
<u>To LS:</u>		<u>To LS:</u>		
- x		- x		

**8.73.1 Example RVT Local Set**

ST 0601 Tag 73 allows users to include, or nest, RVT LS (MISB ST 0806) metadata items within ST 0601.

This provides users who are required to use the RVT LS data field (Points of Interest, Areas of Interest, etc.) a method to leverage the data field contained within ST 0601 (like platform location, and sensor pointing angles).

**8.74 Tag 74: VMTI Local Set Conversion**

<b>LS Tag</b>	74	<b>Units</b>	<b>Range</b>	<b>Format</b>
<b>LS Name</b>	VMTI Local Set	None	Set	Set
<b>US Mapped Key</b>	Use ST 0903 VMTI LS 16-byte Key			
<b>Notes</b>		<b>Conversion Formula</b>		
<ul style="list-style-type: none"> <li>- Local set tag to include the ST0903 VMTI Local Set metadata items within ST0601. Use the ST0903 Local Set Tags within the ST0601 tag 0d74.</li> <li>- The length field is the size of all VMTI LS metadata items to be packaged within tag 0d74.</li> </ul>		<ul style="list-style-type: none"> <li>x</li> <li>x</li> </ul>		
<b>Example Value</b>		<b>Example LS Packet</b>		
x		[K] [L] [V] = [0d74] [0dx] [x]		
<b>US Key</b>	06 0E 2B 34 02 0B 01 01 0E 01 03 03 06 00 00 00 (CRC 51307)	<b>ESD Digraph</b>	x	
<b>US Name</b>	Video Moving Target Indicator Local Set	<b>ESD Name</b>	x	
<b>Units</b>	<b>Range</b>	<b>Format</b>	<b>Units</b>	<b>Range</b>
None	Set	Set	x	x
<b>Notes</b>		<b>Notes</b>		
- x		- x		
<b>US Conversion</b>		<b>ESD Conversion</b>		
x		x		
<u>To US:</u>		<u>To ESD:</u>		
- x		- x		
<u>To LS:</u>		<u>To LS:</u>		
- x		- x		

**8.74.1 Example VMTI Local Set**

ST 0601 Tag 74 allows users to include, or nest, VMTI LS (MISB ST 0903 [18]) metadata items within ST 0601.

This provides users who are required to use the VMTI LS data field a method to leverage the data field contained within ST 0601 (like platform location, and sensor pointing angles, or frame center).

**8.75 Tag 75: Sensor Ellipsoid Height Conversion**

LS Tag	75	Units	Range	Format
LS Name	Sensor Ellipsoid Height	Meters	-900..19000	uint16
US Mapped Key	06 0E 2B 34 01 01 01 01 0E 01 02 01 82 47 00 00 (CRC 16670)			
Notes		Conversion Formula		
<ul style="list-style-type: none"><li>- Sensor Ellipsoid Height as measured from the reference WGS84 Ellipsoid.</li><li>- Map 0..(2^16-1) to -900..19000 meters.</li><li>- 1 meter = 3.2808399 feet.</li><li>- Resolution: ~0.3 meters.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{uint\_range} * LS\_uint \right) - Offset$ $LS\_75\_dec = \left( \frac{19900}{65535} * LS\_75 \right) - 900$		
Example Value	Example LS Packet			
14190.72 Meters	[K][L][V] = [0d75][0d2][0xC2 21]			

**8.75.1 Example Sensor Ellipsoid Height**

*For legacy purposes, both MSL (Tag 15) and HAE (Tag 75) representations of Sensor True Altitude MAY appear in the same ST 0601 packet. A single representation is preferred favoring the HAE version (Tag 75).*

The Sensor Ellipsoid Height is the vertical distance between the sensor and the WGS84 Reference Ellipsoid. Measurement is GPS derived.

**8.76 Tag 76: Alternate Platform Ellipsoid Height Conversion**

LS Tag	76	Units	Meters	Range	-900..19000	Format	uint16
LS Name	Alternate Platform Ellipsoid Height						
US Mapped Key	06 0E 2B 34 01 01 01 01 0E 01 02 01 82 48 00 00 (CRC 27951)						
Notes			Conversion Formula				
<ul style="list-style-type: none"><li>- Alternate Platform Ellipsoid Height as measured from the reference WGS84 Ellipsoid.</li><li>- Map 0..(2^16-1) to -900..19000 meters.</li><li>- 1 meter = 3.2808399 feet.</li><li>- Resolution: ~0.3 meters.</li></ul>			$LS\_dec = \left( \frac{LS\_range}{uint\_range} * LS\_uint \right) - Offset$				
			$LS\_76\_dec = \left( \frac{19900}{65535} * LS\_76 \right) - 900$				
Example Value		Example LS Packet					
9.445334 Meters		[K][L][V] = [0d76][0d2][0x0B B3]					

**8.76.1 Example Alternate Platform Ellipsoid Height**

The Alternate Platform Ellipsoid Height is the vertical distance between the sensor and the WGS84 Reference Ellipsoid. Measurement is GPS derived.

The Alternate Platform is an airborne or ground based platform that is connected via direct datalink to a UAS generating Motion Imagery and metadata.

**8.77 Tag 77: Operational Mode Conversion**

LS Tag	77	Units	Range	Format
LS Name	Operational Mode	None	None	uint8
US Mapped Key	06 0E 2B 34 01 01 01 01 0E 01 01 03 21 00 00 00 (CRC 8938)			
Notes		Conversion Formula		
<ul style="list-style-type: none"><li>- Indicates the mode of operations of the event portrayed in metadata. Enumerated.</li><li>- 0x00 = "Other"</li><li>- 0x01 = "Operational"</li><li>- 0x02 = "Training"</li><li>- 0x03 = "Exercise"</li><li>- 0x04 = "Maintenance"</li><li>- 0x05 = "Test"</li></ul>			x	
			x	
Example Value	Example LS Packet			
x	[K] [L] [V] = [0d77] [0dx] [x]			

**8.77.1 Example Operational Mode**

The Operational Mode provides an indication of the event portrayed in the metadata. This allows for categorization of Motion Imagery streams and is often useful for archival systems.

**8.78 Tag 78: Frame Center Height Above Ellipsoid Conversion**

LS Tag	78	Units	Range	Format
LS Name	Frame Center Height Above Ellipsoid	Meters	-900..19000	uint16
US Mapped Key	06 0E 2B 34 01 01 01 01 0E 01 02 03 48 00 00 00 (CRC 18095)			
Notes		Conversion Formula		
<ul style="list-style-type: none"><li>- Frame Center Ellipsoid Height as measured from the reference WGS84 Ellipsoid.</li><li>- Map 0..(2^16-1) to -900..19000 meters.</li><li>- 1 meter = 3.2808399 feet.</li><li>- Resolution: ~0.3 meters.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{uint\_range} * LS\_uint \right) - Offset$ $LS\_78\_dec = \left( \frac{19900}{65535} * LS\_78 \right) - 900$		
Example Value		Example LS Packet		
9.445334 Meters		[K][L][V] = [0d78][0d2][0x0B B3]		

*For legacy purposes, both MSL (Tag 25) and HAE (Tag 78) representations of Frame Center Elevation MAY appear in the same ST 0601 packet. A single representation is preferred favoring the HAE version (Tag 78).*

The Frame Center Ellipsoid Height is the vertical distance on the ground within the center of the Motion Imagery frame and the WGS84 Reference Ellipsoid. Measurement is GPS derived.

**8.79 Tag 79: Sensor North Velocity Conversion**

LS Tag	79	Units	Range	Format
LS Name	Sensor North Velocity	Meters /Second	+/-327	int16
US Mapped Key	06 0E 2B 34 01 01 01 01 0E 01 02 02 7E 00 00 00 (CRC 59278)			
Notes		Conversion Formula		
<ul style="list-style-type: none"><li>- Northing velocity of the sensor or platform. Positive towards True North</li><li>- Map-(2^15-1)..(2^15-1) to +/-327</li><li>- Use -(2^15) as an "out of range" indicator.</li><li>- -(2^15) = 0x8000.</li><li>- Resolution: ~ 1 cm/sec.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{int\_range} * LS\_int \right)$ $LS\_79 = \left( \frac{654}{65534} * LS\_79 \right)$		
Example Value	Example LS Packet			
x	[K][L][V] = [0d79][0dx][x]			

**8.79.1 Example Sensor North Velocity**

The Northing velocity of the sensor is the sensor movement rate in the north direction. Positive values indicate a sensor approaching True North.

Note that the int16 used in the LS value is encoded using two's complement.



8.80 Tag 80: Sensor East Velocity Conversion

LS Tag	80	Units	Range	Format
LS Name	Sensor East Velocity	Meters	+/-327	int16
US Mapped Key	06 0E 2B 34 01 01 01 01 0E 01 02 02 7F 00 00 00 (CRC 37178)	/Second		
Notes		Conversion Formula		
<ul style="list-style-type: none"><li>- Easting velocity of the sensor or platform. Positive towards East.</li><li>- Map-(2^15-1)..(2^15-1) to +/-327</li><li>- Use -(2^15) as an "out of range" indicator.</li><li>- -(2^15) = 0x8000.</li><li>- Resolution: ~ 1 cm/sec.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{int\_range} * LS\_int \right)$ $LS\_80 = \left( \frac{654}{65534} * LS\_80 \right)$		
Example Value	Example LS Packet			
x	[K] [L] [V] = [0d80] [0dx] [x]			

8.80.1 Example Sensor East Velocity

The Easting velocity of the sensor is the sensor movement rate in the east direction. Positive values indicate a sensor approaching east.

Note that the int16 used in the LS value is encoded using two's complement.

## 8.81 Tag 81: Image Horizon Pixel Pack Conversion


LS Tag	81	Units	Pack	Range	Pack	Format	Pack
LS Name	Image Horizon Pixel Pack						
US Mapped Key	06 0E 2B 34 02 05 01 01 0E 01 03 02 08 00 00 00 (CRC 37658)						
Notes	- <tag 81><length> - < start x0, start y0 // point p0 - end x1, end y1 // point p1 - start lat, start lon - end lat, end lon - >						
Conversion Formula	See Notes below.						
Example Value	Example LS Packet						
x	[K] [L] [V] = [0d81] [0dx] [x]						

### 8.81.1 Description of Image Horizon Pixel Pack

The Image Horizon Pixel Pack allows a user to separate sky and ground portions of an image by defining a line representing the horizon. The method for detecting where the horizon is within the image is left to the system implementer.

The line representing the horizon which transects the image is defined by a vector with start and end points which must lie on the extents of the image. This is called the Horizon Vector. The horizontal (x) and vertical (y) coordinates are represented in a relative scale (from 0 to 100%) with (x,y) equal to (0%,0%) being the top left corner of the image.

Once start and end coordinates are defined, the pixels to the right of this Horizon Vector designates the ground region, while pixels to the left represent sky. Refer to Figure 8-21.




**Figure 8-21: Horizon Vector**

With the Horizon Vector defined, only the image corner points to the right are considered valid and allowed to be included within a ST 0601 packet. No invalid corner coordinates are allowed when the Image Horizon Pixel Pack is included in the same ST 0601 packet.

The Horizon Line and valid corner coordinates define the Pixel Frame (PF) (i.e. a polygon) which represents ground pixels.

In the example shown in in Figure 8-21, corner point number 3 is the only valid corner point and is used with the start and end points to define a 3-point Pixel Frame.

Examples for 3-point, 4-point, and 5-point Pixel Frames are shown in Figure 8-22.




**Figure 8-22: Pixel Frame Examples**

Note that the pixel points  $p_0$  through  $p_4$  do not always directly correspond with the offset (Tags 26-33) or absolute (Tags 82-89) corner coordinates defined within this document.

### 8.81.2 Image Horizon Pixel Pack Example

To show how to use the Image Horizon Pixel Pack, consider the following example shown in Figure 8-23 for sample 720p airborne imagery:



**Figure 8-23: Image Horizon Pixel Pack Example**

In the example above, the horizon (barely visible through haze) is covered by the Horizon Vector with  $p_0 = (0\%, 36.11\%)$ , and  $p_1 = (56.25\%, 0\%)$ .

### 8.81.3 Decoding the Image Horizon Pixel Pack

When an Image Horizon Pixel Pack only includes the x & y coordinates of the Horizon Vector and not the geo-locations, the Horizon Vector is used to determine the image pixel coordinates (derived from the relative values) which construct the Pixel Frame.

When the latitudes and longitudes of the Horizon Vector are included, these geo-locations along with the valid offset or absolute corner coordinates in the same ST 0601 packet are then matched with the appropriate points defined by the Pixel Frame.

### 8.81.4 Floating Length Pack Definition for the Image Horizon Pixel Pack

The Image Horizon Pixel Pack makes use of a Floating Length Pack as described by MISB RP 0701 and allows a user to include or exclude data items as necessary. The first items defined within this pack are the Start x0, Start y0 and End x1, End y1 coordinates representing the start and end of the Horizon Vector. These are then followed by real earth latitude-longitude geo-coordinate pairs for the start and end points of the Horizon Vector.

As used here, the minimum required components are the Start x0, Start y0 and End x1, End y1 end points defining the Horizon Vector in image space. The latitudes/longitudes of these points are optional (but recommended). The Image Horizon Pixel Pack is defined in Table 2.

The “Key” column indicates the Universal Set key for the corresponding metadata item as defined in MISB ST 0807 [5]. The “Name” column is the corresponding name of the metadata item. The “Units/Range” column provides the units of measurement for the item’s value, and the range of allowed values. The “Format” column indicates the data type used for the value of the item. This is directly related to the “Length” column, which indicates the number of bytes allotted to the item value. Finally, the “M/O” column indicates whether the corresponding metadata item is mandatory (i.e. “M”), or optional (i.e. “O”). However, values which are optional are recommended to be provided.

**Table 2: Image Horizon Pixel Pack**

Local Set Key			Name			
06 0E 2B 34 02 05 01 01 0E 01 03 02 08 00 00 00 (CRC 37658)			Image Horizon Pixel Pack			
Constituent Elements						
Key	Name	Notes	Units/Range	Format	Len	M/O
06 0E 2B 34 01 01 01 01 0E 01 01 02 09 01 00 00 (CRC 3334)	Start x0	The X coordinate (in percent) of an X-Y pair representing the start point of a vector crossing an image. Top left of image is 0,0 with positive X increasing to the right. To be used with Start y0. Mandatory in the Image Horizon Pixel Pack.	Percent [0..100]	uint8	1	M
06 0E 2B 34 01 01 01 01 0E 01 01 02 09 02 00 00 (CRC 21590)	Start y0	The Y coordinate (in percent) of an X-Y pair representing the start point of a vector crossing an image. Top left of image is 0.0 with positive Y increasing down. To be used with Start x0. Mandatory in the Image Horizon Pixel Pack.	Percent [0..100]	uint8	1	M
06 0E 2B 34 01 01 01 01 0E 01 01 02 09 03 00 00 (CRC 25446)	End x1	The X coordinate (in percent) of an X-Y pair representing the end point of a vector crossing an image. Top left of image is 0,0 with positive X increasing to the right. To be used with End y0. Mandatory in the Image Horizon Pixel Pack.	Percent [0..100]	uint8	1	M
06 0E 2B 34 01 01 01 01 0E 01 01 02 09 04 00 00 (CRC 59126)	End y1	The Y coordinate (in percent) of an X-Y pair representing the end point of a vector crossing an image. Top left of image is 0.0 with positive Y increasing down. To be used with End x0. Mandatory in the Image Horizon Pixel Pack.	Percent [0..100]	uint8	1	M
06 0E 2B 34 01 01 01 01 0E 01 01 02 09 05 00 00 (CRC 53702)	Start Latitude	The Latitude of the Start point (x0,y0) on the image border. Based on WGS84 ellipsoid. Map $-(2^{31}-1)..(2^{31}-1)$ to $\pm 90$ . Use $(-2^{31})$ as an “error” indicator. Optional (but recommended).	Degrees [-90..+90]	int32	4	O
06 0E 2B 34 01 01 01 01 0E 01 01 02 09 06 00 00 (CRC 34966)	Start Longitude	The Longitude of the Start point (x0,y0) on the image boarder. Based on WGS84 ellipsoid. Map $-(2^{31}-1)..(2^{31}-1)$ to $\pm 180$ . Use $(-2^{31})$ as an “error” indicator. Optional (but recommended).	Degrees [-180..+180]	int32	4	O
06 0E 2B 34 01 01 01 01 0E 01 01 02 09 07 00 00 (CRC 49062)	End Latitude	The Latitude of the End point (x1,y1) on the image boarder. Based on WGS84 ellipsoid. Map $-(2^{31}-1)..(2^{31}-1)$ to $\pm 90$ . Use $(-2^{31})$ as an “error” indicator. Optional (but recommended).	Degrees [-90..+90]	int32	4	O
06 0E 2B 34 01 01 01 01 0E 01 01 02 09 08 00 00 (CRC 37783)	End Longitude	The Longitude of the End point (x1,y1) on the image boarder. Based on WGS84 ellipsoid. Map $-(2^{31}-1)..(2^{31}-1)$ to $\pm 180$ . Use $(-2^{31})$ as an “error” indicator. Optional (but recommended).	Degrees [-180..+180]	int32	4	O

## 8.82 Tag 82: Corner Latitude Point 1 (Full) Conversion


LS Tag	82	Units	Range	Format	
LS Name	Corner Latitude Point 1 (Full)	Degrees	+/- 90	int32	
US Mapped Key	Use EG 0104 US Key				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- Frame Latitude for upper left corner.</li><li>- Full Range.</li><li>- Based on WGS84 ellipsoid.</li><li>- Map -(2^31-1)..(2^31-1) to +/-90.</li><li>- Use -(2^31) as an "error" indicator.</li><li>- -(2^31) = 0x80000000.</li><li>- Resolution: ~42 nano degrees.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{int\_range} * LS\_int \right)$ $LS\_82\_dec = \left( \frac{180}{4294967294} * LS\_82 \right)$			
Example Value		Example LS Packet			
-10.579637999887 Corrected Degrees		[K][L][V] = [0d82][0d4][0xF0 F4 12 44]			
US Key	06 0E 2B 34 01 01 01 03 07 01 02 01 03 07 01 00 (CRC 23392)	ESD Digraph	Rg		
US Name	Corner Latitude Point 1 (Decimal Degrees)	ESD Name	SAR Latitude 4		
Units	Range	Format	Units	Range	Format
Degrees	+/- 90	Double	Degrees	+/- 90.00	PDDMMSSST
Notes		Notes			
<ul style="list-style-type: none"><li>- Latitude coordinate of corner 1 of an image or bounding rectangle.</li><li>- Positive (+) is northern hemisphere.</li><li>- Negative (-) is southern hemisphere.</li></ul>		<ul style="list-style-type: none"><li>- The latitude of the upper left corner of the SAR image box</li></ul>			
US Conversion		ESD Conversion			
$US\_dec = \left( \frac{180}{4294967294} * LS\_int \right)$		$ESD\_dec = \left( \frac{180}{4294967294} * LS\_int \right)$			
<u>To US:</u> <ul style="list-style-type: none"><li>- US = (double)(180/0xFFFFFFFF * LS)</li></ul>		<u>To ESD:</u> <ul style="list-style-type: none"><li>- Convert LS to decimal.</li><li>- Convert decimal to ASCII.</li></ul>			
<u>To LS:</u> <ul style="list-style-type: none"><li>- LS = (int32)round(0xFFFFFFFF/180 * US)</li></ul>		<u>To LS:</u> <ul style="list-style-type: none"><li>- Convert ASCII to decimal.</li><li>- Map decimal to int32.</li></ul>			

### 8.82.1 Example Corner Latitude Point 1 (Full) Conversion

*For legacy purposes, both range-restricted (Tags 26-33) and full-range (Tag 82-89) representations of Image Corner Coordinates MAY appear in the same ST 0601 packet. A single representation is preferred, with the full-range version (Tags 82-89) being favored as per Section 6.3.*

The corner points of the captured image or image sequence have a real earth coordinate represented by a latitude-longitude pair. Corner points that lie above the horizon typically do not correspond to a point on the earth, should either not be reported, or be reported as an "error".

Corner point 1 is the upper left corner of the captured image as highlighted in red (Figure 8-24).



**Figure 8-24: Offset Corner Point 1**

Value is encoded using two's complement.

### 8.83 Tag 83: Corner Longitude Point 1 (Full) Conversion

LS Tag	83	Units	Range	Format	
LS Name	Corner Longitude Point 1 (Full)	Degrees	+/- 180	int32	
US Mapped Key	Use EG 0104 US Key				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- Frame Longitude for upper left corner.</li><li>- Full Range.</li><li>- Based on WGS84 ellipsoid.</li><li>- Map -(2^31-1)..(2^31-1) to +/-180.</li><li>- Use -(2^31) as an "error" indicator.</li><li>- -(2^31) = 0x80000000.</li><li>- Resolution: ~84 nano degrees.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{int\_range} * LS\_int \right)$ $LS\_83\_dec = \left( \frac{360}{4294967294} * LS\_83 \right)$			
Example Value		Example LS Packet			
29.1273677986333 Corrected Degrees		[K][L][V] = [0d83][0d4][0x14 B6 79 B9]			
US Key	06 0E 2B 34 01 01 01 03 07 01 02 01 03 0B 01 00 (CRC 11777)	ESD Digraph	Rh		
US Name	Corner Longitude Point 1 (Decimal Degrees)	ESD Name	SAR Longitude 4		
Units	Range	Format	Units	Range	Format
Degrees	+/- 180	Double	Degrees	+/- 180.00	PDDMMSSST
Notes		Notes			
<ul style="list-style-type: none"><li>- Longitude coordinate of corner 1 of an image or bounding rectangle.</li><li>- Positive (+) is eastern hemisphere.</li><li>- Negative (-) is western hemisphere.</li></ul>		<ul style="list-style-type: none"><li>- The longitude of the upper left corner of the SAR image box</li></ul>			
US Conversion		ESD Conversion			
$US\_dec = \left( \frac{360}{4294967294} * LS\_int \right)$		$ESD\_dec = \left( \frac{360}{4294967294} * LS\_int \right)$			
<u>To US:</u> <ul style="list-style-type: none"><li>- US = (double)(360/0xFFFFFFFF * LS)</li></ul>		<u>To ESD:</u> <ul style="list-style-type: none"><li>- Convert LS to decimal.</li><li>- Convert decimal to ASCII.</li></ul>			
<u>To LS:</u> <ul style="list-style-type: none"><li>- LS = (int32)round(0xFFFFFFFF/360 * US)</li></ul>		<u>To LS:</u> <ul style="list-style-type: none"><li>- Convert ASCII to decimal.</li><li>- Map decimal to int32.</li></ul>			

#### 8.83.1 Example Corner Longitude Point 1 (Full) Conversion

*For legacy purposes, both range-restricted (Tags 26-33) and full-range (Tag 82-89) representations of Image Corner Coordinates MAY appear in the same ST 0601 packet. A single representation is preferred, with the full-range version (Tags 82-89) being favored as per Section 6.3.*

The corner points of the captured image or image sequence have a real earth coordinate represented by a latitude-longitude pair. Corner points that lie above the horizon typically do not correspond to a point on the earth (an example being the tracking of an airborne object), should either not be reported, or be reported as an "error".

Corner point 1 is the upper left corner of the captured image. See Figure 8-24 for Tag 82 above.



### 8.84 Tag 84: Corner Latitude Point 2 (Full) Conversion


LS Tag	84	Units	Range	Format	
LS Name	Corner Latitude Point 2 (Full)	Degrees	+/- 90	int32	
US Mapped Key	Use EG 0104 US Key				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- Frame Latitude for upper right corner.</li><li>- Full Range.</li><li>- Based on WGS84 ellipsoid.</li><li>- Map -(2^31-1)..(2^31-1) to +/-90.</li><li>- Use -(2^31) as an "error" indicator.</li><li>- -(2^31) = 0x80000000.</li><li>- Resolution: ~42 nano degrees.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{int\_range} * LS\_int \right)$ $LS\_84\_dec = \left( \frac{180}{4294967294} * LS\_84 \right)$			
Example Value		Example LS Packet			
-10.5661816260963 Corrected Degrees		[K][L][V] = [0d84][0d4][0xF0 F8 F8 7E]			
US Key	06 0E 2B 34 01 01 01 03 07 01 02 01 03 08 01 00 (CRC 30545)	ESD Digraph	Ra		
US Name	Corner Latitude Point 2 (Decimal Degrees)	ESD Name	SAR Latitude 1		
Units	Range	Format	Units	Range	Format
Degrees	+/- 90	Double	Degrees	+/- 90.00	PDDMMSSST
Notes		Notes			
<ul style="list-style-type: none"><li>- Latitude coordinate of corner 2 of an image or bounding rectangle.</li><li>- Positive (+) is northern hemisphere.</li><li>- Negative (-) is southern hemisphere.</li></ul>		<ul style="list-style-type: none"><li>- The latitude of the upper right corner of the SAR image box</li></ul>			
US Conversion		ESD Conversion			
$US\_dec = \left( \frac{180}{4294967294} * LS\_int \right)$		$ESD\_dec = \left( \frac{180}{4294967294} * LS\_int \right)$			
<u>To US:</u> <ul style="list-style-type: none"><li>- US = (double)(180/0xFFFFFFFF * LS)</li></ul>		<u>To ESD:</u> <ul style="list-style-type: none"><li>- Convert LS to decimal.</li><li>- Convert decimal to ASCII.</li></ul>			
<u>To LS:</u> <ul style="list-style-type: none"><li>- LS = (int32)round(0xFFFFFFFF/180 * US)</li></ul>		<u>To LS:</u> <ul style="list-style-type: none"><li>- Convert ASCII to decimal.</li><li>- Map decimal to int32.</li></ul>			

#### 8.84.1 Example Corner Latitude Point 2 (Full) Conversion

*For legacy purposes, both range-restricted (Tags 26-33) and full-range (Tag 82-89) representations of Image Corner Coordinates MAY appear in the same ST 0601 packet. A single representation is preferred, with the full-range version (Tags 82-89) being favored as per Section 6.3.*

The corner points of the captured image or image sequence have a real earth coordinate represented by a latitude-longitude pair. Corner points that lie above the horizon typically do not correspond to a point on the earth, should either not be reported, or be reported as an "error".

Corner point 2 is the upper right corner of the captured image as highlighted in red (Figure 8-25).



**Figure 8-25: Offset Corner Point 2**

Value is encoded using two's complement.

### 8.85 Tag 85: Corner Longitude Point 2 (Full) Conversion

LS Tag	85	Units	Range	Format	
LS Name	Corner Longitude Point 2 (Full)	Degrees	+/- 180	int32	
US Mapped Key	Use EG 0104 US Key				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- Frame Longitude for upper right corner.</li><li>- Full Range.</li><li>- Based on WGS84 ellipsoid.</li><li>- Map -(2^31-1)..(2^31-1) to +/-180.</li><li>- Use -(2^31) as an "error" indicator.</li><li>- -(2^31) = 0x80000000.</li><li>- Resolution: ~84 nano degrees.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{int\_range} * LS\_int \right)$ $LS\_85\_dec = \left( \frac{360}{4294967294} * LS\_85 \right)$			
Example Value		Example LS Packet			
29.140824172424 Corrected Degrees		[K][L][V] = [0d85][0d4][0x14 B8 EC D6]			
US Key	06 0E 2B 34 01 01 01 03 07 01 02 01 03 0C 01 00 (CRC 43921)	ESD Digraph	Rb		
US Name	Corner Longitude Point 2 (Decimal Degrees)	ESD Name	SAR Longitude 1		
Units	Range	Format	Units	Range	Format
Degrees	+/- 180	Double	Degrees	+/- 180.00	PDDMMSSST
Notes		Notes			
<ul style="list-style-type: none"><li>- Longitude coordinate of corner 2 of an image or bounding rectangle.</li><li>- Positive (+) is eastern hemisphere.</li><li>- Negative (-) is western hemisphere.</li></ul>		<ul style="list-style-type: none"><li>- The longitude of the upper right corner of the SAR image box</li></ul>			
US Conversion		ESD Conversion			
$US\_dec = \left( \frac{360}{4294967294} * LS\_int \right)$		$ESD\_dec = \left( \frac{360}{4294967294} * LS\_int \right)$			
<u>To US:</u> <ul style="list-style-type: none"><li>- US = (double)(360/0xFFFFFFFF * LS)</li></ul>		<u>To ESD:</u> <ul style="list-style-type: none"><li>- Convert LS to decimal.</li><li>- Convert decimal to ASCII.</li></ul>			
<u>To LS:</u> <ul style="list-style-type: none"><li>- LS = (int32)round(0xFFFFFFFF/360 * US)</li></ul>		<u>To LS:</u> <ul style="list-style-type: none"><li>- Convert ASCII to decimal.</li><li>- Map decimal to int32.</li></ul>			

#### 8.85.1 Example Corner Longitude Point 2 (Full) Conversion

*For legacy purposes, both range-restricted (Tags 26-33) and full-range (Tag 82-89) representations of Image Corner Coordinates MAY appear in the same ST 0601 packet. A single representation is preferred, with the full-range version (Tags 82-89) being favored as per Section 6.3.*

The corner points of the captured image or image sequence have a real earth coordinate represented by a latitude-longitude pair. Corner points that lie above the horizon typically do not correspond to a point on the earth (an example being the tracking of an airborne object), should either not be reported, or be reported as an "error".

Corner point 2 is the upper right corner of the captured image. See Figure 8-25 for Tag 84 above.

## 8.86 Tag 86: Corner Latitude Point 3 (Full) Conversion


LS Tag	86	Units	Range	Format	
LS Name	Corner Latitude Point 3 (Full)	Degrees	+/- 90	int32	
US Mapped Key	Use EG 0104 US Key				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- Frame Latitude for lower right corner.</li><li>- Full Range.</li><li>- Based on WGS84 ellipsoid.</li><li>- Map -(2^31-1)..(2^31-1) to +/-90.</li><li>- Use -(2^31) as an "error" indicator.</li><li>- -(2^31) = 0x80000000.</li><li>- Resolution: ~42 nano degrees.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{int\_range} * LS\_int \right)$ $LS\_86\_dec = \left( \frac{180}{4294967294} * LS\_86 \right)$			
Example Value		Example LS Packet			
-10.5527275411938 Corrected Degrees		[K][L][V] = [0d86][0d4][0xF0 FD DE 81]			
US Key	06 0E 2B 34 01 01 01 03 07 01 02 01 03 09 01 00 (CRC 16481)	ESD Digraph	Rc		
US Name	Corner Latitude Point 3 (Decimal Degrees)	ESD Name	SAR Latitude 2		
Units	Range	Format	Units	Range	Format
Degrees	+/- 90	Double	Degrees	+/- 90.00	PDDMMSSST
Notes		Notes			
<ul style="list-style-type: none"><li>- Latitude coordinate of corner 3 of an image or bounding rectangle.</li><li>- Positive (+) is northern hemisphere.</li><li>- Negative (-) is southern hemisphere.</li></ul>		<ul style="list-style-type: none"><li>- The latitude of the lower right corner of the SAR image box</li></ul>			
US Conversion		ESD Conversion			
$US\_dec = \left( \frac{180}{4294967294} * LS\_int \right)$		$ESD\_dec = \left( \frac{180}{4294967294} * LS\_int \right)$			
<u>To US:</u> <ul style="list-style-type: none"><li>- US = (double)(180/0xFFFFFFFF * LS)</li></ul>		<u>To ESD:</u> <ul style="list-style-type: none"><li>- Convert LS to decimal.</li><li>- Convert decimal to ASCII.</li></ul>			
<u>To LS:</u> <ul style="list-style-type: none"><li>- LS = (int32)round(0xFFFFFFFF/180 * US)</li></ul>		<u>To LS:</u> <ul style="list-style-type: none"><li>- Convert ASCII to decimal.</li><li>- Map decimal to int32.</li></ul>			

### 8.86.1 Example Corner Latitude Point 3 (Full) Conversion

*For legacy purposes, both range-restricted (Tags 26-33) and full-range (Tag 82-89) representations of Image Corner Coordinates MAY appear in the same ST 0601 packet. A single representation is preferred, with the full-range version (Tags 82-89) being favored as per Section 6.3.*

The corner points of the captured image or image sequence have a real earth coordinate represented by a latitude-longitude pair. Corner points that lie above the horizon typically do not correspond to a point on the earth, should either not be reported, or be reported as an "error".

Corner point 3 is the lower right corner of the captured image as highlighted in red (Figure 8-26).



**Figure 8-26: Offset Corner Point 3**

Value is encoded using two's complement.

**8.87 Tag 87: Corner Longitude Point 3 (Full) Conversion**

<b>LS Tag</b>	87	<b>Units</b>	<b>Range</b>	<b>Format</b>
<b>LS Name</b>	Corner Longitude Point 3 (Full)	Degrees	+/- 180	int32
<b>US Mapped Key</b>	Use EG 0104 US Key			
<b>Notes</b>		<b>Conversion Formula</b>		
<ul style="list-style-type: none"> <li>- Frame Longitude for lower right corner.</li> <li>- Full Range.</li> <li>- Based on WGS84 ellipsoid.</li> <li>- Map <math>-(2^{31}-1) \dots (2^{31}-1)</math> to +/-180.</li> <li>- Use <math>-(2^{31})</math> as an "error" indicator.</li> <li>- <math>-(2^{31}) = 0x80000000</math>.</li> <li>- Resolution: ~84 nano degrees.</li> </ul>		$LS\_dec = \left( \frac{LS\_range}{int\_range} * LS\_int \right)$ $LS\_87\_dec = \left( \frac{360}{4294967294} * LS\_87 \right)$		
<b>Example Value</b>		<b>Example LS Packet</b>		
29.1542782573265 Corrected Degrees		[K][L][V] = [0d87][0d4][0x14 BB 5F D8]		
<b>US Key</b>	06 0E 2B 34 01 01 01 03 07 01 02 01 03 0D 01 00 (CRC 40097)	<b>ESD Digraph</b>	Rd	
<b>US Name</b>	Corner Longitude Point 3 (Decimal Degrees)	<b>ESD Name</b>	SAR Longitude 2	
<b>Units</b>	<b>Range</b>	<b>Format</b>	<b>Units</b>	<b>Range</b>
Degrees	+/- 180	Double	Degrees	+/- 180.00
<b>Notes</b>		<b>Notes</b>		
<ul style="list-style-type: none"> <li>- Longitude coordinate of corner 3 of an image or bounding rectangle.</li> <li>- Positive (+) is eastern hemisphere.</li> <li>- Negative (-) is western hemisphere.</li> </ul>		<ul style="list-style-type: none"> <li>- The longitude of the lower right corner of the SAR image box</li> </ul>		
<b>US Conversion</b>		<b>ESD Conversion</b>		
$US\_dec = \left( \frac{360}{4294967294} * LS\_int \right)$		$ESD\_dec = \left( \frac{360}{4294967294} * LS\_int \right)$		
<u>To US:</u>		<u>To ESD:</u>		
<ul style="list-style-type: none"> <li>- US = (double)(360/0xFFFFFFFF * LS)</li> </ul>		<ul style="list-style-type: none"> <li>- Convert LS to decimal.</li> <li>- Convert decimal to ASCII.</li> </ul>		
<u>To LS:</u>		<u>To LS:</u>		
<ul style="list-style-type: none"> <li>- LS = (int32)round(0xFFFFFFFF/360 * US)</li> </ul>		<ul style="list-style-type: none"> <li>- Convert ASCII to decimal.</li> <li>- Map decimal to int32.</li> </ul>		

**8.87.1 Example Corner Longitude Point 3 (Full) Conversion**

*For legacy purposes, both range-restricted (Tags 26-33) and full-range (Tag 82-89) representations of Image Corner Coordinates MAY appear in the same ST 0601 packet. A single representation is preferred, with the full-range version (Tags 82-89) being favored as per Section 6.3.*

The corner points of the captured image or image sequence have a real earth coordinate represented by a latitude-longitude pair. Corner points that lie above the horizon typically do not correspond to a point on the earth (an example being the tracking of an airborne object), should either not be reported, or be reported as an "error".

Corner point 3 is the lower right corner of the captured image. See Figure 8-26 for Tag 86 above.

### 8.88 Tag 88: Corner Latitude Point 4 (Full) Conversion


LS Tag	88	Units	Range	Format	
LS Name	Corner Latitude Point 4 (Full)	Degrees	+/- 90	int32	
US Mapped Key	Use EG 0104 US Key				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- Frame Latitude for lower left corner.</li><li>- Full Range.</li><li>- Based on WGS84 ellipsoid.</li><li>- Map -(2^31-1)..(2^31-1) to +/-90.</li><li>- Use -(2^31) as an "error" indicator.</li><li>- -(2^31) = 0x80000000.</li><li>- Resolution: ~42 nano degrees.</li></ul>		US = (double)(180/0xFFFFFFFF * LS)  LS_88_dec = $\left(\frac{180}{4294967294} * LS_{88}\right)$			
Example Value		Example LS Packet			
-10.5392711674031 Corrected Degrees		[K][L][V] = [0d88][0d4][0xF1 02 C4 BB]			
US Key	06 0E 2B 34 01 01 01 03 07 01 02 01 03 0A 01 00 (CRC 6449)	ESD Digraph	Re		
US Name	Corner Latitude Point 4 (Decimal Degrees)	ESD Name	SAR Latitude 3		
Units	Range	Format	Units	Range	Format
Degrees	+/- 90	Double	Degrees	+/- 90.00	PDDMMSSST
Notes		Notes			
<ul style="list-style-type: none"><li>- Latitude coordinate of corner 4 of an image or bounding rectangle.</li><li>- Positive (+) is northern hemisphere.</li><li>- Negative (-) is southern hemisphere.</li></ul>		<ul style="list-style-type: none"><li>- The latitude of the lower left corner of the SAR image box</li></ul>			
US Conversion		ESD Conversion			
US_dec = $\left(\frac{180}{4294967294} * LS_{int}\right)$		ESD_dec = $\left(\frac{180}{4294967294} * LS_{int}\right)$			
<u>To US:</u> <ul style="list-style-type: none"><li>- US = (double)(180/0xFFFFFFFF * LS)</li></ul>		<u>To ESD:</u> <ul style="list-style-type: none"><li>- Convert LS to decimal.</li><li>- Convert decimal to ASCII.</li></ul>			
<u>To LS:</u> <ul style="list-style-type: none"><li>- LS = (int32)round(0xFFFFFFFF/180 * US)</li></ul>		<u>To LS:</u> <ul style="list-style-type: none"><li>- Convert ASCII to decimal.</li><li>- Map decimal to int32.</li></ul>			

#### 8.88.1 Example Corner Latitude Point 4 (Full) Conversion

*For legacy purposes, both range-restricted (Tags 26-33) and full-range (Tag 82-89) representations of Image Corner Coordinates MAY appear in the same ST 0601 packet. A single representation is preferred, with the full-range version (Tags 82-89) being favored as per Section 6.3.*

The corner points of the captured image or image sequence have a real earth coordinate represented by a latitude-longitude pair. Corner points that lie above the horizon typically do not correspond to a point on the earth, should either not be reported, or be reported as an "error".

Corner point 4 is the lower left corner of the captured image as highlighted in red (Figure 8-27).



**Figure 8-27: Offset Corner Point 4**

Value is encoded using two's complement.



**8.89 Tag 89: Corner Longitude Point 4 (Full) Conversion**

<b>LS Tag</b>	89	<b>Units</b>	<b>Range</b>	<b>Format</b>
<b>LS Name</b>	Corner Longitude Point 4 (Full)	Degrees	+/- 180	int32
<b>US Mapped Key</b>	Use EG 0104 US Key			
<b>Notes</b>		<b>Conversion Formula</b>		
<ul style="list-style-type: none"> <li>- Frame Longitude for lower left corner.</li> <li>- Full Range.</li> <li>- Based on WGS84 ellipsoid.</li> <li>- Map -(2^31-1)..(2^31-1) to +/-180.</li> <li>- Use -(2^31) as an "error" indicator.</li> <li>- -(2^31) = 0x80000000.</li> <li>- Resolution: ~84 nano degrees.</li> </ul>		$LS\_dec = \left( \frac{LS\_range}{int\_range} * LS\_int \right)$ $LS\_89\_dec = \left( \frac{360}{4294967294} * LS\_89 \right)$		
<b>Example Value</b>		<b>Example LS Packet</b>		
29.1677346311172 Corrected Degrees		[K][L][V] = [0d89][0d4][0x14 BD D2 F5]		
<b>US Key</b>	06 0E 2B 34 01 01 01 03 07 01 02 01 03 0E 01 00 (CRC 50673)	<b>ESD Digraph</b>	Rf	
<b>US Name</b>	Corner Longitude Point 4 (Decimal Degrees)	<b>ESD Name</b>	SAR Longitude 3	
<b>Units</b>	<b>Range</b>	<b>Format</b>	<b>Units</b>	<b>Range</b>
Degrees	+/- 180	Double	Degrees	+/- 180.00
<b>Notes</b>		<b>ESD Conversion</b>		
<ul style="list-style-type: none"> <li>- Longitude coordinate of corner 4 of an image or bounding rectangle.</li> <li>- Positive (+) is eastern hemisphere.</li> <li>- Negative (-) is western hemisphere.</li> </ul>		<ul style="list-style-type: none"> <li>- The longitude of the lower left corner of the SAR image box</li> </ul>		
<b>US Conversion</b>		<b>ESD Conversion</b>		
$US\_dec = \left( \frac{360}{4294967294} * LS\_int \right)$		$ESD\_dec = \left( \frac{360}{4294967294} * LS\_int \right)$		
<u>To US:</u>		<u>To ESD:</u>		
- US = (double)(360/0xFFFFFFFF * LS)		- Convert LS to decimal.		
<u>To LS:</u>		- Convert decimal to ASCII.		
- LS = (int32)round(0xFFFFFFFF/360 * US)		<u>To LS:</u>		
		- Convert ASCII to decimal.		
		- Map decimal to int32.		

**8.89.1 Example Corner Longitude Point 4 (Full) Conversion**

*For legacy purposes, both range-restricted (Tags 26-33) and full-range (Tag 82-89) representations of Image Corner Coordinates MAY appear in the same ST 0601 packet. A single representation is preferred, with the full-range version (Tags 82-89) being favored as per Section 6.3.*

The corner points of the captured image or image sequence have a real earth coordinate represented by a latitude-longitude pair. Corner points that lie above the horizon typically do not correspond to a point on the earth (an example being the tracking of an airborne object), should either not be reported, or be reported as an "error".

Corner point 4 is the lower left corner of the captured image. See Figure 8-27 for Tag 88 above.


## 8.90 Tag 90: Platform Pitch Angle (Full) Conversion

LS Tag	90	Units	Range	Format	
LS Name	Platform Pitch Angle (Full)	Degrees	+/- 90	int32	
US Mapped Key	Use EG 0104 US Key				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- Aircraft pitch angle. Angle between longitudinal axis and horizontal plane.</li><li>- Positive angles above horizontal plane.</li><li>- Map -(2^31-1)..(2^31-1) to +/-90.</li><li>- Use -(2^31) as an "out of range" indicator.</li><li>- -(2^31) = 0x80000000.</li><li>- Res: ~42 nano deg.</li></ul>		US = (double)(180/0xFFFFFFFF * LS)  LS_90_dec = $\left(\frac{180}{4294967294} * LS_{90}\right)$			
Example Value		Example LS Packet			
-0.4315251 Degrees		[K][L][V] = [0d90][0d4][0x62 E2 F2]			
US Key	06 0E 2B 34 01 01 01 07 07 01 10 01 05 00 00 00 (CRC 51059)	ESD Digraph	Ip		
US Name	Platform Pitch Angle	ESD Name	UAV Pitch (INS)		
Units	Range	Format	Units	Range	Format
Degrees	+/- 90	Float	Degrees	+/- 20.00	PDD.HH
Notes		Notes			
<ul style="list-style-type: none"><li>- Pitch angle of platform expressed in degrees.</li><li>- The Pitch of an airborne platform describes the angle the longitudinal axis makes with the horizontal (i.e., equi-potential gravitational surface);</li></ul>		<ul style="list-style-type: none"><li>- Pitch angle of the aircraft</li></ul>			
US Conversion		ESD Conversion			
US_dec = $\left(\frac{180}{4294967294} * LS_{int}\right)$		ESD_dec = $\left(\frac{180}{4294967294} * LS_{int}\right)$			
<u>To US:</u> <ul style="list-style-type: none"><li>- US = (double)(180/0xFFFFFFFF * LS)</li></ul>		<u>To ESD:</u> <ul style="list-style-type: none"><li>- Convert LS to decimal.</li><li>- Convert decimal to ASCII.</li></ul>			
<u>To LS:</u> <ul style="list-style-type: none"><li>- LS = (int32)round(0xFFFFFFFF/180 * US)</li></ul>		<u>To LS:</u> <ul style="list-style-type: none"><li>- Convert ASCII to decimal.</li><li>- Map decimal to int32.</li></ul>			

### 8.90.1 Example Platform Pitch Angle (Full) Conversion

*For legacy purposes, both range-restricted (Tag 6) and full-range (Tag 90) representations of Platform Pitch Angle MAY appear in the same ST 0601 packet. A single representation is preferred, with the full-range version (Tag 90) being favored as per Section 6.3.*

The pitch angle of the platform is the angle between the longitudinal axis (line made by the fuselage) and the horizontal plane. Angles are positive when the platform nose is above the horizontal plane. This item allows unrestricted pitch angle values (see Figure 8-28).



**Figure 8-28: Platform Pitch Angle**

Note that the int32 used in the LS value is encoded using two's complement.


## 8.91 Tag 91: Platform Roll Angle (Full) Conversion

LS Tag	91	Units	Range	Format	
LS Name	Platform Roll Angle (Full)	Degrees	+/- 90	int32	
US Mapped Key	Use EG 0104 US Key				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- Platform roll angle. Angle between transverse axis and transvers-longitudinal plane. Positive angles for lowered right wing.</li><li>- Map -(2^31-1)..(2^31-1) to +/-90.</li><li>- Use -(2^31) as an "error" indicator.</li><li>- -(2^31) = 0x80000000.</li><li>- Resolution: ~42 nano degrees.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{int\_range} * LS\_int \right)$ $LS\_91\_dec = \left( \frac{180}{4294967294} * LS\_91 \right)$			
Example Value		Example LS Packet			
3.405814 Degrees		[K][L][V] = [0d91][0d4][0x04 D8 04 DF]			
US Key	06 0E 2B 34 01 01 01 07 07 01 10 01 04 00 00 00 (CRC 45511)	ESD Digraph	Ir		
US Name	Platform Roll Angle	ESD Name	UAV Roll (INS)		
Units	Range	Format	Units	Range	Format
Degrees	+/- 90	Float	Degrees	+/- 50.00	PDD.HH
Notes		Notes			
<ul style="list-style-type: none"><li>- Roll angle of platform expressed in degrees.</li><li>- The Roll of an airborne platform is rotation about its longitudinal (front-to-back) axis;</li><li>- Wings level is zero degrees, positive (negative) angles describe a platform orientation with the right wing down(up).</li></ul>		<ul style="list-style-type: none"><li>- Roll angle of the aircraft</li></ul>			
US Conversion		ESD Conversion			
$US\_dec = \left( \frac{180}{4294967294} * LS\_int \right)$		$ESD\_dec = \left( \frac{180}{4294967294} * LS\_int \right)$			
<u>To US:</u>		<u>To ESD:</u>			
<ul style="list-style-type: none"><li>- US = (double) (180/0xFFFFFFFF * LS)</li></ul>		<ul style="list-style-type: none"><li>- Convert LS to decimal.</li><li>- Convert decimal to ASCII.</li></ul>			
<u>To LS:</u>		<u>To LS:</u>			
<ul style="list-style-type: none"><li>- LS = (int32)round(0xFFFFFFFF/180 * US)</li></ul>		<ul style="list-style-type: none"><li>- Convert ASCII to decimal.</li><li>- Map decimal to int32.</li></ul>			

### 8.91.1 Example Platform Roll Angle (Full) Conversion

*For legacy purposes, both range-restricted (Tag 7) and full-range (Tag 91) representations of Platform Roll Angle MAY appear in the same ST 0601 packet. A single representation is preferred, with the full-range version (Tag 91) being favored as per Section 6.3.*

The rotation operation performed about the longitudinal axis forms the roll angle between the previous aircraft transverse-longitudinal plane and the new transverse axis location (line from wing tip to wing tip). Positive angles correspond to the starboard (right) wing lowered below the previous aircraft transverse-longitudinal plane. This item allows unrestricted roll angles (see Figure 8-29).



**Figure 8-29: Platform Roll Angle**


## 8.92 Tag 92: Platform Angle of Attack (Full) Conversion

LS Tag	92	Units	Range	Format
LS Name	Platform Angle of Attack (Full)	Degrees	+/- 90	int32
US Mapped Key	06 0E 2B 34 01 01 01 01 0E 01 01 01 02 00 00 00 (CRC 51963)			
Notes		Conversion Formula		
<ul style="list-style-type: none"><li>- Platform Attack Angle. Angle between platform longitudinal axis and relative wind.</li><li>- Positive angles for upward relative wind.</li><li>- Map <math>-(2^{31}-1) \dots (2^{31}-1)</math> to +/-90.</li><li>- Use <math>-(2^{31})</math> as an "out of range" indicator.</li><li>- <math>-(2^{31}) = 0x80000000</math>.</li><li>- Res: ~42 nano deg.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{int\_range} * LS\_int \right)$ $LS\_92\_dec = \left( \frac{180}{4294967294} * LS\_92 \right)$		
Example Value	Example LS Packet			
-8.670177 Degrees	[K][L][V] = [0d92][0d4][0xF3 AB 48 EF]			

### 8.92.1 Example Platform Angle of Attack (Full) Conversion

*For legacy purposes, both range-restricted (Tag 50) and full-range (Tag 92) representations of Platform Angle of Attack MAY appear in the same ST 0601 packet. A single representation is preferred, with the full-range version (Tag 92) being favored as per Section 6.3.*

The angle of attack of an airborne platform is the angle formed between the relative wind and platform longitudinal axis (line made by the fuselage). Positive angles for wind with a relative upward component. Refer to Figure 8-30.



**Figure 8-30: Platform Angle of Attack**

Note that the int32 used in the LS value is encoded using two's complement.


### 8.93 Tag 93: Platform Sideslip Angle (Full) Conversion

LS Tag	93	Units	Range	Format
LS Name	Platform Sideslip Angle (Full)	Degrees	+/- 180	int32
US Mapped Key	06 0E 2B 34 01 01 01 01 0E 01 01 01 04 00 00 00 (CRC 60770)			
Notes		Conversion Formula		
<ul style="list-style-type: none"><li>- Angle between the platform longitudinal axis and relative wind.</li><li>- Full Range.</li><li>- Positive angles to right wing, neg to left.</li><li>- Map <math>-(2^{31}-1) \dots (2^{31}-1)</math> to +/-90.</li><li>- Use <math>-(2^{31})</math> as an "out of range" indicator.</li><li>- <math>-(2^{31}) = 0x80000000</math>.</li><li>- Res: ~42 nano deg.</li></ul>		$LS\_dec = \left( \frac{LS\_range}{int\_range} * LS\_int \right)$		
		$LS\_93\_dec = \left( \frac{360}{4294967294} * LS\_93 \right)$		
Example Value	Example LS Packet			
x	[K][L][V] = [0d93][0dx][x]			

#### 8.93.1 Example Platform Sideslip Angle (Full) Conversion

For legacy purposes, both range-restricted (Tag 52) and full-range (Tag 93) representations of Platform Sideslip Angle MAY appear in the same ST 0601 packet. A single representation is preferred, with the full-range version (Tag 93) being favored as per Section 6.3.

The angle formed between the platform longitudinal axis (line made by the fuselage) and the relative wind is the sideslip angle. A negative sideslip angle is depicted in Figure 8-31:



**Figure 8-31: Platform Sideslip Angle**

Note that the int32 used in the LS value is encoded using two's complement.

**8.94 Tag 94: MIIS Core Identifier**

LS Tag	94	Units	Range	Format	
LS Name	MIIS Core Identifier	None	None	Binary Value	
US Mapped Key	Use ST 1204 MIIS Core 16-byte Key				
Notes		Conversion Formula			
- Local set tag to include the ST1204 MIIS Core Identifier binary value within ST0601. Use according to the rules and requirements defined in ST1204.		x			
		x			
Example Value		Example LS Packet			
x		[K][L][V] = [0d94][0dx][x]			
US Key	06 0E 2B 34 01 01 01 01 0E 01 04 05 03 00 00 00 (CRC 30280)	ESD Digraph	x		
US Name	Motion Imagery Identification System Core	ESD Name	x		
Units	Range	Format	Units	Range	Format
None	None	Set	x	x	x

**8.94.1 Example MIIS Core Identifier Details**

ST 0601 Tag 94 allows users to include the MIIS Core Identifier (MISB ST 1204 [19]) Binary Value (opposed to the text-based representation) within ST 0601. Tag 94's value does not include ST 1204's 16-byte Key or length, only the value portion.

See MISB ST 1204 for generation and usage requirements.



**8.95 Tag 95: SAR Motion Imagery Local Set**

LS Tag LS Name	95			Units	Range	Format
	SAR Motion Imagery Local Set			None	None	Set
US Mapped Key	Use ST 1206 SARMI 16-byte Key					
Notes			Conversion Formula			
- Local set tag to include the ST1206 SAR Motion Imagery Metadata Local Set data within ST0601. Use according to the rules and requirements defined in ST1206.				x		
				x		
Example Value			Example LS Packet			
x			[K] [L] [V] = [0d95] [0dx] [x]			
US Key	06 0E 2B 34 02 0B 01 01 0E 01 03 03 0D 00 00 00 (CRC 54900)			ESD Digraph	x	
US Name	SAR Motion Imagery Local Set			ESD Name	x	
Units	Range	Format		Units	Range	Format
None	None	Set		x	x	x

**8.95.1 Example SAR Motion Imagery Metadata Details**

ST 0601 Tag 95 allows users to include the SAR Motion Imagery Metadata (MISB ST 1206) within ST 0601. The SARMI metadata set allows users to exploit both sequential synthetic aperture radar (SAR) imagery and sequential SAR coherent change products as Motion Imagery. See MISB ST 1206 [20] for generation and usage requirements.


## 8.96 Tag 96: Target Width Extended Conversion

LS Tag	96	Units	Range	Format	
LS Name	Target Width Extended	Meters	0..1,500,000	IMAPB	
US Mapped Key	Use EG 0104 US Key				
Notes		Conversion Formula			
<ul style="list-style-type: none"><li>- Target Width within sensor field of view.</li><li>- Range of 0 to 1,500,000 m established as maximum distance visible from an altitude of 40,000 m.</li><li>- To be consisent with Tag 22 Target Width, recommend a length of 3 bytes which provides ~0.25 meters of resolution.</li></ul>		See MISB ST 1201			
Example Value		Example LS Packet			
13,898.5463		[K][L][V] = [0d96][0dx][0x6C 95]			
US Key	06 0E 2B 34 01 01 01 01 07 01 09 02 01 00 00 00 (CRC 60350)	ESD Digraph	Tw		
US Name	Target Width	ESD Name	Target Width		
Units	Range	Format	Units	Range	Format
Meters	0..1,500,000	IMAPB	Feet	0..99,999	N
Notes		Notes			
<ul style="list-style-type: none"><li>- Within SMPTE RP 210, horizontal half width of the target frame image; used to compute the four corner points of the frame, (default meters).</li></ul>		<ul style="list-style-type: none"><li>- Width of the EO/IR Payloads field of view on the ground.</li></ul>			

### 8.96.1 Example Target Width Extended Details

*For legacy purposes, both distance-restricted (Tag 22) and distance-extended (Tag 96) representations of Target Width MAY appear in the same ST 0601 packet. A single representation is preferred, with the distance-extended version (Tag 96) being favored as per Section 6.3.*

The target width is the linear ground distance between the center of both sides of the captured image. Refer to Figure 8-32. As Target Width (Tag 22) limits the distance to 10,000 meters, this limit is no longer sufficient to support current capabilities. Target Width Extended is intended to allow for the maximum viewable distance from an altitude of 40,000 meters which is sufficient for all airborne UAS systems.



**Figure 8-32: Target Width**

**8.97 Tag 97: Range Image Local Set**

LS Tag	97	Units	Range	Format	
LS Name	Range Image Local Set	None	Set	Set	
US Mapped Key	Use ST 1002 Range Imaging LS 16-byte key				
Notes		Conversion Formula			
- Local Set tag to include ST 1002 Range Imaging LS within ST 0601.			x	x	
Example Value		Example LS Packet			
x		[K] [L] [V] = [0d97] [0dx] [x]			
US Key	06 0E 2B 34 02 0B 01 01 0E 01 03 03 0C 00 00 00 (CRC 41152)	ESD Digraph	x		
US Name	Range Image Local Set	ESD Name	x		
Units	Range	Format	Units	Range	Format
None	Set	Set	x	x	x
Notes		Notes			
- x		- x			
US Conversion		ESD Conversion			
x		x			
<u>To US:</u>		<u>To ESD:</u>			
- x		- x			
<u>To LS:</u>		<u>To LS:</u>			
- x		- x			

**8.97.1 Range Image Local Set Details**

Tag 97 allows users to include the Range Image LS (MISB ST 1002 [21]) within ST 0601.

Range Motion Imagery is a temporal sequence of Range Images. Each Range Image is a collection of Range Measurements from a sensor to target scene. A Range Measurement is the distance (e.g. meters) from an object (or area) in the scene to the sensor. The KLV structures of this standard are intended to allow for flexibility, efficient packing, and future extensions. Range Motion Imagery can be used standalone, or in collaboration with other Motion Imagery.

See MISB ST 1002 for generation and usage requirements.

**8.98 Tag 98: Geo-Registration Local Set**

LS Tag	98	Units	Range	Format	
LS Name	Geo-Registration Local Set	None	Set	Set	
US Mapped Key	Use ST 1601 Geo-Registration LS 16-byte key				
Notes		Conversion Formula			
- Local Set tag to include the ST 1601 Geo-Registration LS within ST 0601.			x	x	
Example Value		Example LS Packet			
x		[K] [L] [V] = [0d98] [0dx] [x]			
US Key	06 0E 2B 34 02 0B 01 01 0E 01 03 03 01 00 00 00 (CRC 39238)	ESD Digraph	x		
US Name	Geo-Registration Local Set	ESD Name	x		
Units	Range	Format	Units	Range	Format
None	Set	Set	x	x	x
Notes		Notes			
- x		- x			
US Conversion		ESD Conversion			
x		x			
<u>To US:</u>		<u>To ESD:</u>			
- x		- x			
<u>To LS:</u>		<u>To LS:</u>			
- x		- x			

**8.98.1 Geo-registration Local Set Details**

ST 0601 Tag 98 allows users to include the Geo-Registration Local Set (MISB ST 1601 [22]) within ST 0601. This local set supports the identification of a geo-registration algorithm and standard deviations & correlation coefficients output from a geo-registration process.

See MISB ST 1601 for generation and usage requirements.

### 8.99 Tag 100: Segment Local Set

LS Tag	100	Units	Range	Format	
LS Name	Segment Local Set	None	Set	Set	
US Mapped Key	Use ST 1607 Segment LS 16-byte key				
Notes		Conversion Formula			
- Local Set tag to include ST 1607 Segment LS within ST 0601.		x			
		x			
Example Value		Example LS Packet			
x		[K][L][V] = [0d100][0dx][x]			
US Key	06 0E 2B 34 02 0B 01 01 0E 01 03 03 03 00 00 00 (CRC 29742)	ESD Digraph	x		
US Name	Segment Local Set	ESD Name	x		
Units	Range	Format	Units	Range	Format
None	Set	Set	x	x	x
Notes		Notes			
- x		- x			
US Conversion		ESD Conversion			
x		x			
<u>To US:</u>		<u>To ESD:</u>			
- x		- x			
<u>To LS:</u>		<u>To LS:</u>			
- x		- x			

#### 8.99.1 Tag 100: Segment Local Set Usage

In applying the Segment LS Tag, it is best to take the perspective of the receiver of the data. Described in Section 6.5.3 is the concept of nesting a Local Set within a ST 0601 Local Set. In Section 6.5.4, this concept is expanded by allowing multiple uses of the same tag (i.e. same Tag ID, but with a different value) within a ST 0601 set along with the inclusion of a nested Local Set.

The principles underlying the Segment LS construct are found in the Motion Imagery Handbook [8]; ST 1607 [24] defines its rules of usage. At a high level, consider a UAS Datalink LS as consisting of a parent set of Tag's, and one or more child sets of Tag's. Segment LS enables use of ST 0601 Tag's at the parent level, and reuse of the same Tag's – possibly and likely with different Tag values – or other Tag's not specified at the parent level at the child level, effectively adding Tags with new values. A use of a Tag at the parent level is applicable across the ST 0601 set, whereas use of the same Tag within the Segment LS signals its use as restricted to the purpose indicated by other tags present within the Segment LS. For example, a Tag 94 MIIS Core Identifier at the parent level applies to the entire Motion Imagery frame; a Tag 94 within an Segment LS may apply to a second sensor image overlay and its specific sensor MIIS Core Identifier.

In cases where the MISB ST 0902 mandatory set of tags (which are a subset of ST 0601) are distributed between a parent/child set, the MISP requirement for the ST 0902 set is still satisfied.

It is incumbent on the system implementer to meet all required metadata elements for conformance, such as ST 0902 metadata, regardless of whether the set elements are present in a parent or a child set.

**8.100 Tag 101: Amend Local Set**

LS Tag	101	Units	Range	Format	
LS Name	Amend Local Set	None	Set	Set	
US Mapped Key	Use ST 1607 Amend LS 16-byte key				
Notes		Conversion Formula			
- Local Set tag to include ST 1607 Amend LS within ST 0601.			x		
			x		
Example Value		Example LS Packet			
x		[K][L][V] = [0d101][0dx][x]			
US Key	06 0E 2B 34 02 0B 01 01 0E 01 03 03 03 01 00 00 (CRC 17182)	ESD Digraph	x		
US Name	Amend Local Set	ESD Name	x		
Units	Range	Format	Units	Range	Format
None	Set	Set	x	x	x
Notes		Notes			
- x		- x			
US Conversion		ESD Conversion			
x		x			
<u>To US:</u>		<u>To ESD:</u>			
- x		- x			
<u>To LS:</u>		<u>To LS:</u>			
- x		- x			

**8.100.1 Tag 101: Amend Local Set Usage**

In applying the Amend LS, it is best to take the perspective of the receiver of the data. Described in Section 6.5.3 is the concept of nesting a Local Set within a ST 0601 Local Set. In Section 6.5.4, this concept is expanded by allowing multiple uses of the same tag (i.e. same Tag ID, but with a different value) within a ST 0601 set, along with the inclusion of a nested Local Set.

The principles underlying the Amend LS construct are found in the Motion Imagery Handbook [7]; ST 1607 [24] defines its rules for usage; an application of its use is found in MISB ST 1601 [22]. At a high level, consider a UAS Datalink LS as consisting of a parent set of Tag's, and one or more child sets of Tag's. Amend LS enables use of ST 0601 Tag's at the parent level, and reuse of the same Tag's – possibly and likely with different Tag values – or other Tag's not specified at the parent level at the child level, effectively adding Tags with new values. A use of a Tag at the parent level is applicable across the ST 0601 LS, whereas use of the same Tag within the Amend LS signals its use as restricted to the purpose indicated by other tags present within the Amend LS. For example, a Tag 13 Sensor Latitude at the parent level may also be at a child level, but with a different value. A receiver can choose either value to complete a ST 0601 set. In effect, the value of a Tag can be changed for the same Tag.

Metadata originating at its source is always maintained and never discarded. Values which “replace” existing elements are basically “added” to the overall ST 0601 metadata stream.

**8.101 Tag 102: SDCC-FLP**

LS Tag	102	Units	Range	Format	
LS Name	SDCC-FLP	Pack	Pack	Pack	
US Mapped Key	Use ST 1010 SDCC-FLP 16-byte key				
Notes		Conversion Formula			
- SDCC-FLP defined in MISB ST 1010.			x		
			x		
Example Value		Example LS Packet			
x		[K] [L] [V] = [0d102] [0dx] [x]			
US Key	06 0E 2B 34 02 05 01 01 0E 01 03 03 21 00 00 00 (CRC 64882)	ESD Digraph	x		
US Name	SDCC-FLP	ESD Name	x		
Units	Range	Format	Units	Range	Format
x	None	x	x	x	x
Notes		Notes			
- x		- x			
US Conversion		ESD Conversion			
x		x			
<u>To US:</u>		<u>To ESD:</u>			
- x		- x			
<u>To LS:</u>		<u>To LS:</u>			
- x		- x			

**8.101.1 Tag 102: SDCC-FLP Usage**

In applying the SDCC-FLP Tag, it is advised to review the usage of the SDCC-FLP (Standard Deviation Correlation Coefficient Floating Length Pack) construct presented in MISB ST 1010 [14]. The allowed metadata items from ST 0601 for use in the SDCC-FLP are denoted with a “Y” in the ST 0601 Table 1 column labeled SDCC FLP.

The SDCC defines a compact structure for two data lists: Standard Deviation and Cross Correlation values. The data type and size for each list must be self-consistent; all Standard Deviation values must be the same type and size; all Cross Correlation values must be the same type and size. The type and size of each list can be determined at runtime.

Important: In version 10 of ST0601 the Standard Deviation values are restricted to IEEE floating point values. Future versions of ST 0601 may allow for the use IMAP values after appropriate limits are defined for each Standard Deviation.

Cross Correlation values may use either IEEE or IMAP types as needed by the system producing the SDCC pack. Each value indicated with a “Y” in the SDCC FLP column of Table 1 can have uncertainty (i.e. standard deviation or sigma,  $\sigma$ ) computed or measured information.

Additionally, each value can be correlated to any of the other value resulting in a potential correlation coefficient value for that pair of values. Values with no correlation result in a correlation coefficient value of zero for that pair of values.

MISB ST 1010 defines how to package the standard deviation and correlation coefficient values. Per ST 1010, at runtime the list of values with standard deviation values defined constitutes the Refined Source List. The Refined Source List values are written into the UAS Datalink Local Set immediately followed by the SDCC-FLP, where each row of the SDCC-FLP upper triangular matrix is in the same order as the values just written in the Local Set.

The SDCC-FLP has five defining parameters: Matrix Size, Parse Control, Bit Vector, Standard Deviation Elements (values), and the Correlation Coefficient Elements (values).

#### 8.101.1.1 Matrix Size

The Matrix Size is set to the value of the Refined Source List. This value will be less than or equal to the size of the Source List.

#### 8.101.1.2 Parse Control

Mode 2 Parse Control is the mode used for ST 0601. Consult MISB ST 1010 for further description of Mode 1 and 2 of the Parse Control.

Requirement	
ST 0601.10-22	The UAS Datalink Local Set shall only include SDCC-FLPs using Mode 2 Parse Control, as defined in MISB ST 1010.

Five values in the Mode 2 Parse Control are computed at runtime:  $C_s$ ,  $S_f$ ,  $S_{len}$ ,  $C_f$ , and  $C_{len}$ .

- The  $C_s$  value indicates if the correlation coefficient values are sparsely represented in the SDCC-FLP.
- The  $S_f$  value defines the data format type of the standard deviation values, either IMAP (see MISB ST 1201 [15]) or IEEE Floating Point values. ST 1010 does not allow the mixing of types; therefore, all standard deviation values need to be converted to one type.
- Four-byte IEEE Floating Point values are recommended for standard deviation values.
- The  $S_{len}$  value defines the number of bytes used by each standard deviation value. If a system requires greater precision, more bytes can be added.
- The  $C_f$  value defines the data format type of the correlation coefficient values (i.e. either IEEE Floating Point or ST 1201 mapped values).
- The  $C_{len}$  value defines the number of bytes for each correlation coefficient value. Systems requiring greater precision can use more bytes.

#### 8.101.1.3 Bit Vector

As discussed in ST 1010 correlation coefficient data can be a sparse matrix. The Bit Vector indicates where to eliminate the zeros in the SDCC-FLP. See Appendix A in ST 1010 to determine when the Bit Vector should be used. The decision to use the Bit Vector can be made at run time.

#### 8.101.1.4 Standard Deviation Values

The standard deviation values in IEEE Floating Point, and included in the SDCC-FLP in the same order of the Refined Source List.



#### **8.101.1.5 Correlation Coefficient Values**

The correlation coefficient values converted to the desired data format, either IEEE Floating Point or ST 1201 mapped values, and included in the SDCC-FLP. The rows and columns of the correlation coefficient matrix are in the same order as the Refined Source List.

## 9 Appendix A – Deprecated Requirements

The following requirement was deprecated in ST 0601.6.

REQ-2.08 (ST 0601 decoders shall accept Universal Keys with any version number represented within byte 8.) as this is difficult to enforce from a compliance perspective, and is in with another requirement specifying the exact 16-byte KLV key to use (REQ-1.02) [REQ-1.02 is now REQ. ST 0601.8-18].